

# Operating Instructions

**STILL  
ELECTRONIC  
DOCUMENTATION  
SYSTEM**

## Diesel forklift truck

R70-40  
R70-45  
R70-50





## 1 Foreword

<b>Your industrial truck</b> .....	2
General .....	2
EC declaration of conformity, EC mark of conformity .....	2
<b>Information about documentation</b> .....	3
Documentation scope .....	3
Issue date and currentness of manual .....	4
Copyright and proprietary rights .....	4
Explanations of the signal terms used: .....	5
Explanation of the cross-references .....	5
Definition of directions .....	6
Sample graphics .....	6
<b>Environmental considerations</b> .....	7
Packaging .....	7
Disposal of units and batteries during repair work .....	7

## 2 Introduction

<b>Use of truck</b> .....	10
Proper use .....	10
Proper towing usage .....	10
Impermissible use .....	10
Place of use .....	11
Use of working platforms .....	12
<b>Residual risk</b> .....	13
Residual hazards, residual risks .....	13
Special risks when using the forklift truck and attachments .....	14
Overview of hazards and countermeasures .....	16
Risk for employees .....	18

## 3 Safety

<b>Definition of terms used for responsible persons</b> .....	20
Operating company .....	20
Specialist .....	20
Drivers .....	20
<b>Essentials for safe operation</b> .....	23
Insurance coverage on company premises .....	23
Changes and retrofitting .....	23
Warning regarding non-original parts .....	24
Damage, defects and misuse of safety devices .....	24

Tyres	25
Medical equipment	25
<b>Safety inspections</b>	26
Regular safety check of the industrial trucks	26
Checking the diesel engine emissions	26
Trucks with particle filters	27
Insulation test	27
<b>Safety regulations when handling working materials</b>	29
Permissible consumables	29
Oils	29
Diesel fuel	30
Hydraulic fluid	32
Battery acid	33
Coolant	33
Disposal of consumables	34
<b>Emissions</b>	35
<b>4 Overviews</b>	
<b>General view</b>	40
<b>Versions of driver's compartment</b>	42
Driver's compartment, single pedal version	42
<b>Operating and display elements</b>	44
Display and operating unit	44
Direction of travel/flasher/fault multi-function display	45
Mini-console	45
<b>Identification points</b>	46
Overview	46
Nameplate	46
C. U. R. data	47
Vehicle identification number	47
<b>Accessories</b>	48
Special equipment and variants	48
Attachments	49
Accessory overview	49
<b>5 Operation</b>	
<b>Checks and operations prior to start-up</b>	52
Visual inspections	52

Open the motor hood	53
Checking the engine oil level	54
Filling the washer system	55
Checking the condition of the wheels and tyres	55
Adjusting driver's seat MSG 65/MSG 75	56
Adjusting the steering column	59
<b>Start-up</b>	60
Turning on the key switch	60
Start the engine	62
Operating the signal horn	64
Restraining belt	64
Checking function of brake system	67
Checking function of steering system	68
Setting the traction programs	68
<b>Driving</b>	69
Safety regulations when driving	69
Behaviour in emergencies	71
Driveways	72
Driving (single-pedal operation with multiple lever version)	74
Operating the service brake	77
Operating the parking brake	79
Steering	80
<b>Lifting</b>	81
Lifting system variants	81
Lift mast versions	81
Malfunction during a lifting operation	82
Controls, lifting system	84
Lifting system, multi-lever operation	85
Fork extension	86
Operation with reversible forks	86
Emergency lowering	87
<b>Working with loads</b>	89
Safety regulations when handling loads	89
Prior to taking up a load	90
Carrying loading units	91
Hazard area	91
Transporting pallets	92
Transport of swinging loads	93
Taking up load	94
Transporting loads	97
Depositing and retrieving loading units	100

Driving on ascending and descending slopes	101
Driving on lifts	101
Driving on loading bridges	102
<b>Working with attachments</b>	103
Assembling attachments	103
Depressurising connections for attachments	104
General information on control of attachments	105
Controlling attachments using multi-lever controls	106
Taking up a load using attachments	107
<b>Operation of additional equipment</b>	108
Switching lighting on and off (special equipment)	108
Switching flashing light off and on	109
Switching hazard warning system off and on (special equipment)	110
Switching direction indicators off and on	111
Windscreen wiper/-washer	111
Cab	112
Heater	113
Driving with cruise control	113
<b>Trailer operation</b>	116
Towed load	116
Coupling the trailer	117
Towing trailers	119
<b>Operation of indicator and operating unit</b>	120
Displays	120
Display settings and changes	120
Setting the date or time	121
Resetting the daily number of kilometres and daily driving time	122
Setting the language	122
Fleet Manager functions	123
Additional settings	124
<b>Error messages</b>	125
Diagram	125
Error code table	126
SAFETY BELT message	130
Message SITZSCHALTER (SEAT SWITCH)	132
AIR FILTER message	135
BREMSE ANZIEHEN (APPLY HANDBRAKE!) message	135
LOWER FORKS message	136
REFERENCE LIFT message	137
ACCELERATOR message	137
BRAKE SENSOR message	138

SURVEILLANCE message	138
MOT/GEN-TEMP message	139
STEERING message	139
OIL PRESSURE message	140
COOLANT LEVEL message	140
COOLANT TEMP message	141
OVERHEATING message	141
ABGASREINIGER (EXH. GAS PURIFIER) message	142
<b>Operation in special operating situations</b>	<b>143</b>
Transport	143
Towing	144
Crane loading	145
Jump starting	147
<b>Filling fuel</b>	<b>149</b>
Filling up with diesel	149
<b>Shut-down</b>	<b>150</b>
Park truck secured	150
Use wheel chocks	151
Measures for prolonged shutdown, storage of truck	151
Returning to service after storage	152
<b>6 Maintenance</b>	
<b>General maintenance information</b>	<b>156</b>
Qualifications of personnel	156
Information regarding performing maintenance	156
Maintenance points overview	158
Intervals for maintenance and inspection	159
Ordering spare parts and wearing parts	162
Quality and quantity of the required operating materials	162
Diesel fuel	163
Maintenance data table	165
<b>Safety instructions for maintenance</b>	<b>167</b>
General information	167
Carrying out work on the hydraulic equipment	167
Working on electrical equipment	167
Safety devices	167
Set values	168
Raising and jacking up	168
Working at the front of the forklift truck	170

<b>Preparation for maintenance</b> .....	172
Installing and removing the floorplate .....	172
Removing and installing the rear cover .....	173
<b>Cleaning</b> .....	174
Cleaning the truck .....	174
Cleaning the electrical system .....	175
Clean load chains .....	175
Cleaning the windscreens .....	176
After washing .....	176
<b>Maintenance after first 50 operating hours</b> .....	177
Maintenance during the breaking-in period .....	177
<b>Maintenance as required</b> .....	178
Cleaning the radiator, checking for leaks .....	178
Topping up coolant and checking coolant concentration .....	178
Drain the fuel filter of water .....	180
Replacing the air filter insert .....	181
Checking parking brake setting .....	183
Servicing battery .....	183
Maintaining hydraulic equipment .....	186
Servicing Eberspächer particle filters .....	187
Servicing wheels and tyres .....	191
Lubricating joints and controls .....	192
Maintaining the steering axle .....	192
Servicing the mast bearing .....	195
Load chain maintenance .....	195
Lubricating the lift mast and roller track .....	198
Servicing the restraining belt .....	198
Check driver's seat .....	200
Replacing fuses .....	200
Attachment maintenance .....	202
<b>1000-hour maintenance/annual maintenance</b> .....	203
Other tasks .....	203
Maintenance of drive axle .....	203
Adjusting the parking brake .....	204
Lubricating the parking brake lever bearing and ratchet .....	204
Checking the counterweight attachment .....	204
Changing the engine oil and filter .....	204
Checking the ribbed V-belt .....	206
Checking the toothed belt .....	207
Replacing the fuel filter .....	207
Replacing the fuel filter for Eberspächer exhaust gas cleaners .....	208

Checking the exhaust gas system	208
Checking the heating system for leaks	208
Check lift cylinders and connections for leaks.	209
Maintain lifting system	209
Checking play between fork carriage stop and run-out stop	211
Checking the fork arms	211
Checking reversible fork arms	212
<b>3000-hour maintenance/two-year maintenance</b>	<b>213</b>
Work that must also be carried out	213
Changing the gear lubricant oil	213
Checking the wheel bearing	214
Checking the engine mountings	214
Replacing the toothed belt	215
<b>6000-hour maintenance</b>	<b>217</b>
Work that must also be carried out	217
Replacing the hydraulic oil and filter	217
<b>9000-hour maintenance/five-year maintenance</b>	<b>221</b>
Work that must also be carried out	221
Changing the coolant	221
<b>7 Technical data</b>	
<b>Dimensions</b>	<b>226</b>
<b>VDI datasheet</b>	<b>227</b>
<b>Wheels and tyres</b>	<b>230</b>
<b>Fuse assignment</b>	<b>231</b>
Fuse assignment in main fuse holder	231
Fuse assignment special equipment	232
<b>8 Circuit diagrams</b>	
<b>Hydraulics</b>	<b>234</b>
Hydraulic circuit diagram	234
<b>Electrical equipment</b>	<b>236</b>
Legend for circuit diagrams	236



1

---

## Foreword

## Your industrial truck

# Your industrial truck

## General

The industrial trucks described in this user manual are built to the applicable standards and safety regulations. If your industrial truck is to be driven on public roads it must satisfy the applicable Road Traffic Act provisions for the country concerned. The vehicle excise licence must be obtained from the appropriate office.

The industrial trucks are fitted with the most up-to-date technology. Now it's up to you to operate your industrial truck safely and obtain the benefits of its functional capabilities.


This user manual gives you the necessary information for this. Read it and follow these instructions before bringing your industrial trucks into use! This way you will avoid accidents, spare yourself worry and maintain the warranty.

## EC declaration of conformity, EC mark of conformity

With the EC declaration of conformity, the manufacturer confirms the compliance of the industrial truck with the standards and regulations valid at the time of marketing. The EC conformity mark is shown on the factory nameplate and indicates compliance with the above regulations.

A structural change or addition to the industrial truck on one's own authority can affect the safety in an unreliable way thus invalidating the EC declaration of conformity.

The EC declaration of conformity must be carefully stored and made available to the responsible authorities.



## Information about documentation

### Documentation scope

- Operating and maintenance manual
- Operating and maintenance manual for attachments (special equipment)
- Maintenance data table
- Spare parts list
- VDMA rules for the proper use of industrial trucks
- Inspection and test log book for power-driven industrial trucks (Germany only)

This operating and maintenance manual describes all necessary measures for safe operation and correct maintenance of your industrial truck. It includes all variants available up to the time of going to press. Special designs to meet customer requirements are documented in a separate operating and maintenance manual. For further information, please contact your service centre.

Please enter the factory no. and year of manufacture from the factory nameplate in the space provided ⇒ Chapter "Nameplate", P. 4-46 below:

**Factory no.** .....

**Year of manufacture**  
.....

Please provide these numbers for all technical questions.

An operating and maintenance manual is provided with every industrial truck. This manual must be stored carefully and must be available to the driver and operator at any time. The storage location is specified in the Overviews chapter ⇒ Chapter "Overviews", P. 39.

If the operating instructions are lost, the operator must obtain a replacement from the manufacturer immediately.

The operating and maintenance manual is included in the spare parts list and can be reordered as a spare part.

## Information about documentation

This operating and maintenance manual must be drawn to the attention of staff responsible for the operation and maintenance of the trucks.

The operator (see ⇒ Chapter "Definition of terms used for responsible persons", P. 20) must ensure that all users have received, read and understood this manual.

Thank you for reading and complying with this manual. For further information or improvement suggestions, or if you have identified errors, please contact our service centre.

## Issue date and currentness of manual

March 2007

STILL is constantly engaged in the further development of industrial trucks. Please note that these operating instructions are subject to change and any claims based on the information and figures contained in these operating instructions cannot be asserted.

If you require technical support for your industrial truck, please contact the responsible service centre.

We hope you enjoy your driving

STILL GmbH

Berzeliusstr. 4

D-22113 Hamburg

## Copyright and proprietary rights

This manual - and any excerpts thereof - may not be reproduced, translated or transmitted in any form to third parties without the express written permission of the manufacturer.

## Explanations of the signal terms used:

### DANGER

In the case of work procedures that must be strictly adhered to in order to prevent a danger to the life or physical condition of persons.

---

### WARNING

In the case of procedures that must be strictly adhered to in order to prevent injury to persons.

---

### CAUTION

In the case of procedures that must be strictly adhered to in order to prevent material damage and/or destruction.

---

### NOTE

*For technical requirements that require special attention.*

### ENVIRONMENT NOTE

*To prevent environmental damage.*

## Explanation of the cross-references

Cross-references refer to the respective chapter.


They give firstly the name of the chapter, then the chapter, and then the page in the document.

Example: ⇒ Chapter "Explanation of the cross-references", P. 1-5

## Information about documentation

### Definition of directions

The directions forwards (1), backwards (3), right (2), left (4) give the installation locations of parts as seen from the driving position; the load is at the front.




### Sample graphics

This documentation explains the (usually sequential) sequence of certain functions or operations. Schematic diagrams of a counterbalance truck are used to illustrate these sequences.



#### NOTE

*These schematic diagrams are not representative of the constructed state of the documented industrial truck. They serve only to illustrate the sequences.*



## Environmental considerations

### Packaging

During delivery of the industrial truck, certain parts are packaged to provide protection during transport. This packaging must be removed completely prior to initial start-up.



#### ENVIRONMENT NOTE

*The packaging material must be properly disposed of after delivery of the industrial truck.*

### Disposal of units and batteries during repair work

It may be necessary to replace units as part of maintenance work. Replaced units must then be disposed of.

Your vehicle is comprised of different materials. Each of these materials must be

- disposed of,
- treated or
- recycled in accordance with regional and national regulations.



#### NOTE

*When disposing of batteries, please refer to the battery manufacturer's documentation.*



#### ENVIRONMENT NOTE

*We recommend working with a waste management company for disposal purposes.*



2

---

## Introduction

## Use of truck

### Use of truck

#### Proper use

The forklift truck described in this operating manual is suitable for lifting, transporting and stacking loads.

The truck may only be used for its proper purpose, as set out and described in this operating manual.

If the truck is to be used for other purposes than those specified in the operating manual, the approval of the manufacturer and, if necessary, the responsible regulator authorities, must be obtained beforehand to prevent hazards.

The maximum load to be lifted is specified on the capacity plate (load diagram) and may not be exceeded.

#### Proper towing usage

This forklift truck is suitable for the occasional towing of trailers and is equipped with a towing device for this purpose. This occasional towing may not exceed 2% of the daily operating time. If you want to use the forklift truck for more frequent towing, the manufacturer must be consulted.

The trailer operation provisions must be followed. See ⇒ Chapter "Trailer operation", P. 116.

#### Impermissible use

Every hazard caused by impermissible use is the responsibility of the operator or driver and not of the manufacturer (also see in this matter ⇒ Chapter "Definition of terms used for responsible persons", P. 20).

Use for purposes other than those described in these operating instructions is prohibited.

**WARNING**

Risk of accident!  
Passengers are not allowed.

The forklift truck may not be operated in areas where is a risk of fire, explosion or corrosion, or areas that are particularly dusty.

Stacking or unstacking is not permissible on inclined surfaces or ramps.

## Place of use

The truck can be used outside and, with the correct equipment (e.g. a particulate filter), in buildings.

Use on public roads is only permitted if special equipment in accordance with StVZO (Road Traffic Licensing Regulations) is installed.

The various regulations applicable in different countries for driving the truck on public roads must be observed.

The ground must have sufficient load-bearing capacity (concrete, asphalt). It should have a rough surface. The driveways, work areas, and working widths must correspond with the specifications in the operating instructions (see ⇒ Chapter "Driveways", P. 5-72).

Driving on ascending and descending slopes is permitted if the indicated data and specifications are observed (see ⇒ Chapter "Driveways", P. 5-72).

The forklift truck is suitable for indoor and outdoor use from northern countries to the tropics (temperature range -20°C to +40°C).

This forklift truck is not designed for use in refrigerated buildings.

The operator (see ⇒ Chapter "Definition of terms used for responsible persons", P. 20) must ensure suitable fire protection in the surroundings of the truck for all applications of the truck. Depending on the application, additional fire protection must be provided on the industrial truck. In cases of doubt, contact the relevant authorities.

## Use of truck

### Use of working platforms

#### **WARNING**

The use of working platforms is governed by national law. This law must be observed. This allowed only if the law allows the use of working platforms in your country.

Consult your national authorities (in Germany the trade association) before any use.

---

## Residual risk

### Residual hazards, residual risks

Despite careful working and compliance with standards and regulations, the occurrence of other risks in using the industrial truck cannot be entirely excluded.

The industrial truck and all other system components comply with current safety requirements. Nevertheless, even with proper use and adherence to all instructions indicated, some residual risk cannot be excluded.

Even beyond the narrow hazard areas of the industrial truck itself, a residual risk cannot be excluded, which means that persons in this area around the industrial truck must exercise a heightened degree of awareness, so that they can react immediately in the event of any malfunction, incident or breakdown etc.

#### **WARNING**

All persons that are in the vicinity of the industrial trucks must be instructed regarding these risks that arise through use of the industrial truck.

In addition, we draw attention to the safety regulations in these operating instructions.

Risks can include:

- Escape of consumables due to leaks, rupture of lines and containers etc.
- Accident risk when driving over difficult ground such as gradients, smooth or irregular surfaces or poor visibility etc.
- Falling, tripping etc. when moving on the industrial truck, especially in the wet, with leaking consumables or icy surfaces.
- The stability of the industrial truck has been tested to the latest standards. These standards only take into account the static and dynamic tipping forces that can arise during specified use in accordance with the operating rules and intended purpose. Risks that arise from improper use or incorrect operation and result in tipping forces that exceed the stability cannot be excluded in extreme cases.
- Loss of stability due to the load being unstable or the load slipping etc.

## Residual risk

- Fire and explosion risks due to batteries and electrical voltages.
- Human error - disregarding safety regulations.

## Special risks when using the forklift truck and attachments

The manufacturer's approval must be obtained for any unconventional use during which the driver cannot ensure proper and safe execution.

In particularly difficult cases such as the simultaneous use of two forklift trucks for transporting heavy or bulky loads, the supervisor must be present at the place of use and accept responsibility and control of this transport.



## Residual risk

## Overview of hazards and counter-measures

### NOTE

*This flat sheet is intended to help evaluate the hazards in your facility and applies to all drive types.*

### NOTE

*Observe the national regulations for your country!*

Hazard	Action	Check note √ actioned - not affected	Notes
Industrial truck equipment does not comply with local regulations.	Testing	○	If in doubt, consult competent factory inspectorate or employers' liability insurance association
Lack of skills and qualification of driver	Driver training (sit-on and stand-on)	○	BGG 925 VDI 3313 driver permit
Usage by unauthorised persons	Access with key only for authorised persons	○	
Industrial truck not in safe operating condition	Recurrent testing and rectification of defects	○	BetrSichVO (Workplace Safety Ordinance)
Impaired visibility through load	Resource planning	○	BetrSichVO (Workplace Safety Ordinance)
Contamination of respiratory air	Assessment of diesel exhaust gases	○	TRGS 554 and BetrSichVO (Workplace Safety Ordinance)
	Assessment of LPG exhaust gases	○	MAK (Maximum Workplace Concentrations) list and BetrSichVO (Workplace Safety Ordinance)

Hazard	Action	Check note ✓ actioned - not affected	Notes
Impermissible usage (improper usage)	Issue of operating instructions	○	BetrSichVO (Workplace Safety Ordinance) and ArbSchG (Health and Safety at Work Act)
	Written notice of instruction to driver	○	BetrSichVO (Workplace Safety Ordinance) and ArbSchG (Health and Safety at Work Act)
	Observe BetrSichVO (Workplace Safety Ordinance), operating instructions and VDMA (German Engineering Federation) rules	○	
When fuelling			
a) Diesel	Observe BetrSichVO (Workplace Safety Ordinance), operating instructions and VDMA (German Engineering Federation) rules	○	
b) LPG	Observe BGV D34, operating instructions and VDMA (German Engineering Federation) rules	○	
When charging traction batteries	Observe BetrSichVO (Workplace Safety Ordinance), operating instructions and VDMA (German Engineering Federation) rules	○	VDE 0510: In particular - Ensure ventilation - Insulation value within permissible range
When using battery chargers	Observe BetrSichVO, BGR 104 and the operating instructions.	○	BetrSichVO and BGR 104
When parking LPG vehicles	Observe BetrSichVO, BGR 104 and the operating instructions.	○	BetrSichVO and BGR 104

## Residual risk

### Risk for employees

According to the operating safety ordinance (BetrSichVO) and German Law on Health and Safety at Work (ArbSchG) the operator (see ⇒ Chapter "Definition of terms used for responsible persons", P. 20) must ascertain and assess the hazards present at his plant. He must specify the necessary measures for health and safety for employees (BetrSichVO). The operator must thus draw up operating instructions applicable to his plant (§ 6 ArbSchG) and inform the driver accordingly. A person responsible for health and safety must be appointed.

Construction and equipment of the industrial truck correspond to the Machinery Directive 98/37/EEC and they are therefore identified with the CE symbol. They are therefore not included in the hazard assessment, and the attachments likewise on account of their own CE marking. The operator must however select the type and equipment of the industrial

trucks so as to comply with the local provisions for usage.

The result must be documented (Section 6 ArbSchG). In the case of industrial truck usage involving similar hazard situations it is permitted to summarise the results. The overview provided (see ⇒ Chapter "Overview of hazards and countermeasures", P. 2-16) means we are helping you to comply with these regulations. The overview specifies key hazards which are most frequently the cause of accidents in the event of non-compliance. If other major hazards are involved at a specific plant, these must be taken into consideration additionally.

In many plants the conditions of use for industrial trucks are by and large similar so that the hazards can be summarised in one overview. Take note of information of the respective employers' liability insurance association as regards this topic.

3

---

**Safety**

## Definition of terms used for responsible persons

# Definition of terms used for responsible persons

## Operating company

The operating company is the natural or legal person that operates the industrial truck or in whose employment the industrial truck is used.

The operating company must ensure that the forklift truck is used only for its proper purposes and in compliance with the safety instructions in this operating and maintenance manual.

The operating company must ensure that all users understand the safety information.

The operating company is responsible for the scheduling and correct performance of regular safety checks.

We recommend that the national performance specifications are adhered to.

## Specialist

A specialist is considered to be someone whose technical training and experience have enabled them to develop an appropriate knowledge of industrial trucks and who is sufficiently familiar with the applicable national health and safety regulations, accident prevention regulations, directives and generally recognised technical conventions (standards, VDE regulations, technical regulations of other member states of the European Union or other countries that are signatories to the treaty establishing the European Economic Area) as to be able to assess the condition of industrial trucks in terms of health and safety.

## Drivers

This industrial truck may only be driven by suitable persons who are at least 18 years old, who have been trained in driving, have demonstrated their skills in driving and handling loads to the operator or an authorised representative and have been specifically instructed to drive the truck. Specific knowledge

of the industrial truck to be operated is also required.

The training requirements under §3 of the Health and Safety at Work Act and §9 of the plant safety regulations are satisfied if the driver has been trained in accordance with the BGG (General Employers' Liability Insurance Association Act) 925. Follow the national regulations for your country.

### **Rights, duties and rules of behaviour for the driver,**

The driver must be trained in his rights and duties.

The driver must be granted the required rights.

The driver must wear appropriate protective equipment (protective clothing, safety shoes, safety helmet, protective goggles, gloves) for the conditions, the job and the load to be lifted. Strong footwear should be worn to ensure safe driving and braking.

The driver must be familiarised with the operating manual and it must be accessible to him at all times.

The driver must:

- have read and understood the operating manual,
- have familiarised himself with safe operation of an industrial truck,
- be physically and psychologically able to drive an industrial truck safely.

### **⚠ DANGER**

**Taking drugs, alcohol or medications that affect the response of an individual limits the ability of that individual to drive an industrial truck!**

Individuals under the influence of the above-mentioned substances are not permitted to perform any work on or with an industrial truck.

### **Prohibition on use by unauthorised persons**

The driver is responsible for the industrial truck during working hours. He may not allow unauthorised persons to operate the truck.

### Definition of terms used for responsible persons

When leaving the truck, he must secure it against unauthorised use.

## Essentials for safe operation

### Insurance coverage on company premises

In many cases, company premises are restricted public traffic areas.



#### NOTE

We advise checking your public liability insurance to determine whether you have insurance coverage for your industrial truck with respect to third parties in the event of damage in restricted public traffic areas.

### Changes and retrofitting

If your forklift truck is used for work not listed in the guidelines or in these instructions and must be consequently converted or retrofitted, be aware that each change to the structural state can affect the handling and the stability of the forklift truck and can result in accidents. Therefore, contact your customer service office in advance. Changes that will disadvantageously affect stability among other things may not be made without our approval.

The forklift truck can only be converted with our written approval. Approval from the responsible authority must be obtained if necessary.

We warn against the installation and use of restraint systems not approved by us.

If your forklift truck is equipped with a restraint system that is approved by the manufacturer, we nonetheless recommend using the restraining belt.

For safety reasons, it is prohibited to drill holes in the driver's overhead guard or to weld to it. In the case of welding to other locations of the forklift truck, the battery and all connections to the electronic control cards must be disconnected. Please contact your customer service office.

## Essentials for safe operation

### **⚠ DANGER**

**Operation of the forklift truck without the overhead guard at a lift height of over 1800 mm is prohibited. This voids the CE conformity!**

---

## Warning regarding non-original parts

Original parts, attachments and accessories are specially designed for this vehicle. We specifically draw your attention to the fact that parts, attachments and accessories supplied by other companies have not been tested and approved by us.

### **⚠ CAUTION**

Installation and/or use of such products may therefore have a negative impact on the design features of your industrial truck and thus impair active and/or passive driving safety.

We recommend that you obtain approval from us and, if necessary, from the responsible regulatory authorities, before installing such parts. The manufacturer accepts no liability for any damage caused by the use of non-original parts and accessories without our approval.

---

## Damage, defects and misuse of safety devices

The driver must report any damage or other defects to the truck or attachment immediately to the supervisory personnel.

Trucks and attachments that are not functional or safe to drive may not be used until they have been properly repaired.

Do not remove or deactivate safety devices and switches.

Fixed set values may only be changed with the approval of the manufacturer.

Work on the electrical system (e.g. connecting a radio, additional headlights, etc.) are only permitted with the manufacturer's written approval. All electrical system interventions must be documented.

Even if they are removable, roof panels may not be removed as they are designed to protect against falling small objects.

## Tyres

Tyre quality affects the stability and handling of the forklift truck. Changes can only be made in consultation with the manufacturer. When changing wheels or tyres, always ensure that no tilting of the forklift truck occurs (e.g. always change right and left wheels at the same time).

## Medical equipment

When a driver is wearing medical equipment, e.g. heart pacemaker or hearing aids, the operation of this equipment may be affected. A doctor or the manufacturer of the medical equipment should be asked whether the equipment is sufficiently protected against electromagnetic interference.

## Safety inspections

### Safety inspections

#### Regular safety check of the industrial trucks ▷

##### Safety check based on time and extraordinary incidents

The operator (see ⇒ Chapter "Definition of terms used for responsible persons", P. 20) must make sure that the industrial truck is checked by a specialist at least once per year or after special incidents (audit in line with accident prevention guidelines in Germany; please observe your national guidelines) (see ⇒ Chapter "Definition of terms used for responsible persons", P. 20).

A complete audit of the technical condition of the industrial truck is performed with regard to accident safety. In addition, the industrial truck must also be thoroughly checked for damage, that could have potentially been caused by improper use. An audit log must be created. The results from the audit must be retained until a further two audits have been carried out.

The schedule is indicated by a sticker on the vehicle. Use the "Test log book for power-driven industrial trucks"! Order No. 135745

Observe the guidelines for testing on your vehicles in accordance with accident prevention regulations (GERMAN ACCIDENT PREVENTION REGULATIONS FOR INDUSTRIAL TRUCKS).


The operator must ensure faults are rectified without delay. Please contact the service centre.

#### NOTE

*Observe the national regulations for your country.*

#### Checking the diesel engine emissions

- Check the diesel engine emissions annually to TRGS 554.



The emission analysis must be performed by a specialist, and documented in writing.

- Contact the customer service office.

 **NOTE**

*Follow the national regulations for your country.*

## Trucks with particle filters

Trucks with particle filters (special equipment) may be operated in completely or partially enclosed working areas.

 **NOTE**

*Observe the national regulations for your country!*

The operator must ensure that the following requirements are met; (see ⇒ Chapter "Definition of terms used for responsible persons", P. 20):

- Their use must be reported to the relevant health and safety authorities
- Operating instructions must be displayed in the working areas
- Employees must be informed
- The particle filter must be tested and serviced every 12 months or after every 1000 operating hours. The emission analysis must be performed by a specialist, and documented in writing.

 **NOTE**

*Observe the other regulations under TRGS 554 and/or your national regulations.*

## Insulation test

Industrial truck insulation must have a sufficient insulation resistance. The test is only necessary in the engine-generator circuit.

## Safety inspections

### **Test the insulation resistance of the electrical system.**

Have the insulation resistance of all active electrical parts tested according to DIN 57117 and DIN 43539, VDE 0117 and VDE 0510 at least once per year. Measurement voltage > nominal voltage < 500 V.

The insulation resistance is sufficient when it has a nominal voltage of at least 1000 Ohm/V against ground.

Contact STILL service personnel.

## Safety regulations when handling working materials

### Permissible consumables

#### WARNING

Consumables can be dangerous.

Follow the safety regulations when handling these substances.

Refer to the maintenance data table for the permissible substances necessary for operation. (See ⇒ Chapter "Maintenance data table", P. 6-165).

### Oils



#### WARNING

Oils are flammable.

- Follow the statutory regulations.
- Do not allow them to get onto hot engine components.
- Do not smoke while working.



#### WARNING

Oils are toxic!

- Avoid contact and consumption.
- If vapour or fumes are inhaled, administer fresh air immediately.
- After contact with the eyes, rinse thoroughly (for at least 10 minutes) with water and then consult an ophthalmologist.
- If swallowed, do not induce vomiting. Seek medical attention.

## Safety regulations when handling working materials



### ⚠ WARNING

Prolonged intensive contact with the skin can cause scouring and skin abrasion.

- Avoid contact and consumption.
- Wear protective gloves.
- Wash the skin with soap and water and use skin care products.
- Immediately change soaked clothing and shoes.

### ⚠ WARNING

Risk of slipping on spilled product, particularly when combined with water.

- Remove any spilled fluid immediately with oil binding agent and dispose of in line with the applicable regulations.



### ENVIRONMENT NOTE

*Oils are water pollutants!*

- *Always store oil in vessels that comply with the applicable regulations.*
- *Avoid spilling.*
- *Remove any spilled fluid immediately with oil binding agent and dispose of in line with the applicable regulations.*
- *Dispose of old oils according to the applicable regulations.*

## Diesel fuel



### ⚠ WARNING

Diesel fuel is combustible.

- Observe statutory regulations.
- Do not allow them to get onto hot engine components.
- Do not smoke!

**⚠ WARNING**

Diesel fuel is toxic!

- Avoid contact and consumption.
- If vapour or fumes are inhaled, administer fresh air immediately.
- After contact with the eyes, rinse thoroughly (for at least 10 minutes) with water and then consult an eye specialist.
- If swallowed, do not induce vomiting. Seek medical attention.

**⚠ WARNING**

Prolonged intensive contact with the skin can cause scouring and skin abrasion.

- Avoid contact and consumption.
- Wear protective gloves.
- Wash the skin with soap and water and use skin care products.
- Immediately change soaked clothing and shoes.

**⚠ WARNING**

Risk of slipping due to spilled diesel fuel, particularly in connection with water.

- Immediately remove spilled diesel fuel with an oil-binding agent and dispose of in accordance with regulations.

**ENVIRONMENT NOTE**

*Diesel fuel contaminates groundwater.*

- *Always store in regulation containers.*
- *Avoid spilling.*
- *Immediately remove spilled diesel fuel with an oil-binding agent and dispose of in accordance with regulations.*

## Safety regulations when handling working materials

### Hydraulic fluid



#### ⚠ WARNING

These fluids are pressurised during operation of the forklift truck and are hazardous to your health.

- Do not spill the fluids.
- Follow the statutory regulations.
- Do not allow to come into contact with hot motor parts.



#### ⚠ WARNING

These fluids are pressurised during operation of the forklift truck and are hazardous to your health.

- Do not allow to come into contact with the skin.
- Avoid inhaling spray.
- Penetration of pressurised fluids into the skin is particularly dangerous if these fluids escape at high pressure due to leaks in the hydraulic system. In case of such injury, immediate medical assistance is required.
- To avoid injury, use appropriate personal protective equipment (e.g. protective gloves, industrial goggles, skin protection and skin care products).



#### ENVIRONMENT NOTE

*Hydraulic fluid is a substance hazardous to water.*

- *Always store hydraulic fluid in containers complying with the regulations.*
- *Avoid spilling.*
- *Spilt hydraulic fluid should be removed with oil-binding agents at once and disposed of according to the regulations.*
- *Dispose of old hydraulic fluid according to the regulations.*

## Battery acid



### ⚠ WARNING

Battery acid contains dissolved sulphuric acid. This is toxic.

- Avoid contact and consumption.
- In case of injury, seek medical advice immediately.



### ⚠ WARNING

Battery acid contains dissolved sulphuric acid. This is corrosive.

- When working with battery acid, always wear protective clothing and eye protection.
- Do not allow any acid to get onto the clothing or skin or into the eyes; if this does happen, rinse immediately with plenty of clean water.
- In case of injury, seek medical advice immediately.
- Immediately rinse away spilt battery acid with plenty of water.
- Follow the statutory regulations.



### ENVIRONMENT NOTE

- Dispose of used battery acid in line with the applicable regulations.

## Coolant



### ⚠ WARNING

Coolant and coolant additive are hazardous to health.

- Store only in original vessels, do not spill.
- Never use empty food containers, bottles or other vessels for storing coolant.
- The legal regulations must be observed.



### ENVIRONMENT NOTE

## Safety regulations when handling working materials

- Immediately remove escaped coolant with an oil binding agent and dispose of in line with the regulations.
- Dispose of used coolant in line with the regulations.

## Disposal of consumables



### ENVIRONMENT NOTE

*Materials that have to be disposed of following maintenance, repair, and cleaning must be systematically collected and disposed of in accordance with regulations. Follow the national regulations for your country. Work may only be carried out in areas designated for the purpose. Care must be taken to minimise, as far as possible, any impact on the environment.*

- Any spillage of fluids such as hydraulic oil, brake fluid or gear lubricant oil must be immediately soaked up with an oil-binding agent.
- The regulations for disposal of used oil are applicable.
- Any spillage of battery acid must be neutralised immediately.

## Emissions

### Noise emissions

The values were determined based on measurement procedures from the standard EN 12053 (noise measurement in industrial trucks based on EN 12001 and EN ISO 3744 and the requirements of EN ISO 4871). This machine emits the following sound pressure levels:

continuous sound pressure level in the driver's compartment	
L <sub>pAZ</sub>	< 78 dB(A)
Uncertainty K <sub>pA</sub>	4 dB(A)

The values were determined in the test cycle on an identical machine from the weighted values for operating conditions and idling.

Time percentages:

- Lifting 18%
- Idling 58%
- Driving 24%

However, the indicated noise levels at the truck cannot be used to determine the noise emissions at workplaces according to the most recent version of **Directive 2003/10/EC** (daily personal noise pollution). If necessary, these should be determined directly at the workplace under the actual conditions there (additional noise sources, special conditions of usage, sound reflections) by the operating company; (see ⇒ Chapter "Definition of terms used for responsible persons", P. 20).

### Vibrations

The vibrations of the machine must be determined on an identical machine in accordance with the standard EN 13059 "Vibration measurements on industrial trucks".

Weighted effective value of the acceleration the body (feet or seat surface) is subjected to	< 0.59 m/s <sup>2</sup>
Uncertainty K	0.177 m/s <sup>2</sup>

Tests have indicated that the amplitude of the hand and arm vibrations on the steering wheel

## Emissions

or the operating elements in the truck are less than  $2.5 \text{ m/s}^2$ . There are therefore no measurement guidelines for these measurements. The personal vibration load on the driver over a working day shall be determined in accordance with the **Directive 2002/44/EC** by the operating company (see  $\Rightarrow$  Chapter "Definition of terms used for responsible persons", P. 20) at the actual place of use, in order to consider all additional influences, such as driving route, intensity of use etc.

### Exhaust gases

The engine releases exhaust gases into the environment during operation. The exhaust gases consist mainly of water vapour, carbon dioxide ( $\text{CO}_2$ ), carbon monoxide ( $\text{CO}$ ), hydrocarbons ( $\text{CH}$ ), aldehydes, nitrogen oxide ( $\text{NO}_x$ ) and soot. The components  $\text{CO}$ ,  $\text{CH}$ ,  $\text{NO}_x$  and soot are poisonous or are health hazards, and may not be breathed at high concentrations.

### Diesel engine emissions (DME)

Diesel engine emissions are harmful to health. In particular the particulates contained in the exhaust gases can cause cancer.

#### WARNING

Danger to health!

If your truck is not equipped with a particle filter (exhaust gas purifier for diesel engines), it is not allowed to operate in completely or partially enclosed working areas.

### Heat



#### WARNING

The exhaust gases are very hot and can ignite combustible material.

The exhaust pipe should therefore be kept away from combustible materials.

## Battery



### **⚠ WARNING**

During charging, the battery releases a mixture of oxygen and hydrogen (detonating gas). This gas mixture is explosive and must not be ignited.

Suitable ventilation and keeping it away from open flames can avoid the danger of explosion. Observe the safety regulations for handling the battery.

---




4

---

## Overviews

## General view

## General view



- 1 Lift mast
- 2 Overhead guard
- 3 Steering wheel
- 4 Driver's seat


- 5 Steering axle
- 6 Drive axle
- 7 Tilt cylinder
- 8 Fork arms



## Versions of driver's compartment

## Versions of driver's compartment

## Driver's compartment, single pedal version



7071\_003-001


## Versions of driver's compartment

1	Steering wheel	10	Display and operating unit
2	Steering column adjustment lever	11	Storage box
3	Direction of travel/flasher/fault multi-function display	12	Bottle holder for 1 l-PET bottles
4	Travel direction switch	13	Parking brake lever
5	"Lift-lower" operating lever	14	Storage compartment for user and maintenance manual
6	"Tilt" operating lever	15	Driver seat
7	"Attachments" operating lever	16	Accelerator pedal
8	"Attachments" operating lever	17	Bonnet release
9	Emergency stop switch for Eberspächer particle filter system	18	Brake pedal
		19	Alarm horn foot switch

## Operating and display elements

## Operating and display elements

## Display and operating unit



7311\_560-001


- |    |                                 |    |                           |
|----|---------------------------------|----|---------------------------|
| 1  | Front windscreen wiper switch   | 13 | Rear window heater switch |
| 2  | Work light switch               | 14 | Rear searchlight display  |
| 3  | Rear windscreen wiper switch    | 15 | Rear searchlight switch   |
| 4  | Flashing light switch           | 16 | Time symbol               |
| 5  | Lighting switch                 | 17 | Time                      |
| 6  | Switch - hazard warning lights  | 18 | Operating hours symbol    |
| 7  | Traction program switch         | 19 | Operating hours display   |
| 8  | Menu change key                 | 20 | Traction program symbol   |
| 9  | Fleet Manager smart card reader | 21 | Current traction program  |
| 10 | Interior light display          | 22 | Fuel fill-up symbol       |
| 11 | Interior light switch           | 23 | Fuel level in %           |
| 12 | Rear window heater display      |    |                           |

**NOTE**

*The displays (10, 12, 14) as well as the buttons (11, 13, 15) are assigned independently from the additional electrical special equipment.*

### Direction of travel/flasher/fault multi-function display

The direction of travel/flasher/fault multi-function display is used to display the direction of travel. In addition, the flasher is used to indicate that messages are shown on the display and operating unit.




- 1 Forward travel display
- 2 Right flasher display
- 3 Reverse travel display
- 4 Message display
- 5 Left flasher display

### Mini-console

The mini console is located on the steering column below the steering wheel.

**i** NOTE

*Switch (1) is not assigned in trucks with the travel direction switch on the "lift-lower" operating lever.*



- 1 Travel direction switch
- 2 Direction indicator switch

## Identification points

### Identification points


#### Overview

#### Warning labels

The label locations on your vehicle were not yet finalized at the time of printing. Observe the warning and information labels on your vehicle.

#### Nameplate


It is possible to identify your forklift truck from the information on the nameplate.



- 1 Type
- 2 Factory no. ....
- 3 Year of construction
- 4 Tare weight kg
- 5 Permissible battery weight, max. (only for electric lift trucks)
- 6 Permissible battery weight, min. (only for electric lift trucks)
- 7 Ballast weight (only for electric lift trucks)
- 8 Refer to the technical data listed in these operating instructions for more detailed information
- 9 CE mark
- 10 Nominal drive rating
- 11 Battery voltage V
- 12 Nominal forklift capacity kg

### C. U. R. data

This label provides information on the weight and the load distribution of your truck.



- 1 Admissible rear axle load in kg
- 2 Admissible total weight kg
- 3 Admissible front axle load in kg

### Vehicle identification number




**NOTE**

*Please state this serial number when making technical inquiries.*

The serial number contains the following information:

- 1 Production site
- 2 Type
- 3 Variant
- 4 Serial number



## Accessories

**Accessories****Special equipment and variants****Driver seat**

Driver's seat MSG 65:

- Textile cover, lumbar support
- Synthetic leather, lumbar support, heating, backrest extension
- Textile cover, lumbar support, heating, backrest extension

Driver's seat MSG 75:

- Synthetic leather, lumbar support, heating, backrest extension
- Textile cover, lumbar support, heating, backrest extension

**Overhead guard and cabin**

- Overhead guard
- Cab weather protection
- Cabin
- Cabin with heater

**Lift mast****NOTE**

*Overall height and lifting height, see ⇒ Chapter "Technical data", P. 225.*

- Tele
- Triple
- Load guard

**Electrical equipment**

- Standard lighting system
- Lighting system according to StVZO (Road Traffic Licensing Regulations)
- Left/right/front/rear searchlight
- Flashing light
- Reverse light
- Dual-pedal control drive operation
- FleetManager
- Accident recorder
- Cruise control

## Switching off

Particle filter system

- Eberspächer

## Attachments

- Fork extension
- Warning beam
- Grille
- Mandril
- Crane arm
- Snow remover
- Shovel
- Sideshift
- Clamp forks without sideshift
- Bale clamp without sideshift
- Clamp forks with sideshift
- Bale clamp with sideshift
- Fork arm adjustment

## Accessory overview

- Key for key switch (2 pieces)
- Key for cab (special equipment)
- Emergency lowering key
- Release tool for bonnet



5

---

Operation

## Checks and operations prior to start-up

## Checks and operations prior to start-up

## Visual inspections

**▲ WARNING**

Damage or other defects of the forklift truck or attachment (special equipment) can result in accidents.

If damage or other defects are identified on the forklift truck or attachment (special attachment) during the following inspections, do not use the vehicle until it has been repaired properly. Do not remove or deactivate safety devices and switches. Do not change predefined set values.

**▲ WARNING**


Risk of falling!

When working on high-level areas of the truck, do not use truck components for access or to stand on.

- Always use suitable equipment for this.

Prior to start-up, a safe operating state must be ensured:

- The retaining devices (1) of the fork arms for preventing lifting and shifting should not show any defects.
- Fork arms or other load-carrying equipment may not have any noticeable damage (e.g. bends, cracks, significant wear).
- The chains must be undamaged and evenly and adequately tensioned.
- Check the area under the forklift truck for leaking consumables.
- The guard grille (special equipment) and overhead guard must be undamaged and secure.
- Attachments (special equipment) must be properly secured and function according to their operating instructions.
- Check whether all information labels/notices are present and legible. Damaged or missing stickers must be replaced according to the overview of sticker locations ⇒ Chapter "Overview", P. 4-46.



- The roller tracks (2) must be lubricated with a visible lubricant film.
- Check the hydraulic system and hydraulic oil tank where visible for damage and leaks. Damaged hoses must be replaced.
- Check the fuel system and fuel tank where visible for damage and leaks. Damaged hoses must be replaced.
- The motor hood must be securely closed.
- Steps must be clean and free of ice.
- In the case of versions with a cabin (special equipment) all windows must be clean and free of ice. Switch on the heater (special equipment) and set the air vents so that the windows remain free of ice.
- Report defects to the supervisor.

## Open the motor hood.

### **⚠ WARNING**

Risk of injury!

Switch off the engine before opening the bonnet.

- Lock steering column (1) into the frontmost position.
- Slide the driver's seat completely forward and, in vehicles with a rear window, fold the seat back (2) forward; see ⇒ Chapter "Adjusting driver's seat MSG 65/MSG 75", P. 5-56.



## Checks and operations prior to start-up

- Insert the release tool (3) and release the catch. To open it, use the release tool from the accessories. ▷



### NOTE


*The catch can be secured with a lock. Release the lock beforehand.*

- Use the handle (4) next to the driver seat to open the motor hood to the rear.

### ⚠ WARNING

Risk of accident!

The release tool must always remain with the vehicle, so that in an emergency the bonnet can be opened at any time!




7311\_120-002

## Checking the engine oil level

- Position truck horizontally.
- Pull out the dipstick (1) and wipe it off.
- Insert dipstick to the stop and pull out again.

The oil level must be between the marks (arrows).

- If the oil level is not up to the required level, top up the engine oil according to the data in the maintenance table, see ⇒ Chapter "Maintenance data table", P. 6-165.



7071\_003-057


### Filling the washer system

- Open the lid (1).
- Fill the washer reservoir (2) using washer fluid with anti-freeze.

**⚠ CAUTION**

If there is no anti-freeze in the washer system (special equipment), the washer system may be damaged.

- Top up the container with clean water.
- Close lid.
- Operate the washer system until washer fluid is discharged from the spray nozzles.



### Checking the condition of the wheels and tyres

**⚠ WARNING**

Risk of accident! With uneven wear or incorrect air pressure, the stability of the forklift truck decreases and the braking distance increases.

Renew left and right worn or damaged tyres without delay.

**i NOTE**

- Only permissible tyre types may be used, see ⇒ Chapter "Wheels and tyres", P. 7-230.


- Check tyres (1) for wear or damage.

Tyres cannot be damaged or worn. They must be worn evenly on both sides.

- Check air pressure. The air pressure given on the stickers (2) must be observed.

**i NOTE**

Note the safety principles for tyres, see ⇒ Chapter "Tyres", P. 3-25.



## Checks and operations prior to start-up

## Adjusting driver's seat MSG 65/MSG 75

### **⚠ DANGER**

#### **Risk of accident!**

Do not adjust the seat while driving.

- Adjust the seat in such a way that you can safely reach and operate all the controls.

On some versions (special equipment), the amount of head clearance on your forklift truck may be restricted. On these versions, the distance between the head and the lower edge of the roofing sheet must be at least 40 mm.

### **i NOTE**

*If your truck comes with separate operating instructions for the seat, they must be followed.*

### **⚠ WARNING**

#### Risk of injury

To obtain optimum seat cushioning, you must adjust the seat suspension to your own body weight. This helps your back and protects your health.

To prevent injury, make sure that there are no objects in the swivel area of the seat.


### Moving the driver's seat

- Pull lever (1) up and move the seat.
- Release the lever.

### **⚠ WARNING**

#### Risk of injury

- Make sure that the seat is securely engaged.



7094\_003-006


### Adjusting the backrest

- Pull lever (2) upwards and adjust the incline of the seat back using your body weight.
- Release the lever.

#### **⚠ WARNING**

Risk of injury

- Make sure that the backrest is engaged.



### Adjusting the seat suspension to your weight

#### **i NOTE**

*This adjustment should only be made while the seat is loaded.*

#### **i NOTE**


*The MSG 75 seat is equipped with an electric air suspension activated with an electric switch instead of a (3) lever.*

- Completely fold open lever (3) and adjust the driver's weight by pumping up or down.
- Return the lever (3) back to the initial central position before each new lift (audible click).

#### **i NOTE**

*A noticeable empty lift on the operating handle shows you have reached the minimum or maximum weight setting.*

The correct driver's weight has been selected when the arrow is in the middle of the view window.




## Checks and operations prior to start-up

### Adjust lumbar support (special equipment) ▷

- Adjust the lumbar support by turning the (4) hand wheel.


By turning upwards, the convexity of the upper lumbar support can be adjusted individually, and by turning downwards, the lower area can be adjusted individually.



### Adjusting backrest extension (special equipment) ▷

- Adjust the seat back extension (5) by pulling it out or pushing it in to the desired position.

To remove the seat back extension, move it past the end stop by jolting it upwards.



### Switching seat heater (special equipment) on and off

- Switch the seat heater on or off (6) using the switch.



### Adjusting the steering column


- Loosen the button (1) of the steering column locking device.
- Position the steering column (2) and retighten the button.

#### **⚠ WARNING**

Risk of accident!  
Ensure that the steering column is secure.

#### **⚠ DANGER**

Risk of accident!  
Never adjust the steering column while driving.



## Start-up

## Start-up

## Turning on the key switch

**⚠ WARNING**

Before switching on the key switch, all tests before commissioning must be performed without detecting any defects.

- Perform checks prior to start-up, see  
⇒ Chapter "Checks and operations prior to start-up", P. 52.



If defects are identified, the truck may not be switched on! Please contact your supervisor or service centre.

**⚠ DANGER****Risk of accident!**

Only drive with the bonnet locked.

- Insert the ignition key (1) into the key switch and turn it to the right into the operating position "I".

This initiates a self-test. All lamps in the multi-function display light up briefly.



Upon switching on the key switch, the display shows the welcome screen in the set language until the vehicle controls have completely started up. ▷



**Displays during the switching-on operation** ▷

- Fuel level (1).

The fuel level can be displayed as either a percentage or bar display in the display field.

- Top up if necessary, see ⇒ Chapter "Filling fuel", P. 149.


- Traction program (2).

The current traction program appears in the display.

- Operating hours (3).

The operating hours appear on the display.

- Inform your service centre when a maintenance interval is reached.



**i NOTE**

*Have all repair and maintenance work performed by your responsible service centre. Defects can only be corrected permanently in this manner.*

- Time display (4).

The time appears on the display.

## Start-up

### NOTE

*The three buttons (5) below are assigned independently from the additional electrical special equipment.*

### NOTE

*Additional information can appear on the display.*

- *If there are fault displays, please consult the instructions in the corresponding chapter, see ⇒ Chapter "Error messages", P. 125).*


## Start the engine

- Apply the parking brake.

### WARNING

Toxicity hazard from exhaust gases.  
Do not allow engine to run in unventilated rooms.

- Insert the key (3) into the key switch and turn it to position "I".



- The display **GLUEHEN (GLOW)** (4) flashes to indicate that the engine has been preheated.

**NOTE**

*Preheating can take up to 20 seconds. If the engine is already warmed up, preheating is not performed.*

- If the display **STARTEN (START)** lights up, turn the key to position "II" and hold until the engine starts.
- As soon as the engine has started, release the key.

If the engine does not start after 20 seconds, end the starting operation and start again after one minute.

**CAUTION**


Risk of engine damage!

- If the message **OELDRUCK (OIL PRESSURE)** appears in the display after the engine has been started, turn off the engine immediately.

Refer to the information in the chapter "Fault displays". See ⇒ Chapter "Error messages", P. 125).

**NOTE**

*If the engine cannot be started due to a discharged battery, it can be jump-started; see ⇒ Chapter "Jump starting", P. 5-147.*




## Start-up

**Operating the signal horn**

- Press the foot switch (1).

The signal horn sounds.

**Restraining belt****⚠ DANGER**

**Driving without a seat belt is dangerous and never permitted!**

- Always fasten the seat belt before driving.

**⚠ DANGER**

**Only a full cab with closed, fixed doors or bracket doors is an operator restraint system. PVC doors are not a restraint system.**

If the doors are open or removed, you must use a different, suitable restraint system (e.g. restraining belt).

## Fastening the restraining belt

### ⚠ WARNING

Risk of accident!

- Fasten belt before any movement of the truck. The belt must not be twisted when fastening.
- Only use the belt to secure one person!
- If you notice any malfunction in the belt while fastening, have the belt repaired.

### i NOTE


The buckle has a buckle switch (special equipment). If there is an operating error or malfunction, the message SICHERHEITSGURT (SAFETY BELT) appears in the display and operating unit (see ⇒ Chapter "SAFETY BELT message", P. 5-130).

- Pull belt (3) out of retractor without jerking and fasten closely around the body over the thighs.

### i NOTE

Sit back as far as possible, so that your back is against the seat back. The automatic blocking mechanism permits sufficient freedom of movement.

- Click belt latch (2) into buckle (1).
- Check tension of the belt. It should be close to the body.




7311\_003-048

## Fastening on a steep slope

The automatic blocking mechanism prevents the belt from being extended whenever the forklift truck is on a steep gradient. It is not possible to pull the belt any further out of the retractor.

- Drive off the slope carefully.
- Fasten the belt.




7071\_003-035

## Start-up

**Releasing the restraining belt**

- Press red key (4) on the buckle (1).




- Slowly move belt latch (2) back into belt retractor (3) by hand.

**NOTE**

*Do not allow the belt to quickly retract. The automatic blocking mechanism may be triggered if the belt latch strikes the housing. It will no longer be possible to pull the belt out again with the usual force.*

- Using increased force, pull the belt out of the belt retractor approx. 10-15 mm and release the block.
- Slowly allow belt to retract again.
- Protect belt from dirt (for example, by covering it).

**Malfunctions due to cold**

- Melt ice and dry buckle or belt retractor to prevent repeated freezing.

**CAUTION**

Do not subject buckle or belt retractor to excessive heat while melting ice.

Do not use air warmer than 60 °C to melt ice!

## Checking function of brake system

### **⚠ DANGER**

#### **Risk of accident!**

Do not put forklift trucks with a defective brake system into service.


### Checking the foot brake

- Checking pedal clearance.

The brake must have sufficient distance from the pressure point to the pedal stop.

- Accelerate empty truck in a clear area.
- Press the brake pedal (1) firmly.

Check brake for noticeable delay.




### Checking the parking brake

- Check operation of parking brake (2) at walking speed or on a large gradient.

### **⚠ DANGER**

#### **Risk of accident!**

During operation, the forklift truck must never be parked on slopes. In an emergency, secure the forklift truck by inserting chocks on the downhill side.



## Start-up


### Checking function of steering system ▷

- Operate steering wheel (1). The play of the steering wheel while stationary may not be more than two finger widths.

#### **⚠ DANGER**

##### **Risk of accident!**

If the hydraulics malfunction, steering is stiff.  
The forklift truck may not be operated with a defective steering system.



### Setting the traction programs ▷


The driving and braking response of the drive can be set on the display and operating unit.

- Press the traction programme key (1) until the number of the desired traction programme appears on the (2) display.

Traction programs 1-5 are available.

The basic principle is that the higher the traction program number is, the greater the traction dynamics.

The following settings are possible:



Traction program	1	2	3	4	5
Speed (km/h)	21	21	21	21	21
Acceleration (%) (forward / backward)	50	100	120	140	160
Deceleration (%) (forward / backward)	50	100	120	140	160
Reversing (%) (forward / backward)	50	100	120	140	160
Brake retardation (%) (electric brake booster)	80	90	100	100	100

## Driving

### Safety regulations when driving

#### Driving conduct

The driver must observe public road traffic regulations when driving on company grounds.

Driving speed must be appropriate to the local conditions.

For example, the driver must drive slowly around corners, in tight passage ways, when driving through swing-doors, at blind spots or on uneven surfaces.

The driver must always maintain a safe braking distance from vehicles and persons in front and always have the vehicle under control. Sudden stopping, quick turning and overtaking at dangerous or blind spots must be avoided.

- Initial driving practice must be performed in an empty space or on a clear driving lane.

The following are forbidden during driving:

- Allowing arms and legs to hang out
- Leaning over the outer edge of the forklift truck
- Crossing from one vehicle to another or to fixed components
- Moving the driver seat
- Adjusting the steering column
- Releasing the restraining belt
- Disabling the restraint system
- Driving with the load raised impermissibly high
- Using mobile phones or radios.

#### **WARNING**

Risk of accident!

Use of mobile phones or radios in the vehicle is permitted.

However, these devices must not be used while driving or manipulating loads, since this affects your concentration.

The volume of radios or hands-free systems must be adapted to local conditions and must not affect your concentration.

## Driving

### **▲ WARNING**

In areas where use of mobile phones is prohibited, use of a mobile phones or radio telephones is generally not permitted.

- Turn off the devices.

### **Visibility when driving**

The driver must look in the direction of travel and have a sufficient view of the driving lane.

Particularly when driving backwards, the driver must be sure that the driving lane is clear.

When transporting goods that impair visibility, the driver must drive the vehicle backwards.

If this is not possible, a second person acting as a guide must walk ahead of the vehicle.

Only drive at walking pace and always take extra care in such situations. The forklift truck must be stopped immediately if eye contact with the guide is lost.

Driving with the load raised unnecessarily high is not permitted.

Rear-view mirrors are only to be used for observing the road area behind the vehicle and not for driving backwards. If visual aids (mirror, monitor) are necessary to achieve sufficient visibility, their use must be carefully practised. When driving backwards using visual aids, extra care should be used.

When using attachments, special conditions apply, see ⇒ Chapter "Assembling attachments", P. 5-103.

In models with cabins, the windows must always be clean and free of ice.

## Behaviour in emergencies

### Procedure if truck tips over

#### **⚠ WARNING**

Risk of injury!

Failure to comply with the limits specified in these operating instructions, e.g. driving on unacceptably steep inclines or failing to adjust speed when cornering, can cause the truck to tip over.



If the truck is threatening to tip over, you should not under any circumstances attempt to jump clear. This increases the risk of injury. Do not release your seat belt!

#### The correct behaviour is as follows:

- Bend your upper body over the steering wheel.
- Hold on tight to the steering wheel with both hands and brace yourself with your feet.
- Bend your body against the direction of the fall.
- On forklift trucks with a cabin, if the door cannot be opened after tipping over; the emergency hammer (1) can be used to break the windscreen.

#### **⚠ WARNING**

Glass splinters may cause injuries.  
Protect your face by turning away.




## Driving

## Driveways

## Dimensions of the driveways and aisle widths

The following dimensions and aisle width requirements apply under the specified conditions to ensure safe manoeuvring. In each case, it should be checked whether a larger aisle width is necessary, e.g. with deviating load dimensions. Within the EU, the 89/654/EEC directive (Minimum guidelines for protecting safety and health) must be maintained. The respective national guidelines apply for the areas outside of the EU.

The required aisle widths (Ast) depend on the dimensions of the load. For pallets, these are:



aisle width (mm)	with pallet 1000x1200 crosswise	with pallet 800x1200 longitudinal
R70-40	4418	4618
R70-45	4470	4670
R70-50	4510	4710

The forklift truck may only be used on driveways that do not have curves that are too tight, have slopes that are too steep and have thoroughfares that are not too narrow or low.

## Driving on slopes

The truck may be driven on the following upwards or downwards slopes:

Max. gradient in %	with load	without load
R70-40	22	34
R70-45	20	33
R70-50	18	32

The upwards and downwards slopes may not exceed the gradient listed above and should have a rough surface.

Smooth and gradual transitions should be provided at the top and bottom of the gradient

to avoid the load from falling on the floor or the forklift truck being damaged.

### **Condition of the driveways**

Driveways must be made sufficiently firm, and be level and free of dirt and fallen objects. Compensation must be made for drainage channels, level crossings and similar items; and if necessary, ramps must be provided, so that trucks can drive over them with as few bumps as possible.

Ensure sufficient load-bearing capacity of manhole/drain covers and the like.

There must be sufficient clearance between the highest points of the forklift truck or the load and the fixed points of the surroundings. The height is based on the overall height of their lift mast and the dimensions of the load. Observe the technical data (see ⇒ Chapter "Technical data", P. 225).

### **Rules for driveways and the working area,**

Only those routes authorized for traffic by the operator (see ⇒ Chapter "Definition of terms used for responsible persons", P. 20) or his representative may be driven. The traffic routes must be free of obstacles. The load may only be set down and stored in the designated locations. The operator and his representative must ensure that unauthorised third parties keep away from the area of operation.

### **Dangerous locations**

Dangerous locations on the driveways must be designated by the signs typical for traffic or, if necessary, by additional warning signs.

## Driving

## Driving (single-pedal operation with multiple lever version) ▷

### ⚠ DANGER

#### Risk of accident!

- Only operate the forklift truck from the driver seat.

Please take note of information in the section entitled Safety Regulations when driving (see ⇒ Chapter "Safety regulations when driving", P. 5-69).


- Sit down on the driver's seat.

The driver's seat is equipped with a seat switch. If there is an operating error or malfunction, the message **SITZSCHALTER** (SEAT SWITCH) appears in the display and operating unit (see ⇒ Chapter "Message SITZSCHALTER (SEAT SWITCH)", P. 5-132).

- Fasten the safety belt.

The buckle has a buckle switch (special equipment). If there is an operating error or malfunction, the message **SICHERHEITSGURT** (SAFETY BELT) appears in the display and operating unit (see ⇒ Chapter "SAFETY BELT message", P. 5-130).

- Lift the fork carriage until the necessary floor clearance is achieved. To do this, pull back the "lift-lower" operating lever(1).
- Tilt the mast back by pulling back the (2)"tilt" operating lever.
- Do not take up a load yet!



### Travel direction switch

The travel direction switch (5) is used to select the desired travel direction. The appropriate arrow for the selected travel direction lights up on the travel direction/flasher/fault (4) multi-function display.

**i NOTE**

*When the seat is vacated, the travel direction switch is set to neutral.*



### Forwards motion

- Release the (6) parking brake.
- Press down the lower section of the travel direction switch (5).
- The arrow for forward motion (4) lights up.
- Press accelerator pedal (3).

The forklift truck moves forwards. The speed is controlled by the accelerator pedal position. When releasing the accelerator pedal, the forklift truck decelerates. On a gradient the truck creeps downhill slowly after a stop.

**i NOTE**

*The truck can briefly be stopped on upward or downward inclines without actuating the parking brake (6) (electric brake). The truck begins to creep downwards slowly.*



**⚠ DANGER**

#### Risk of accident!

Do not leave the vehicle.

This electric brake only functions while the key switch is switched on and the parking brake is released. Press the brake pedal!

## Driving

**Reverse motion**

- Release the (6) parking brake.
- Press down the upper section of the travel direction switch (5).
- The arrow for reverse motion (4) lights up.

**NOTE**

*At the same time, an acoustic signal sounds (special equipment) as a warning or the back-up light as well as the front headlights light up (only if there is a lighting system (special equipment) in accordance with the Road Traffic Licensing Regulations). At the same time, an acoustic signal sounds (special equipment) as a warning or the back-up light as well as the front headlights light up (only if there is a lighting system (special equipment) in accordance with the Road Traffic Licensing Regulations).*

- Press accelerator pedal (3).

The forklift truck travels backwards. The speed is controlled by the accelerator pedal position. When releasing the accelerator pedal, the forklift truck decelerates. On a gradient the truck creeps downhill slowly after a stop.

**NOTE**

*The truck can briefly be stopped on upward or downward inclines without actuating the parking brake (6) (electric brake). The truck begins to creep downwards slowly.*



**⚠ DANGER****Risk of accident!**

Do not leave the vehicle.

This electric brake only functions while the key switch is switched on and the parking brake is released. Press the brake pedal!

**Change direction of travel**

- Remove foot from accelerator pedal (3).
- Operate the travel direction switch (5) to select the opposite direction (top for reverse, bottom for forwards).



- Operate the accelerator pedal again.

**NOTE**

*The travel direction can also be changed during travel. The foot can remain on the accelerator pedal. The vehicle is then braked and accelerated again in the opposite direction (reversing).*

**Neutral position**

- To switch to neutral position, briefly tap the travel direction switch (5) for the opposite direction (top for reverse, bottom for forward).

**Operating the service brake**** DANGER****Risk of accident!**

Always choose a driving speed that will provide a sufficient stopping distance. Note that the pure braking distance increases as the square of the speed, and that sharp braking can cause the driving wheels to skid and the truck to tip over.

The truck's braking distance is influenced by the quality of the floor surface. A wet surface increases the braking distance. The driver must take account of this in his driving and braking style.

---

## Driving

- The accelerator pedal (2) should be released to slow down the vehicle.
- If the braking effect is insufficient, the foot brake (1) should be applied.

In the first section of the pedal's travel, only the electric brake takes effect; as the pedal is depressed further, the mechanical brake is activated and acts on the driving wheels.

**⚠ DANGER**


**Risk of accident!**

Trucks with zero braking (special equipment) do not have an electrical braking function.

**⚠ DANGER**

**Risk of accident!**

If the service brake fails, the truck must be brought to a stop by applying the parking brake.



## Operating the parking brake

- To park the truck, pull the parking brake lever (4) up and let it engage.

### **⚠ WARNING**

Risk of accident!

If the parking brake is not applied, the forklift truck can roll away.

It can no longer be driven. The travel direction/flasher/message multi-function display (2) goes out.

### **⚠ DANGER**

**The truck should not be parked on a slope.**

In case of emergency, secure the truck with chocks on the downhill side.



- To release the parking brake, push button (3) and lower the lever completely.

### **i NOTE**

*Once released, the travel direction previously selected is retained and is shown on the travel direction/flasher/message multi-function display (2).*

### **i NOTE**

*If you operate the accelerator pedal while the parking brake is applied, the message FESTSTELLBREMSE ( PARKING BRAKE ) appears on the display.*



## Driving

**Steering**


- Steer the vehicle by turning the steering wheel (1) accordingly.

For turning radius information, see ⇒ Chapter "Technical data", P. 225.

**⚠ WARNING**

Risk of accident!

If the hydraulics fail, steering is tight (emergency steering property).



## Lifting

### Lifting system variants

Lifting operations are largely dependent on the following factors:

- The mast with which your truck is equipped. See ⇒ Chapter "Lift mast versions", P. 5-81.
- The lifting system with which your truck is equipped. See ⇒ Chapter "Controls, lifting system", P. 5-84.

Regardless of the individual equipment of your forklift truck, the basic specifications and procedures are to be complied with. See ⇒ Chapter "Safety regulations when handling loads", P. 5-89.

### Lift mast versions

The following lift masts may be installed in your truck:


#### Telescopic mast

When moving the "lift-lower" operating lever backwards, the mast rises via two outer cylinders and brings the fork carriage with it via the chains (the fork carriage rises at twice the speed of the inner mast).

#### **⚠ DANGER**

#### **Risk of accident!**

With low ceilings, be aware that the inner mast lift (1) can be higher than the fork carriage.



## Lifting

**Triplex mast (special equipment)**


When the "lift-lower" operating lever is moved backwards, the inner cylinder moves up to (3) free lift, and then the outer cylinders directly raise the inner mast up to the max. (2) height.

**NOTE**

*When raising above the free lift, the fork carriage always remains at the upper edge of the extending mast tip.*

**⚠ DANGER****Risk of accident!**

With low ceilings, be aware that the carried load can project over the fork carriage. The fork carriage can be higher than the load.

**Malfunction during a lifting operation****⚠ DANGER****Risk of accident!**

In the case of triplex masts (special equipment), an incorrect extension sequence can occur, i. e. the inner mast extends before the fork carriage is at the end of lift 1. As a result, the overall height is exceeded and damage may occur with passageways or low ceilings.

This can occur as a result of:

- low oil temperature

**NOTE**

*The oil temperature can be increased by operating the mast functions several times slowly.*

- Fork carriage blocking in the inner mast.
- Lift cylinder 1 blocking.
- Chain roller lift 1 blocking.

In these cases, you must eliminate the cause of the blockage before you can continue.

- Notify the service centre.

**⚠ DANGER****Risk of accident!**

When lowering, you must ensure that the chain(s) does/do not become slack. There is a danger that the load could suddenly fall.

---

This can occur as a result of:

- resting the fork carriage or the load on the racking.

**i NOTE**

*Lift the fork carriage until the chains are taut again and lower the load at another suitable location.*

- Fork carriage rollers blocking in the lift mast due to dirt.

**i NOTE**

*Lift the fork carriage until the chains are taut again. Remove the dirt before continuing.*

**⚠ WARNING**

Risk of injury!

Observe the safety regulations for working on lift masts, see ⇒ Chapter "Working at the front of the forklift truck", P. 6-170.

---

## Lifting

**Controls, lifting system**

Operation of the lifting system depends on which controls the fork lift truck is equipped with.

Possible equipment variations are as follows:

- Multi-lever controls (1) and (2).
- The following information must be observed regardless of the equipment variation:


**⚠ DANGER****Risk of accident!**

The lifting system must only be operated when the driver seat is occupied.

**⚠ WARNING**

Risk of injury!

The safety regulations "Before taking up a load" must be closely observed ⇒ Chapter "Prior to taking up a load", P. 5-90. Reaching or climbing into moving parts of the fork lift truck (e.g. lift mast, sideshifts, working equipment, load bearing systems etc.) is prohibited.



**Lifting system, multi-lever operation** ▷

**Tilt mast**

To tilt mast forward:

- Push the "tilt" operating lever (2) forwards.

To tilt mast backwards:

- Pull the "tilt" operating lever (2) backwards.


**Lift, lower fork carriage**

To raise fork carriage:

- Pull back the "lift-lower" operating lever (1).


To lower the fork carriage:

- Push the "lift-lower" operating lever (1) forwards.



** NOTE**

*The symbols on the operating levers show the movement direction of the mast when the lever is pulled or pushed.*



## Lifting


## Fork extension

- Attach the fork extension (3) (special equipment) to the fork arms and secure it with socket pin (4).

**⚠ WARNING**

The fork extension affects the stability of the forklift truck.


The weight allowed according to the capacity rating plate must be accordingly reduced in relation to the actual load distance. See ⇒ Chapter "Prior to taking up a load", P. 5-90.



## Operation with reversible forks

## Normal operation

Like a normal fork, the reversible fork arms (special equipment) can be lifted and tilted with the mast.



### Reverse operation

**⚠ CAUTION**

Loads cannot be lifted up on the fork arms due to the missing(1)load support.

When driving, the centre of gravity of the load may not be(2)higher than 600 mm above the ground. The fork extension (special equipment) may not be used.


**⚠ WARNING**

Risk of accident!

Reverse operation is not permitted with the standard fork arms.

**i NOTE**

Conduct annual checks for cracks on the outside of the fork bend; see ⇒ Chapter "Checking reversible fork arms", P. 6-212.



### Emergency lowering

If the load cannot be lowered from a raised position due to a control failure, emergency lowering is possible.



**⚠ DANGER**

**Risk to life!**

Do not walk underneath the raised load!


**i NOTE**

A 4 mm L-wrench is located on the right side of the valve block frame for use when performing the following work (1).

**i NOTE**

This L-wrench must remain on the vehicle.

- Open the bonnet; see ⇒ Chapter "Open the motor hood.", P. 5-53.
- Remove the L-wrench (1).



## Lifting

- Unscrew the emergency lowering screw in the control block a maximum of 1.5 revolutions (2) using the L-wrench. ▷

**⚠ WARNING**

The load is lowered.

The speed can be controlled by the degree to which the screw is unscrewed.


Unscrewed minimally: load is lowered slowly.

Unscrewed maximally: load is lowered quickly.

- Screw the emergency lowering screw back in (2) after the load is lowered.

**Tightening torque: max. 2.5 Nm**

- Return the L-wrench to the (1) mounting support provided.
- Close the bonnet.



## Working with loads

### Safety regulations when handling loads

The safety regulations for handling loads are shown in the following sections.

#### **⚠ DANGER**

##### **Risk to life!**

The operating hydraulics may only be operated from the driver's compartment.

Never walk or stand underneath suspended loads or raised fork arms.

Never exceed the maximum load indicated on the capacity rating plate. Otherwise stability cannot be guaranteed!

#### **⚠ DANGER**

##### **Risk of accident!**

Do not step onto the forks. Do not lift people.

Never grab or climb on moving parts of the forklift truck.

#### **⚠ DANGER**

##### **Risk of accident!**

- When transporting small items, attach a safety guard (special equipment) to prevent the load from falling on the driver.

A closed roof covering (special equipment) should also be used.



7311\_001-001



7311\_001-002

## Working with loads

## Prior to taking up a load

## Load capacity

The load capacity specified for the forklift truck may not be exceeded. It is affected by the load centre of gravity and the lift height and possibly the tyres. Observe the capacity plate to the right of the driver's compartment. Including additional weights to increase the load capacity is forbidden.

**▲ DANGER**

## Risk to life

Never exceed the maximum loads indicated there! These apply for compact and homogenous loads. Otherwise the stability and strength of the fork arms and lift mast are not ensured. Improper or false operation or the boarding of persons to increase the load capacity is forbidden.

- (1) Distance "C" of load centre from fork back (mm)
- (2) Lift height "h" (in mm)
- (3) Maximum loads "Q" (in kg)

## Example:

Weight of the load to be lifted: 2220 kg (3)

Load distance from the fork back: 600 mm (1)

Permissible lift height: 6030 mm (2)

**▲ WARNING**

The diagrams show examples. Only the capacity plates in the vehicle are valid!


**▲ WARNING**

In the case of attachments (special equipment): do not exceed the permissible load of the attachments and the reduced load capacity of the combination of forklift truck and attachment. Observe the special capacity plate information specified on the forklift truck and attachment. Observe the capacity plate for attachments. The data on the plate is explained in the example above.



kg				
1400	1430	1430	1430	7630
1470	1610	1610	1610	7080
1560	1800	1960	1960	6480
1620	1870	2220	2360	6030
1710	1970	2330	2570	5430
1850	2130	2530	2780	4530
1980	2300	2730	3000	3780
1000	800	600	500	

6210\_800-003



6210\_800-004

## Carrying loading units

To ensure secure supporting of the load, it must be ensured that the fork arms are sufficiently far apart and are positioned as far as possible under the load.

If possible, the load should rest on the back of the fork.

The load may not protrude significantly beyond the fork tips and vice versa.

Loads are to be carried and transported as close to the middle as possible.

### **⚠ DANGER**

#### **Risk of accident!**

When transporting small items, attach a safety guard (special equipment) to prevent the load from falling on the driver.

A closed roof covering (special equipment) should also be used.


Removable roof segments may not be removed.

## Setting forks

- Lift stopping lever (1) and move the fork arms to the desired position.
- Allow the stopping lever to snap back into place.

The centre of gravity of the load must be positioned between the fork arms in the middle.

- Only operate the fork arm adjustment (special equipment) when the forks are not loaded.



## Hazard area

The hazard area is the area where persons are endangered by movements of the forklift truck, its working equipment, its load-carrying equipment (e.g. attachments) or the load. Included in this area is also the area which can be affected by a falling load, or by lowering or falling working equipment.

## Working with loads



### ⚠️ WARNING

Risk of injury  
The forks must not be stepped on.



### ⚠️ WARNING

Risk of injury  
Do not step under the raised forks.

### ⚠️ WARNING

People can be injured in the hazard area of the forklift truck.

No persons should be in the hazard area of the forklift truck, except the driver in his normal operating position. Stop work with the forklift truck immediately and secure the forklift truck against unintentional use by unauthorised persons if persons do not leave the hazard area despite being warned.



### ⚠️ DANGER

#### Risk to life from falling loads!


Never walk or stand underneath overhead loads.

## Transporting pallets

Loading units (e.g. pallets) are generally to be transported individually. Simultaneous transport of several loading units is only allowed

- when instructed by the supervisor and
- when the technical requirements have been met.

The driver must ensure proper condition of the loading unit. Only safely and carefully positioned loading units may be transported.



6327\_003-009

## Transport of swinging loads

Contact your national regulatory authorities (trade associations in Germany) prior to transporting swinging loads.

National regulations may place restrictions on these operations. Please contact the authority responsible.

### **⚠ DANGER**

**Swinging loads can result in the following risks:**


- Reduced braking and steering action,
- Tipping over the wheels or drive wheels,
- Tipping of the truck transverse to the direction of travel,
- Risk of crushing of guide persons,
- Reduced visibility.

### **⚠ DANGER**

**Loss of stability due to slipped, unstable or, in particular, hanging loads!**

The following information should be noted when transporting hanging loads:

- Swinging of the load is to be prevented by using the proper driving speed and driving manner (careful steering, braking).
- Hanging loads can only be coupled to the industrial truck so that the load-securing device cannot shift or release unintentionally and cannot be damaged.
- Ensure that there are no persons in the direction of travel in the driving lane.
- Ensure that swinging loads do not put persons at risk.
- When transporting hanging loads, suitable devices (e.g. guy wires or hand rails) are to be made available and used by guide persons.



## Working with loads

### **⚠ DANGER**

#### **Risk of accident!**

When transporting hanging loads, never abruptly perform or end driving and load movements during transport.

Never drive on slopes with a hanging load!

Containers with fluids cannot be transported as hanging loads.

---


## Taking up load

Only pallets that do not exceed the specified maximum size may be used. Damaged loading equipment and improperly designed loading units may not be used.

The load should be placed on the load-carrying equipment or secured thereon so that it cannot shift or fall.

The loading units should be stored so that the defined aisle width is not reduced by protruding parts.

- Approach the racking carefully, brake gently, and stop just in front of the racking. ▷



- Position the forks.
- Position the mast so that it is vertical.
- Lift the fork carriage to the stack height.


**⚠ DANGER**

**Risk of accident!**

When the mast is tilted forward, make sure that the forklift truck does not tilt forward and that the load does not slip.


If a forklift truck with increased forward tilt (special equipment) (greater than 3°) is in use, a greater risk of slipping can be assumed during raising or lowering of the load.

- Move forward slowly.
- Do not damage the racking and load when inserting the forks!
- Insert the forks under the load as far as possible. Bring the vehicle to a standstill once the back of the fork is resting against the load. The centre of gravity of the load must be positioned between the fork arms in the middle.
- Lift the fork carriage until the load is resting entirely on the forks.




## Working with loads

- Drive backwards.
- Watch behind you for a clear pathway. Move backwards carefully and slowly until the load is clear of the racking. Brake gently.




- Tilt the mast backwards.



- Lower the load while maintaining floor clearance. ▷

Now you can drive away.



7090\_800-009

## Transporting loads

### ⚠ WARNING

Risk of accident! As the height at which a load is transported increases, the stability decreases.

- Always drive with the load lowered.
- Lower the load until ground clearance is reached (not over 300 mm).

The load should not be high enough to block the front view, otherwise drive backwards. If this is not possible, a second person acting as a guide must walk beside the vehicle. Only drive at walking pace and always take extra care. The forklift truck must be stopped immediately if contact with the guide is lost.

When using attachments, special conditions apply, see ⇒ Chapter "Assembling attachments", P. 5-103.



7090\_800-010

### ⚠ DANGER

**The truck can tip over or the load can fall.**

Driving with the mast tilted forward is not permitted.

## Working with loads

- Only drive with the mast tilted back.




- Drive slowly and carefully around sharp corners!
- Always accelerate and brake gradually!

**⚠ DANGER****Risk of accident!**

Do not start quickly, do not apply brake fully!

- Never drive with a laterally protruding load (e.g. with a sideshift or sideshift device)!



## Working with loads

### Depositing and retrieving loading units

Always follow the following procedure:

- Move directly to the stack with the load lowered according to regulations.
- Set lift mast to be vertical.

#### **⚠ WARNING**

Risk of accident!

If your forklift truck is equipped with greater forward tilt (special equipment) (over 3°), the load can slip or the forklift truck can tip over.

- Lift the load to the stack height.

#### **⚠ WARNING**

Risk of accident!


Only tilt the mast with raised load-carrying equipment forward directly over the stack.

- Insert the forklift truck carefully into the stack.
- Lower the load until it rests securely on the racking.
- Look back!
- Move the forklift truck back until the fork arms can be lowered without touching the stack.
- Lower the forks until ground clearance is achieved; tilt the mast backwards, and drive away.

#### **⚠ WARNING**

Risk of accident!

When putting into storage, set it far enough back so that the load or the forks can be freely lowered.



## Driving on ascending and descending slopes

### **⚠ DANGER**

#### **Risk to life!**

On ascending and descending slopes the load must be carried facing uphill.

Only those ascending and descending slopes which are marked as traffic routes may be used and can safely be used in accordance with the technical data for this forklift truck, see → Chapter "Technical data", P. 225.

The driver must check that the ground is clean with a good grip.

It is not permitted to perform turns on ascending slopes, to approach them diagonally or to park the truck on them.

Drive at a reduced speed on descending slopes.

Putting items into storage and removing them from storage while on an ascending or descending slope is not permitted.

The truck should not be parked on a slope.

- In case of emergency, secure the truck with chocks.



## Driving on lifts

For this truck, the driver may only use lifts with a sufficient lifting capacity and for which the operator (see → Chapter "Definition of terms used for responsible persons", P. 20) has authorization for use.

- Drive the forklift truck with the load forwards into the lift without touching the shaft walls.
- Secure the truck in the lift so that no part comes into contact with the shaft wall.


The distance from the shaft wall must be at least 100 mm.

### **⚠ DANGER**

#### **Risk of accident!**

Personnel accompanying the truck onto the lift are only allowed to occupy the lift once the forklift truck is secure and must exit the lift first after the trip.

The maximum weight of the forklift truck (tare weight with maximum load):



## Working with loads

R70-40	approx. 10,500 kg
R70-45	approx. 11,300 kg
R70-50	approx. 12,100 kg

## Driving on loading bridges


**⚠ DANGER****Risk of accident!**

Prior to driving on a loading bridge, the driver must ensure that it is properly attached and secured and has sufficient load-bearing capacity (truck, bridge).

The driver must drive slowly and carefully on a loading bridge.

The driver must ensure that the vehicle to be accessed is sufficiently secured against shifting and is suitable for the load of the forklift truck.

The lorry driver and the forklift truck driver must agree on the departure time.



## Working with attachments

### Assembling attachments

If attachments are assembled at the place of use, the specifications in the operating instructions for the attachment must be followed.

Prior to being put into service for the first time, the function of the attachment and the visibility with and without a load from the driver's position must be checked by a specialist. If the visibility is deemed insufficient, visual aids such as mirrors, a camera/monitor system etc. must be used.

If an attachment is not delivered together with the forklift truck, the specifications and operating instructions of the attachment manufacturer must be followed.

Attachments must be CE-certified.

#### CAUTION

If there is no attachment-specific residual lifting capacity plate mounted on the forklift truck, the CE conformity is void.

- Order the residual lifting capacity plate (see → Chapter "Taking up a load using attachments", P. 5-107) promptly from your service centre.

#### WARNING

There is a risk of accident from a falling load!

In the case of installation of a clamp with an integrated sideshift, it must be ensured that the clamp will not open during actuation of the sideshift.

- Contact STILL service personnel prior to installation.

### Hydraulic connection

#### NOTE

*Prior to assembling attachments, the plug-in couplings must be depressurised.*

### Fastening attachments

The fastening of an attachment and the connecting of the energy supply for power-driven

## Working with attachments

attachments must be performed only by competent persons according to the specifications of the manufacturer and the supplier of the attachment. After each assembly, the attachment must be checked for proper functioning prior to being put into operation for the first time.

### Lifting capacity with attachment


The allowable lifting capacity of the attachment and the allowable load (lifting capacity and load moment) of the forklift truck may not be exceeded in the combination of attachment and payload. The specifications of the manufacturer and supplier of the attachment must be complied with.

When determining the lifting capacity, the tare weight of the attachment and the resulting load moment must be taken into consideration.

### Depressurising connections for attachments


 **NOTE**

*Prior to assembling attachments, the plug-in couplings (arrows) must be depressurised.*



### Depressurising, multi-lever controls

- Lower fork carriage to the ground, tilt mast as far back as possible.
- Switch off the key switch.
- Operate all hydraulic operating levers (arrows) several times up to their end positions.



### General information on control of attachments

The control of attachments (option) depends on the type of attachment.

#### **⚠ WARNING**

The use of attachments can result in additional hazards such as, for example, a change in the centre of gravity, additional danger zones, etc.

Attachments may only be used for their intended purpose as described in the relevant operating instructions. The driver must be instructed in the handling of the attachments.

Loads may only be picked up and transported with attachments if they can be seized and held properly. If necessary, the loads must also be secured against sliding, rolling, falling over, swinging or falling off. Note that the stability of the truck changes if the load centre distance is changed. Please refer to the attachment load capacity plate.

#### **i NOTE**

*Further options and functions are possible in addition to those listed below. The directions of movement are shown on the pictograms on the control levers or on the valve cover.*

## Working with attachments

## Controlling attachments using multi-lever controls

The attachments (special equipment) are controlled in this version using the operating levers (1).

The pictograms on the operating levers always show the function that is activated by that lever.

The meanings are as follows:


- Move operating lever (1) forwards:

The attachment moves in the direction shown in the upper part of the pictogram.


- Move operating lever (1) backwards:

The attachment moves in the direction shown in the lower part of the pictogram.

- Please note symbols 2 to 10!



2	Reach frame or forks forwards/backwards
3	Sideshift moves to the left/to the right.
4	Adjust fork arms: open/close
5	Tilt lift mast or forks to the left/to the right.
6	Release/clamp load retainer
7	Raise/lower load
8	Open/close clamps
9	Turn to the left/to the right
10	Tip shovel over/tip shovel back



## Taking up a load using attachments ▷

### ⚠ WARNING

Risk of accident!

Attachments may only be used for their intended purpose as described in the respective operating instructions.

Drivers must be instructed in the handling of the attachments.

### ⚠ WARNING


Risk of accident!

Loads may only be picked up and transported with attachments if they are secure. If necessary, the load must also be secured against slipping, rolling, falling, wobbling or tilting. Note that any change to the position of the centre of gravity of the load will affect the stability of the forklift truck.

Check the capacity plate for the attachments.

– There you will find the permissible values for:

- Lifting capacity  $Q$  (kg) (1)
- Lift height  $h$  (mm) (2)
- Load distance  $C$  (mm) (3)



## Operation of additional equipment




## Operation of additional equipment

## Switching lighting on and off (special equipment) ▷

- Press the switch (1) for the work lights.
- The work lights are (3) switched on.
- Press the light switch (2).
- The parking lights (4) are switched on.
- Press the light switch again (2).
- The driving lights (5) are switched on.

**NOTE**

*Pressing the switch again switches each light back off.*




### Switching flashing light off and on

– Press the switch (1) for the flashing light.

The flashing light (2) is switched on.

**i** NOTE

*Pressing the switch again switches the flashing light back off.*



## Operation of additional equipment

**Switching hazard warning system off and on (special equipment) ▷**

- Press (1) warning light switch.


All flashing lights (3) and the two direction indicator lights (2) in the direction of travel/flasher/fault multi-function display flash.

**i NOTE**

*Pressing the switch again switches the hazard warning system back off.*

**i NOTE**

*The hazard warning system can also be switched on without the key switch connected.*



**Switching direction indicators off and on** ▷

- Activate the right or left direction indicators as required using the direction indicator switch (1).


Direction indicator control lamps (2) or (3) light up.

- To indicate left: move direction indicator switch (1) to the left.

The direction indicators at the left front and rear and the direction indicator control lamp (2) at the left light up.

- To indicate right: move direction indicator switch (1) to the right.

The direction indicators at the right front and rear and the direction indicator control lamp (3) at the right light up.



**NOTE**


To reset, move the switch half the actuation distance in the opposite direction.

**Windscreen wiper/-washer** ▷

- Press the switch to activate the windscreen wiper/ washer (special equipment) (1).
- Press the switch to activate the rear windscreen wiper/ washer (special equipment) (2).

The following table shows the different displays (3) for the operating stages of the windscreen wiper / washer.

Every time the relevant button is pressed, you will move forward one stage.



Display	Operating stage
	Wiper/Washer is "Off"
	Wiper is "On"

## Operation of additional equipment

Display	Operating stage
	Wiper in "Interval mode"
	Washer is "On" NOTE: To activate the washer function, the button must be held down.

## Cab

### Opening the cab doors

#### DANGER

#### Risk of accident!

Always keep doors closed when moving.

#### DANGER


**Only a full cab with closed, fixed doors or bracket doors is an operator restraint system. PVC doors are not a restraint system.**

If the doors are open or removed, you must use a different, suitable restraint system (e.g. restraining belt).

- Insert key in door lock (1) and turn.
- Remove key and pull on door handle (2) 5 until the lock opens.

### Opening the side windows (special equipment)

- Pull on the handle (3) and pull front side window to the rear.
- Pull on the handle (4) and pull the rear side window towards the front.



## Heater

### Switch on blower and heater (special equipment)



#### **⚠ DANGER**

##### **Risk of explosion!**

The heater should not be operated near storage rooms or similar facilities where fuel vapours or coal, wood or grain dust could be accumulate.

Spray cans or gas cartridges should not be exposed to the flow of hot air.


- To switch on heater, turn on blower (1) switch.

The blower runs at the speed level set at the switch.

- Set the desired temperature with the (2) lever.

The heater is in operation. The air is heated up to the heating level set at the (2) switch.

- Adjust the air flow (3) at the vent.



## Driving with cruise control

The cruise control function (special equipment) permits the driver, when travelling forwards, to press a button and save any speed of 6.0 km/h or more selected with the accelerator, then to continue driving without using the accelerator pedal.



#### **NOTE**

*It is not possible to use cruise control when driving in reverse.*

## Operation of additional equipment

### Switching on cruise control

#### **⚠ WARNING**

Risk of accident!

When using cruise control, the special behaviour of this function and the dangers associated with it must be observed by the driver, in addition to the safety guidelines.

- Press the lower section (1) of the travel direction switch.

The forward travel direction display (2) lights continuously.

- Accelerate vehicle to the desired speed using the accelerator pedal (at least 6.0 km/h).

#### **⚠ WARNING**

Risk of accident!

The speed must be selected so that it is suitable for the entire distance that you intend to drive with active cruise control. This is especially true when selecting speeds around corners.

- Press the lower section of the travel direction switch again for at least one (1) second.


The selected speed is saved. The forward travel direction(2)display changes from a steady light to a flashing light.

#### **i NOTE**


*The cruise control function cannot be activated when reversing or at a speed below 6.0 km/h.*

- Remove foot from accelerator pedal.

The vehicle will now drive at the pre-selected speed until the cruise control function is switched off.



7311\_003-062



7071\_003-014

### Switching off cruise control

There are different ways of switching off the cruise control function.

If the cruise control function is switched off, the forward travel direction display will light up again(2)continuously.

The cruise control function can be switched off by operating



- the footbrake,
- the parking brake,
- the travel direction switch in neutral or(1)reverse,
- the accelerator pedal
- or by activating the seat switch (seat not occupied).

There are two different ways of switching it off using the accelerator pedal, depending on the individual vehicle programming:

- Type 1: Even slightly depressing the accelerator pedal switches off the cruise control function.
- Type 2: To switch off the cruise control function, the accelerator pedal must be depressed at least as far as it was when saving the speed.

#### NOTE

*The information label indicates which type of cruise control (type 1 or type 2) is programmed in your vehicle.*



## Trailer operation

## Trailer operation

## Towed load

**i** NOTE

*This forklift truck is suitable for the occasional towing of trailers and is equipped with a towing device for this purpose. This occasional towing may not exceed 2% of the daily operating time. If you want to use the forklift truck for more frequent towing, the manufacturer must be consulted.*

**⚠ CAUTION**

A support load is not permitted.

The maximum permissible towed load for occasional towing is the fork arm lifting capacity specified on the capacity rating plate (to the right of the driver seat). The maximum load may not be exceeded.

The permissible towed load only applies to the towbar.

If this maximum load is being towed, no load may be transported on the fork arms.

However, it is possible to transport part of the maximum load on the fork arms and at the same time tow the balance of the maximum load.

**⚠ CAUTION**

The maximum permissible load only applies for towing unbraked trailers on level surfaces (maximum gradient +/- 1%) and on firm ground.


The maximum load must be reduced if towing on slopes. Please inform the manufacturer of your conditions of use. You will then be given the appropriate data.

**⚠ CAUTION**

The maximum permissible speed when towing is 5 km/h.

Do not exceed the permissible speed.

- Do not couple the forklift truck in front of rail vehicles.
- Do not push carriages of any type.



**⚠ WARNING**

Towing changes the vehicle handling characteristics!

When towing, operate the truck in such a way as to ensure safe transportation and braking of the towed load in all movements.

## Coupling the trailer

**⚠ WARNING**


Risk of accident!

If you briefly leave the forklift truck to couple a trailer:

- Apply the parking brake.
- Switch off the key switch and remove the key.


### Manual tow coupling

- Secure the parked trailer against unintended movement (1). Do not release the parking brake until the trailer has been coupled on.




## Trailer operation

- Insert wheel chock (special equipment)(2)⇒ Chapter "Use wheel chocks", P. 5-151).



- Press down the tow bolt (4), rotate by 90° and remove.
- Insert the drawbar into the recess in the counterweight.



**⚠ DANGER**

**Only use the original tow bolt.**

Make sure that the tow bolt is engaged correctly.


- Insert the tow bolt; press it down against spring force and turn it 90° (tow bolt is then secured in this position).

## Towing trailers

- Before commencing towing, perform a sufficient number of test drives.
- When driving up or down inclines, take account of the dimensions of the trailer and load.
- When towing multiple trailers, ensure a sufficient minimum distance to fixed installations when turning and cornering.

The permissible length of the trailers depends on the routes to be driven and may need to be determined during the test drives.

The permissible number of trailers and - if necessary - any supplementary speed reductions for particular sections must be provided to the drivers as driving instructions.



## Operation of indicator and operating unit


### Operation of indicator and operating unit

#### Displays

##### Normal displays

The following displays are normally visible (factory setting):


- (1) Fuel level.
- (2) Set traction programme PROG with the numbers 1 through 5. The traction programme can be changed, see ⇒ Chapter "Setting the traction programs", P. 5-68.
- (3) Hour meter. The hour meter shows the operating time of the vehicle. It starts as soon as the ignition key is turned to the operating position.
- (4) Time in hours and minutes. The time can be set.



##### Additional displays

Upon pressing the menu change button (4) the following additional displays appear:

- (1) WARTUNG IN (SERVICE IN) display  
Displays the remaining time (in hours) until the next service visit according to the maintenance schedule in the maintenance manual.
  - Contact your customer service office or workshop.
- (3) Displays the total distance driven (in km).
- (5) Displays the distance driven for the day.
- (6) Displays the hours driven for the day (in hours).



#### Display settings and changes


To set and change the displays, first switch to the KONFIGURATION (CONFIGURATION) menu :

- Switch on key switch.

- Press the traction programme key (2) and menu change key (4) at the same time to switch to the PASSWORD menu.
- Press the return key (7) to switch to the KONFIGURATION (CONFIGURATION) menu .

The following settings are possible:

- Set date and time, see ⇒ Chapter "Setting the date or time", P. 5-121
- Reset daily number of kilometres and daily driving time, see ⇒ Chapter "Resetting the daily number of kilometres and daily driving time", P. 5-122
- Select language, see ⇒ Chapter "Setting the language", P. 5-122
- FleetManager functions, see ⇒ Chapter "Fleet Manager functions", P. 5-123
- Other settings, see⇒ Chapter "Additional settings", P. 5-124



### Setting the date or time


- Switch to the Configuration menu; see ⇒ Chapter "Display settings and changes", P. 5-120.
- Press the traction programme button (2) or the menu selection button (4) until the UHRZEIT (TIME) option appears. Confirm your selection with the Return key (7).

The UHRZEIT (TIME) menu appears.

- Hold down the traction program key (2) or the menu selection key (4) until the desired time appears on the display.

As the keys are held down for longer, the scrolling speed increases in three levels.

- Confirm the correct time with the Return key (7).
- Exit the menu and move up a level with the arrow key (8). The date setting appears and can be changed in a similar way.




## Operation of indicator and operating unit

### Resetting the daily number of kilometres and daily driving time

The daily number of kilometres and daily driving time displays can be reset to zero.

- Switch to the Configuration menu; see ⇒ Chapter "Display settings and changes", P. 5-120.
- The values are reset by pressing RESET (RESET).




### Setting the language

The display can be shown in additional languages.

- Switch to the Configuration menu; see ⇒ Chapter "Display settings and changes", P. 5-120.


Operation of indicator and operating unit

- Press the traction program button (1) or the menu change button (2) until the desired language appears in the display.
- Confirm the selected language with the Return key (3).



Fleet Manager functions


Fleet Manager functions (special equipment) can be executed using the smart card (1). Ask your service centre.



## Operation of indicator and operating unit

### Accident recorder (special equipment) ▶

The accident recorder is an auxiliary device to the Fleet Manager. An acceleration sensor (2) is installed in the truck. The acceleration sensor can record data from an accident. This data can be evaluated. Ask your service centre.




### Additional settings

Entering a password makes it possible to set additional values. Contact your customer service office about this.

## Error messages

### Diagram


If a malfunction or a message is displayed on the display and control(1) unit, the display lights up on the combination display for direction of travel/flasher/message.



The following malfunction indications and messages can appear on the display: (2) A graphic symbol and a message describing (3) the faulty function and an error code consisting of (4) a letter and a 4-digit number.

Fault displays are always displayed on a cyclic basis for a number of seconds, depending on the fault.

If more than one fault occurs, they are shown one after the other. This is followed by a pause, with its length also depending on the type of fault. During this pause the status display of the truck is shown.



## Error messages

## Error code table

The table gives you an overview of possible displays. In the "Comment" column you will find information on how to proceed should any of these messages appear.

Message text (English) / Error code	Display animation	Comment
UEBERTEMPERATUR (OVERHEATING) A5022	Cyclic display every 30 sec	Traction motor(s) is/are too hot. 1. Phase: Regulation of acceleration and speed. 2. Phase: Limitation of phase current in converter (emergency driving function is retained). The error code automatically disappears as soon as the temperature is lower than the limit. If the error code appears often, please contact your service centre.
PARAMETER (PARAMETERING) A1206 A1211	Cyclic display every 30 sec	Traction and hydraulic drive not functioning. Contact your service centre.
FAHRGEBER (ACCEL. SENSOR) A3002 A3003 A3004 A3005 A3006 A3007	Cyclic display every 30 sec	Sensor error, vehicle cannot be driven. Contact your service centre.
FAHRGEBER (ACCEL. SENSOR) A3811	Cyclic display every 30 sec	Accelerator configuration is invalid. Vehicle cannot be driven Contact your service centre.
BREMSGEBER (BRAKE SENSOR) A3016 A3017	Cyclic display every 30 sec	Sensor error, vehicle can only be driven at the emergency mode speed. Contact your service centre.
KONFIGURATION (CONFIGURATION) A2111	Cyclic display every 30 sec	Parameterisation error or defective printed circuit board, traction and hydraulic drive not functioning. Contact your service centre.
KONFIGURATION (CONFIGURATION) A3801	Cyclic display every 30 sec	Parameterisation error, traction and hydraulic drive not functioning. Contact your service centre.

Message text (English) / Error code	Display animation	Comment
KONFIGURATION (CONFIGURATION) A3812	Cyclic display every 30 sec	Traction program parameters are outside the permitted range. The traction program parameters are limited internally. Contact your service centre.
KONFIGURATION (CONFIGURATION) A3822	Cyclic display every 30 sec	Wrong converter, traction and hydraulic drive not functioning. Contact your service centre.
KONFIGURATION (CONFIGURATION) A9999	Cyclic display every 30 sec	Software error, traction and hydraulic drive not functioning. Contact your service centre.
SPANNUNG (VOLT- AGE) A2237	Cyclic display every 30 sec	Short circuit 10 V ext., traction and hydraulic drive not functioning. Contact your service centre.
SITZSCHALTER (SEAT SWITCH) A3027	Cyclic display every 30 sec	Seat switch has not been operated for 8 hours. Truck is possibly still driving at a reduced speed and with reduced lifting capacity. Briefly stand up and sit down again. If this does not resolve the problem, contact the service centre.
LENKEN (STEERING) A3202 A3215 A3221 A3226	Cyclic display every 30 sec	Sensor error, vehicle can be driven at emergency mode speed. Contact your service centre.
FAHRTRICHTUNG (DIRECTION SWITCH) A3020	Cyclic display every 30 sec	Switch error, no or limited traction drive function. Contact your service centre.
HEBEN (LIFTING) A3102 A3103	Cyclic display every 30 sec	Sensor error, no or restricted hydraulic drive function. Contact your service centre.
NEIGEN (TILTING) A3107 A3108	Cyclic display every 30 sec	Sensor error, no or restricted hydraulic drive function. Contact your service centre.
ZUSATZ1 (EXT1) A3112 A3113	Cyclic display every 30 sec	Sensor error, no or restricted hydraulic drive function. Contact your service centre.
ZUSATZ2 (EXT2) A3117 A3118	Cyclic display every 30 sec	Sensor error, no or restricted hydraulic drive function. Contact your service centre.

## Error messages

Message text (English) / Error code	Display animation	Comment
VERSORGUNG (POWER SUPPLY) A2242 A2257	Cyclic display every 30 sec	Transmitted power supply short-circuited. Vehicle cannot be driven Contact your service centre.
MONITORING A2801 A2802 A2807 A2808 A2809 A2810 A2811 A2812 A2813 A2814 A2815 A2816	Cyclic display every 30 sec	Traction drive is not functioning. Release pedal. If this error code appears sporadically, it can be tolerated. If usability is impaired, please contact your service centre.
MONITORING A2803 A2806	Cyclic display every 30 sec	Direction of travel is set to neutral. Reselect direction of travel. If this error code appears sporadically, it can be tolerated. If usability is impaired, please contact your service centre.
UEBERWACHUNG (SURVEILLANCE) A2817 A2818	Cyclic display every 30 sec	Vehicle is not ready for operation. Turn key switch to the zero position and start again. If this error code appears sporadically, it can be tolerated. If usability is impaired, please contact your service centre.
ANTRIEB (DRIVE) A5041	Cyclic display every 30 sec	Temperature sensor error Contact your service centre.
OELDRUCK (OIL PRESSURE) A5631	Cyclic display every 10 sec	Engine defect (no oil pressure) or sensor defect. Engine is switched off for protection. Contact your service centre.
COOLANT TEMP A5611	Cyclic display every 10 sec	Coolant temperature too high. Cooling fan is not running. Low coolant level, check coolant level and top up if necessary, see ⇒ Chapter "Topping up coolant and checking coolant concentration", P. 6-178. If this does not resolve the problem, contact the service centre.
LUFTFILTER (AIR FILTER) A5651	Cyclic display every 30 sec	Replace/clean air filter, see ⇒ Chapter "Replacing the air filter insert", P. 6-181.

Message text (English) / Error code	Display animation	Comment
LICHTMASCHINE (GENERATOR) A5811	Cyclic display every 30 sec	Starter battery is not charged. Contact your service centre.
MOT/GEN-TEMP (MOT/GEN.-TEMP.) A5034	Cyclic display every 30 sec	Overtemperature in traction motor or generator. Allow to cool down. If this does not resolve the problem, contact the service centre.
ABGASREINIGER (EXH. GAS PURIFIER) A5795	Cyclic display every 30 sec	Regeneration interrupted. Contact your service centre.
ABGASREINIGER (EXH. GAS PURIFIER) A5797 A5798	Cyclic display every 30 sec	End of regeneration. Contact your service centre.
ABGASREINIGER (EXH. GAS PURIFIER) A5793 A5794 A5796	Cyclic display every 30 sec	Regeneration has not started. Contact your service centre.
ABGASREINIGER (EXH. GAS PURIFIER) A5891	Cyclic display every 30 sec	No regeneration and no intermediate glow. Contact your service centre.
ABGASREINIGER (EXH. GAS PURIFIER) A5892	Cyclic display every 30 sec	Participant is not logged on. Contact your service centre.
STEUERGERAET (CONTROL UNIT) A3305	Cyclic display every 30 sec	The CIO does not work. Contact your service centre.
KUEHLMITTELSTAND (COOLANT LEVEL) A5611	Cyclic display every 30 sec	Low coolant level, check coolant level and top up if necessary, see ⇒ Chapter "Topping up coolant and checking coolant concentration", P. 6-178. If this does not resolve the problem, contact the service centre.

## Error messages

**SAFETY BELT message****⚠ DANGER**

**Driving without a seat belt is dangerous and never permitted!**

- Always fasten the seat belt before driving.

**i NOTE**

*This mechanism (special equipment) ensures that if the seat belt is not being used or is being used incorrectly, the forklift truck will only drive slowly or (optionally) will not drive at all. Depending on the selected version, the operating hydraulic functions (lift/tilt) are either available as normal, slowed down or not available at all. This function is triggered in the following circumstances:*


**Seat belt not worn, driver's seat occupied.**

- Switch on key switch.

The message **SAFETY BELT** appears in the display as long as you operate an operating lever, the steering wheel, or the accelerator pedal. The forklift truck drives slowly or does not drive at all; depending on the selected version, the working functions are either available as normal, slowed down or not available at all.

- Fit the seat belt in line with the instructions and fasten it.

The forklift truck can again be operated without restriction.




**The seat belt is constantly fastened and the driver's seat is then occupied.**

- Switch on key switch.

The message **SAFETY BELT** appears in the display if you operate an operating lever or the accelerator pedal. The forklift truck drives slowly or does not drive at all; depending on the selected version, the working functions are either available as normal, slowed down or not available at all.

- Remove the seat belt from the buckle, fit the belt in line with the instructions and fasten it again.

The forklift truck can again be operated without restriction.



**The seat belt is not fastened until after the key switch has been switched on.**

- Switch on key switch.

The message **SAFETY BELT** appears in the display if you operate an operating lever or the accelerator pedal. The forklift truck drives slowly or does not drive at all; depending on the selected version, the working functions are either available as normal, slowed down or not available at all.

- Remove the seat belt from the buckle, fit the belt in line with the instructions and fasten it again.

The forklift truck can again be operated without restriction.

## Error messages

**The seat belt is unfastened while driving** ▷


- If you release the belt while driving, the message SAFETY BELT appears in the display.

The truck maintains or brakes to a slow speed.

**⚠ DANGER**


**This function does not release you from your duty of care, to adjust the speed of the forklift truck to the driving situation.**

The increased safety provided by this function may not be misused in order to take safety risks.



- Fit the seat belt in line with the instructions and fasten it. ▷

The forklift truck can again be operated without restriction.

**Message SITZSCHALTER (SEAT SWITCH)****i NOTE**

*The truck is equipped with a seat switch. If the message SITZSCHALTER (SEAT SWITCH) appears on the display, the truck will only move slowly or (optionally) not at all. Depending on the selected version, the operating hydraulic functions (lift/tilt) are either*

*available as normal, slowed down or not available at all. This function is triggered in the following circumstances:*

**The seat switch is not actuated, while the accelerator pedal or the steering wheel is actuated.** ▷

The key switch is switched on.

The seat is not occupied while the accelerator pedal or the steering wheel is operated. The message **SITZSCHALTER** (SEAT SWITCH) appears in the display. The forklift truck cannot move.

- Sit on the driver seat and fasten the belt.

The forklift truck can be driven again without restriction.



7311\_003-044

**The seat switch is not actuated, while the operating lever is actuated** ▷

The key switch is switched on.

You are not sitting on the seat, while actuating an operating lever. The message **SITZSCHALTER** (SEAT SWITCH) appears in the display. The work functions can be executed normally, only slowly, or not at all depending on the version.

- Sit on the driver seat and fasten the belt.

The work functions can be operated without restriction again.



7311\_003-045

## Error messages


**Exceeding the shift time****NOTE**

*The shift time is adjustable.*

When the key switch is switched on after sitting steadily for the set time, the message **SITZSCHALTER** (SEAT SWITCH) appears on the display. This also occurs when an operating lever or the accelerator pedal is operated. The forklift truck will only move slowly; the work functions can be executed normally, only slowly, or not at all depending on the selected version.

- Stand up briefly from the seat and then sit back down.

The forklift truck can again be operated without restriction.

**Exceeding the operation time****NOTE**

*The operation time is adjustable.*

If, while the key switch is switched on and the parking brake is released, the driver's seat is occupied longer than the set operation time and the accelerator pedal or an operating lever was not operated during this time, the message **SITZSCHALTER** (SEAT SWITCH) appears in the display. The forklift truck can move only slowly; the work functions can be executed normally, only slowly, or not at all depending on the version.


- Stand up briefly from the seat and then sit back down.

The forklift truck can again be operated without restriction.



## AIR FILTER message

If the AIR FILTER message appears on the indicator and operating unit, the air filter insert must be replaced, see ⇒ Chapter "Replacing the air filter insert", P. 6-181.



## BREMSE ANZIEHEN (APPLY HANDBRAKE!) message

### DANGER

#### Risk of accident!


Parking the forklift truck without the brake being securely applied is dangerous and is not permitted. The increased safety provided by this function may not be misused in order to take safety risks.

### Parking brake is not applied

If you park the vehicle without applying the parking brake and leave the driver's seat, the message BREMSE ANZIEHEN (APPLY HANDBRAKE!) appears, and an optional signal tone sounds.

- Apply the parking brake (1).

The display BREMSE ANZIEHEN (APPLY HANDBRAKE!) disappears.




## Error messages

### The truck moves slowly despite the parking brake being applied ▷

If you park the forklift truck without applying the parking brake sufficiently securely, the forklift truck will slowly roll away. The display **BREMSE ANZIEHEN** (APPLY HANDBRAKE!) appears and an optional signal tone sounds.

- Apply the parking brake (1) securely so that the forklift truck no longer rolls away.

The display **BREMSE ANZIEHEN** (APPLY HANDBRAKE!) disappears.



## LOWER FORKS message

### ⚠ DANGER

#### Risk of accident!


Parking the forklift truck with the load lifted is dangerous and is not permitted under any circumstances. The increased safety provided by this function may not be misused in order to take safety risks.

### Forks are not lowered ▷

The forks are above the height sensor. You switch off the key switch and vacate the seat. In the display, the message **LOWER FORKS** appears (special equipment), and an optional signal tone sounds.

- Lower the forks to the bottom using the lift-lower operating lever.

The message **LOWER FORKS** disappears.



### REFERENCE LIFT message


**i NOTE**

*If you have shut down the control unit and lower the load with the lift-lower operating lever, the following happens when you restart:*

You switch on the key switch. In the display, the message REFERENCE CYCLE (special equipment) or no display appears. The forklift truck will now only drive at a reduced speed. You now have to perform a test lift (reference cycle) using the lifting system:

- Lift the forks up until the message disappears or, if it was not previously displayed, until it appears and then disappears again.
- Then lower the forks again.


The truck can now be driven again with no speed limitation.



### ACCELERATOR message

If the ACCELERATOR message appears on the indicator and operating unit, the vehicle will remain stationary. The accelerator must be checked.

- Contact the customer service office.




## Error messages

**BRAKE SENSOR message**

If the BRAKE SENSOR message appears, the maximum driving speed is reduced. The brake sensor in the brake pedal must be checked.


- Contact the customer service office.

**SURVEILLANCE message**

If the SURVEILLANCE message appears, a fault has occurred in the process monitoring.

This shuts off the traction drive.

- Place the key switch in the "0" position and then back in the "1" position. Start the engine; see ⇒ Chapter "Start the engine", P. 5-62.
- Release the accelerator pedal.
- Select the direction of travel again.


**NOTE**

*If this fault occurs sporadically, it can be tolerated. If the truck's functionality is impaired, contact your service centre.*


### MOT/GEN-TEMP message

If the MOT/GEN-TEMP message appears, the traction motor or the generator is overheated, or a cable is broken.

- Interrupt work, allow to cool off. Do not switch off key switch.

#### NOTE


*If the truck's functionality is impaired, contact your service centre.*



### STEERING message

If the STEERING message appears on the display and operating unit, the vehicle only moves at crawling speed. The accelerator must be checked.

- Contact the customer service office.



## Error messages

**OIL PRESSURE message****⚠ CAUTION**


Risk of engine damage!

If the OIL PRESSURE message appears, shut off the engine immediately.

If the OIL PRESSURE message appears, the oil pressure in the engine is too low.

The message can have different causes:

- The engine has overheated
  - Insufficient oil
  - The oil is insufficiently viscous
  - Engine damage
- Checking engine oil level, see ⇒ Chapter "Checking the engine oil level", P. 5-54.
- If necessary, renew engine oil.
- Contact the customer service office.

**COOLANT LEVEL message**

If the COOLANT LEVEL message appears, the coolant level is too low.


- Checking coolant level, see ⇒ Chapter "Topping up coolant and checking coolant concentration", P. 6-178.

**⚠ CAUTION**

Risk of engine damage!

If the coolant level is low, this indicates a leak in the cooling system.

- Check for leaks in the cooling system; see ⇒ Chapter "Cleaning the radiator, checking for leaks", P. 6-178.




## COOLANT TEMP message

if the COOLANT TEMP message appears, the coolant temperature is too high.

The message can have different causes:


- insufficient coolant in the cooling system; check coolant level, see ⇒ Chapter "Topping up coolant and checking coolant concentration", P. 6-178
- Functional fault at the electrical fan
- Defective thermostat
- Radiator clogged, see ⇒ Chapter "Cleaning the radiator, checking for leaks", P. 6-178



## OVERHEATING message

If the OVERHEATING message appears, the traction motors are overheated. Vehicle speed and acceleration are reduced.

- Allow the vehicle to cool down.
- If the condition persists, contact your service centre.




## Error messages

**ABGASREINIGER (EXH. GAS PURIFIER) message** ▷

If the ABGASREINIGER (EXH. GAS PURIFIER) message appears, the particle filter is full.

- Service the Eberspächer particle filter, see ⇒ Chapter "Servicing Eberspächer particle filters", P. 6-187.



## Operation in special operating situations

### Transport

When driving the forklift truck onto the transport means, pay attention to the following:


- The load capacity of the transport means, ramps, and loading bridges must be greater than the loading weight of the forklift truck.
- Maintain a safe distance from edges, loading bridges, ramps, working platforms, and the like.
- Make sure the tail end doesn't veer out.
- Make sure that the tail end doesn't veer out from the loading bridge in the direction of the edge when turning the steering wheel while driving forward. This can cause the forklift truck to crash.
- Lower the forks completely.
- Always disconnect the battery plug during transport.
- Apply the parking brake, and remove the key.

### Wedging

- Use two wedges to secure each of the front and back wheels against rolling and use wooden blocks to secure the sides against shifting.

#### CAUTION


The wooden blocks must be secured (e.g. with nails).



## Operation in special operating situations

### Securing

- Secure the ropes to the mast in the front and to the towing devices in the back.




### Towing

If the brake for the towed forklift truck is no longer functional, the forklift truck can only be towed with a fixed connection (towing bar).

To tow the forklift, a towing vehicle with sufficient tractive power and braking force for the unbraked towed load is required.

- Set down load and lower fork arms almost to the floor.
- Switch off the engine.



#### **⚠ CAUTION**

As a result of the design of the drive, the engine cannot be started by pushing or towing the truck. Don't start vehicle by pushing or pulling!

#### **⚠ CAUTION**

Steering is stiff! There is no power steering if the hydraulics are not active!

The maximum vehicle towing speed is walking speed.

- After towing, secure truck from rolling away (e.g. by placing chocks).
- Apply the parking brake.

## Crane loading

Crane loading is only intended for transporting the complete truck, including the lift mast, for its commissioning. For use situations that require frequent loading or that are not presented here, please contact the manufacturer with regard to special equipment variants.

Only those persons with sufficient experience of suitable slings and lifting gear may load up forklift trucks.

### Determining loading weight

- Park truck securely.
- Determine the loading weight of the truck.
- Read the following weights on the factory nameplate, and if necessary, the factory nameplate of the attachment, and perform the addition:

Tare weight (1) + ballast weight (3) (if present) + tare weight of the attachment (if present) = laden weight.

### Attaching lifting slings

#### **⚠ CAUTION**

Failure to follow these instructions could result in damaged components.

Use textile slings and, if necessary, edge protectors or similar protective equipment to prevent damage to the truck.

Only use hoists and slings with adequate lifting capacity for the determined loading weight.

#### **⚠ DANGER**


##### **Risk of accident!**

Only use the designated attachment points on your truck!

Make sure that lifting gear such as hooks, shackles, belts and similar items are stressed only in the load direction indicated.

The lifting gear must not be damaged by truck parts.

- Loop the slings to the right and the left around the main traverse (1) on the outer mast of the lift mast.



## Operation in special operating situations


**i** NOTE

The attachment points are indicated by a hook symbol.


**⚠ DANGER**

Only use the designated attachment points on your truck! Make sure that harness parts such as hooks, shackles, belts and similar items are stressed only in the load direction indicated. The lifting gear must not be damaged by truck parts.

- Loop the slings to the right and the left around the main traverse (1) on the outer mast of the lift mast.



- Loop the slings (2) around the counterweight between the counterweight and the steering axle.
- Determine the centre of gravity for your truck.



The centre of gravity is indicated by the "S" symbol in the operating manual in the Technical Data section, see ⇒ Chapter "Dimensions", P. 7-226.

- Set the length of the slings so that the crane hook (3) is vertically above the centre of gravity of the forklift truck.

This ensures that the forklift truck hangs level when lifting it.

- Hang the slings from the crane hook and engage the (4) locking device.

**⚠ CAUTION**

Failure to follow these instructions could result in damaged components.

The slings must be attached so that the lifting forces do not act on truck attachments or parts of the overhead guard or the cab. If attachments are in the way (e.g. lights, rear window, trademark emblem etc.), these must be removed before loading.

**Loading truck**

- Carefully lift the truck and set it down at the intended location.

**⚠ DANGER****Risk to life!**


Never walk or stand underneath suspended loads.

Do not allow the forklift truck to bump into anything whilst it is suspended, or allow it to move in an uncontrolled way. If necessary, hold the truck using guide ropes.

**Jump starting****i NOTE**

*A power source with 12 V (e.g. second forklift truck of same type) must be available.*

- Open the bonnet; see ⇒ Chapter "Open the motor hood.", P. 5-53.
- Allow the engine in the vehicle providing the current to run.
- Connect the positive cable (2) to the positive terminal on the dead battery first and then connect it to the positive terminal of the current-providing battery.
- Connect the negative cable (1) to the negative terminal of the current-providing battery first and then connect it to the negative terminal of the dead battery.
- Start the engine, see ⇒ Chapter "Start the engine", P. 5-62.
- Once the engine is running, remove the jumper cables in exactly the reverse order.



7311\_606-001

## Operation in special operating situations

- Close the bonnet.

## Filling fuel

### Filling up with diesel


The fuel reserve is displayed by the flashing percent indicator for the fuel level (1) on the display and operating unit.



#### **⚠ DANGER**

##### **Risk of fire!**

- Turn off the engine before filling up.
- Do not smoke or use naked flames when filling up.
- Legal regulations relating to the handling of diesel fuel must be observed.
- Observe the safety regulations for handling diesel fuel, see => Chapter "Diesel fuel", P. 3-30.



#### **⚠ CAUTION**

The truck may only be operated with diesel fuel according to DIN EN 590 .


Use of fuel additives supporting soot burn-off is not permitted.

Starting aids (such as "Startpilot" among others) must not be used.

At low temperatures, winter diesel must be used, see => Chapter "Diesel fuel", P. 6-163.

- Open the locking cap (2) of the fuel tank and fill up with clean diesel fuel.

For the fill quantity, see => Chapter "Maintenance data table", P. 6-165.



## Shut-down

## Shut-down

## Park truck secured

**⚠ DANGER****Risk of accident!**

The truck should not be parked on a slope.

- In case of emergency, secure the truck with chocks.

**⚠ WARNING****Risk of accident!**


- Before leaving truck, fully lower load.
- Apply the parking brake (1).
- Lower the forks to the ground and tilt the fork tips sufficiently forward, until they touch the ground.
- Turn the ignition key to the left and remove it.

**i NOTE**

*Without explicit instructions, the ignition key or Fleet Manager card (special equipment) should not be made available to other persons.*

**i NOTE**

*Avoid parking the vehicle for long periods at temperatures lower than 0°C, because the hydraulic fluids will be very viscous and the functions will be tight.*



## Use wheel chocks

The wheel chock (special equipment) serves, among other things, to prevent the forklift truck from rolling away on a slope.


### ⚠ WARNING

Risk of accident!

- If the vehicle is parked with a chock, the load is to be lowered onto the ground.
- 
- Lift handle (3) on the mounting support.
  - Remove wheel chock (4) from the mounting support.
  - Place wheel chock on the side facing downhill behind a wheel of the front axle.

### **i** NOTE

*After using the wheel chock, reinsert into the mounting support and fold the handle (3) back downwards.*



## Measures for prolonged shutdown, storage of truck

If the truck is to be stored for a prolonged time, the following measures must be taken to protect against corrosion. If the truck is to be shut down for more than two months, it must be parked in a clean and dry area. The area should also be well ventilated and frost free. The following additional measures must be taken:

### Measures before shutdown

- Clean forklift truck thoroughly.
- Lift fork carriage to full extent several times.
- Tilt the mast forwards and backwards several times and, if fitted, move attachments repeatedly.
- To relieve the strain on the load chains, lower forks onto a suitable supporting surface e. g. a pallet.
- Check hydraulic oil level and top up if required.

## Shut-down

- Apply oil or grease thinly to all uninsulated moving parts.
- Lubricate the forklift truck.
- Fill the fuel tank.
- Oil joints and controls.
- Check the condition and acid density of the battery and maintain the battery as specified by the manufacturer. (Follow the instructions provided by the battery manufacturer.) Only store completely charged batteries.
- Apply a suitable contact spray to all exposed electrical contacts .
- Preserve the engine as specified by the manufacturer.

### **▲ CAUTION**

Jack up the truck so that all wheels are clear of the ground. This prevents permanent deformation of the tyres.

- Cover the truck with a cotton sheet and protect against dust.

### **▲ CAUTION**

We do not recommend using a plastic sheet as this promotes the formation of condensation.

If the truck is to be shut down for even longer periods, contact your service centre for additional recommended measures.

## Returning to service after storage

If the truck has been in storage for longer than six months, it must be carefully checked before being put back into service. As in the UVV (accident prevention) inspection or the annual inspection, this check should also include all safety items for the truck.

- Clean the forklift truck thoroughly.
- Oil joints and controls.
- Check battery condition and acid density; recharge if necessary.

- Restore engine to normal condition according to regulations of engine manufacturer.
- Check hydraulic oil for condensed water; change if necessary.
- Perform maintenance as before initial start-up.
- Put the truck into service.

Check during start-up in particular:

- drive, control, steering
- brakes (service brake, parking brake)
- lifting system (load-carrying equipment, load chains, fastening)



6

---

## Maintenance

## General maintenance information

# General maintenance information

## Qualifications of personnel

Only qualified and authorised personnel are allowed to perform maintenance work. The annual check must be conducted by a specialist. The specialist's evaluation must be unaffected by operational and economic conditions and be conducted solely from a safety standpoint. The specialist must have sufficient knowledge and experience to be able to assess the condition of a forklift truck and the effectiveness of the protective equipment according to technical conventions and the principles for testing forklift trucks.

## Maintenance work for which no special qualifications are necessary

Simple maintenance work, e.g. checking the hydraulic oil level or checking the fluid level in the battery, may be performed by untrained personnel. This does not require training as described above. Refer to this operating manual for further information.

## Information regarding performing maintenance

This section contains all information to determine when your truck must be serviced. Be sure to perform maintenance according to the maintenance overview programme; this is essential to obtain the full availability, productivity and working life from your truck, and is a pre-condition for any warranty claims.

**Time of maintenance**

Maintenance on the truck must be performed based on the operating hours meter. The maintenance overview programme indicates which maintenance work is due.


The maintenance overview programme includes instructions for performing maintenance.

All lubrication and service intervals must be reduced appropriately for dusty conditions, large temperature fluctuations or intensive use.

**CAUTION**

Risk of component damage!

If technical values in this manual vary from those listed in the enclosed operating instructions for the engine, the values in this manual have priority.



**Maintenance and lubrication**

1. During the initial operating period (designated by numbers in bold with a star (\*))
2. According to the hour meter (bold numbers)


After **6000** operating hours, for example, the following must be performed: maintenance and lubrication "after 1000 and 3000 operating hours".

<b>50*</b>								
<b>1000</b>	<b>2000</b>	<b>3000</b>	<b>4000</b>	<b>5000</b>	<b>6000</b>	<b>7000</b>	<b>8000</b>	<b>9000</b>
1000	1000	3000 1000	1000	1000	6000 3000 1000	1000	1000	9000 3000 1000

After **9000** operating hours, continue as above — instead of 1000 then 10,000 operating hours.

## General maintenance information

## Maintenance points overview



## Intervals for maintenance and inspection

The work shall be performed by your service centre according to the maintenance intervals listed below.

### Maintenance after 50 operating hours

Position	Maintenance work
-	Maintenance during the break-in period; see ⇒ Chapter "Maintenance during the breaking-in period", P. 6-177

### Maintenance as required

Position	Maintenance work
-	Clean truck, see ⇒ Chapter "Cleaning", P. 174
-	Clean radiator, checking seal, see ⇒ Chapter "Cleaning the radiator, checking for leaks", P. 6-178
-	Topping up coolant and checking concentration of coolant additive, see ⇒ Chapter "Topping up coolant and checking coolant concentration", P. 6-178
-	Drain water out of the fuel filter, see ⇒ Chapter "Drain the fuel filter of water", P. 6-180
-	Replace air filter insert, see ⇒ Chapter "Replacing the air filter insert", P. 6-181
-	Check parking brake setting, see ⇒ Chapter "Checking parking brake setting", P. 6-183
-	Service battery, see ⇒ Chapter "Servicing battery", P. 6-183
-	Service hydraulic equipment, see ⇒ Chapter "Maintaining hydraulic equipment", P. 6-186
-	Servicing Eberspächer particle filter, see ⇒ Chapter "Servicing Eberspächer particle filters", P. 6-187
6	Service wheels and tyres, see ⇒ Chapter "Servicing wheels and tyres", P. 6-191
-	Joints and controls, see ⇒ Chapter "Lubricating joints and controls", P. 6-192
5	Service steering axle, see ⇒ Chapter "Maintaining the steering axle", P. 6-192
1	Service mast bearings, see ⇒ Chapter "Servicing the mast bearing", P. 6-195

## General maintenance information

Position	Maintenance work
1	Service load chains, see ⇒ Chapter "Load chain maintenance", P. 6-195
1	Lubricate lift mast and roller track, see ⇒ Chapter "Lubricating the lift mast and roller track", P. 6-198
3	Service restraining belt, see ⇒ Chapter "Servicing the restraining belt", P. 6-198
3	Check driver's seat, see ⇒ Chapter "Check driver's seat", P. 6-200
-	Replace fuses, see ⇒ Chapter "Replacing fuses", P. 6-200
-	Service attachments, see ⇒ Chapter "Attachment maintenance", P. 6-202

## 1000 hour maintenance/annual maintenance

Position	Maintenance work
7	Servicing drive axle, see ⇒ Chapter "Maintenance of drive axle", P. 6-203
-	Adjusting parking brake switch, see ⇒ Chapter "Adjusting the parking brake", P. 6-204
-	Lubricating parking brake lever bearing and ratchet, see ⇒ Chapter "Lubricating the parking brake lever bearing and ratchet", P. 6-204
-	Check the counterweight fastening, see ⇒ Chapter "Checking the counterweight attachment", P. 6-204
-	Replace engine oil and filter, see ⇒ Chapter "Changing the engine oil and filter", P. 6-204
-	Checking the ribbed V-belt, see ⇒ Chapter "Checking the ribbed V-belt", P. 6-206
-	Check toothed belt, see ⇒ Chapter "Checking the toothed belt", P. 6-207
-	Replace fuel filter, see ⇒ Chapter "Replacing the fuel filter", P. 6-207
-	Replace fuel filter for the Eberspächer exhaust cleaner, see ⇒ Chapter "Replacing the fuel filter for Eberspächer exhaust gas cleaners", P. 6-208
4	Check exhaust system; see ⇒ Chapter "Checking the exhaust gas system", P. 6-208
-	Check the heating system for leaks, see ⇒ Chapter "Checking the heating system for leaks", P. 6-208
1	Check lift cylinders and connections for leaks, see ⇒ Chapter "Check lift cylinders and connections for leaks.", P. 6-209

Position	Maintenance work
1	Service lifting system, see ⇒ Chapter "Maintain lifting system", P. 6-209
1	Check play between fork carriage stop and run-out stop, see ⇒ Chapter "Checking play between fork carriage stop and run-out stop", P. 6-211
8	Check fork arms, see ⇒ Chapter "Checking the fork arms", P. 6-211
-	Check reversible fork arms, see ⇒ Chapter "Checking reversible fork arms", P. 6-212

### 3000-hour maintenance/two-year maintenance

Position	Maintenance work
-	Carry out all work from the 1000 hours maintenance/annual maintenance
7	Replace gear lubricant oil, see ⇒ Chapter "Changing the gear lubricant oil", P. 6-213
-	Check wheel bearings, see ⇒ Chapter "Checking the wheel bearing", P. 6-214
-	Check engine bearing, see ⇒ Chapter "Checking the engine mountings", P. 6-214
-	Replace toothed belt, see ⇒ Chapter "Replacing the toothed belt", P. 6-215

### 6000-hour maintenance

Position	Maintenance work
-	Carry out all work from the 1000 hours maintenance/annual maintenance
-	Carry out all work from the 3000 hours maintenance/two-year maintenance
-	Replace hydraulic oil and filter, see ⇒ Chapter "Replacing the hydraulic oil and filter", P. 6-217

### 9000 hour maintenance/five-year maintenance

Position	Maintenance work
-	Carry out all work from the 1000 hours maintenance/annual maintenance

## General maintenance information

Position	Maintenance work
-	Carry out all work from the 3000 hours maintenance/two-year maintenance
-	Replace coolant; see ⇒ Chapter "Changing the coolant", P. 6-221

## Ordering spare parts and wearing parts

Spare parts are provided by our spare parts service department. The information required for ordering spare parts is shown in the spare parts list.

Only use spare parts as per the manufacturer's instructions. The use of unapproved spare parts can result in an increased risk of accidents due to insufficient quality or incorrect assignment.

Anyone using unapproved spare parts shall assume unlimited liability in the event of damage or harm.



STILL  
ELECTRONIC  
DOCUMENTATION  
SYSTEM

R70-40  
R70-45  
R70-50



CE

7071\_003-049

Ident. Nr. 171 649 - 03.07

R7071-73

## Quality and quantity of the required operating materials

Only the operating materials specified in the maintenance data table may be used.

Consult the maintenance data table for the consumables and lubricants needed for maintenance. See ⇒ Chapter "Maintenance data table", P. 6-165.

Different quality oil and grease types may not be mixed. This negatively affects the lubricity. If a change between different manufacturers cannot be avoided: remove the old oil particularly thoroughly.

Before performing greasing, filter changes or any intervention in the hydraulic system, carefully clean the area around the part involved.

When topping up consumables, use clean containers only!

## Diesel fuel

Use distillate fuels without residual oils.

The following limits are specified:

- Density  $\leq 900 \text{ kg/m}^3$
- Cetane number  $\geq 49$

No special engine equipment is required for pure distillate fuels.

- Low-sulphur diesel fuels with a sulphur content of  $< 0.05 \%$  can be used. An adequate lubricity, however, must be ensured through the use of additives. It is the responsibility of the fuel manufacturer to ensure this.

## Winter operation with diesel fuel


Winter operation places special demands on the cold characteristics. Suitable fuels are available for this season (winter diesel fuel), see the specifications. If only summer diesel fuel is available at low ambient temperatures, petroleum can be added to the diesel fuel according to the opposite diagram to ensure its flowability. Only make the mixture in the tank: First fill the necessary quantity of petroleum, then add diesel fuel.

I = Summer diesel fuel

II = Winter diesel fuel

A = Ambient temperature

B = Proportion of petroleum



## General maintenance information

### **▲ WARNING**

It is not permitted to add regular grade petrol according to the laws governing safety .

For arctic climates diesel fuels are available for an ambient temperature of -44°C.

The addition of flow improvers to diesel fuel is possible. The fuel supplier should be consulted as regards efficiency and compatibility .

– Only mix in fuel tank. Do not use petrol.

Outside temperature °C	Summer diesel %	Winter diesel %	Petroleum %	
0 to -10	60	100	40-	-
-10 to -15	40-	100	60	-
-15 to -20	-	100	-	-
-20 to -25	-	75	-	25
-25 to -30	-	50	-	50
-30 to -35	-	40-	-	60

## Maintenance data table

Units	Operating materials	Specification	Dimension
General lubrication points	Grease	DIN 51825-KPF2 N-20 penetration class 2, lithium-saponified, ID no. 141001 (400g cartridge)	as required
Battery	Distilled water		as required
- Insulation resistance			min. 1000 Ohm against ground
Controls/joints	Grease	DIN 51825-KP2 K-20 penetration class 2, lithium-saponified ID no. 163488 (225 g tube)	as required
	Oil	SAE 80 MIL-L2105 API-GL4	as required
Hydraulic system	Hydraulic oil	HVLP68 DIN 51524 Part 3	approx. 48 l
	Hydraulic oil for the foodstuffs industry (special equipment)	USDA H1 DIN 51524	approx. 48 l
Tyres			
- Pneumatic tyres	-		Air pressure: see information on truck Min. profile height: 1.6 mm
- Superelastic tyres	Wear limit:		To wear mark
Wheel mounting nuts			
- Drive axle	Torque wrench		M20x1.5: 640 Nm
- Steering axle	Torque wrench		M20x1.5: 600 Nm
Carraro drive axle EC50i			
- Gear wheel	Mineral oil	ARAL HGS FLUID 127830	Right-hand side: 1.1 l Left-hand side: 0.65 l
Lift mast	Super-pressure adhesive lubricant	ID no. 147873	as required
- Stop	-		Clearance: min. 2 mm
- Mast bearing screws	Torque wrench		M16x80 10.9: 290 Nm

## General maintenance information

Units	Operating materials	Specification	Dimension
Load chains	Chain spray	ID no. 141001 ID no. 156428	as required
- Setting			Distance from the support roller under the inside mast to the top edge: 15 mm
Steering axle			
- Axle stub nuts	Torque wrench		310 Nm
- Wheel hub fastening	Torque wrench		470 Nm
Cooling system	Coolant/water	G12 plus TL-VW 774 F	approx. 11.5 l
Fuel tank	Diesel	-	approx. 58 l
Switching off	Engine oil	VW 507.00	With filter change 4.5 l
Air filter			
- Dry air filter	Filter flushing agent	-	as required

## Safety instructions for maintenance

### General information

To prevent accidents during maintenance and repair work, all necessary safety measures must be taken, e.g.:

- Ensure that unintentional movement or undesired start-up of the forklift truck is prevented (apply the parking brake, jack up the forklift truck).
- Secure against lowering when working under raised load-carrying equipment.
- Secure the mast against unintentional tilting.

### Carrying out work on the hydraulic equipment

Hydraulic equipment must be depressurised prior to all work. See ⇒ Chapter "Depressurising connections for attachments", P. 5-104.

### Working on electrical equipment

Work may only be performed on electrical equipment of the forklift truck in a voltage-free state. Only trained and commissioned persons may perform functional tests, checks, and settings on parts under voltage while taking the suitable precautionary measures. Rings, metal bracelets, etc. must be removed prior to working on electrical components.

To prevent damage to e-systems with electronic components, such as an electronic driving regulator or lift control, these components must be removed from the forklift truck prior to the start of electric welding.

Work on the electrical system (e.g. connecting a radio, additional headlights, etc.) must be approved by us.

### Safety devices

After maintenance and repairs, all safety devices must be reinstalled and checked for proper functioning.

## Safety instructions for maintenance

### Set values

The device-dependent set values must be observed when making repairs and replacing hydraulic and electrical components. These are listed in the appropriate sections.

### Raising and jacking up

#### **⚠ DANGER**

##### **Risk of accident!**

To lift the truck, the components and the attachments, the lifting mechanism may only be applied at the designated points. When jacking up the equipment, appropriate measures must be taken (chocks, wooden blocks) to prevent rolling or tipping.

The truck has to be jacked up for various maintenance tasks. Always ensure that:

- that only jacks with sufficient lifting capacity are used,
- that the truck is only jacked up on level ground, and is secured against rolling and sinking.

#### **⚠ WARNING**

##### **Risk of accident!**

Apply the parking brake and turn off engine when jacking up the truck.

#### **⚠ WARNING**

##### **Risk of injury!**


- Jack up the truck sufficiently high that shoes cannot get trapped under a turning wheel.

**Jack up at the frame.**

- Place jack sideways under the chassis at the designated position.
- Jack up the truck until the rear wheels are no longer in contact with the ground.
- Secure the truck.

** NOTE**

*If the front of the truck must be lifted, the jack must be applied at the lift mast.*

**Jacking up at the lift mast**

- Lift the fork carriage and secure against accidental lowering.

** WARNING**

Risk of injury!


Observe the safety regulations for working on lift masts, see ⇒ Chapter "Working at the front of the forklift truck", P. 6-170.

- Apply the jack at the mast.
- Jack up the truck until the wheels are no longer in contact with the ground.
- Secure the truck.

** WARNING**

Risk of injury!

Do not jack up truck by rear weight.



## Safety instructions for maintenance

### Working at the front of the forklift truck

#### **⚠ WARNING**

Risk of accident!


If the lift mast or fork carriage is raised, no work must be performed on the lift mast or at the front of the forklift truck without observing the following safety measures!

### Removing the lift mast

#### **⚠ CAUTION**

Attach the lifting gear to the top of the bridge piece (2) on the outer mast of the lift mast.

This work must only be performed by a service technician.



### Securing lift mast against tilting back

The lift mast must be secured against unintentional tilting by clamping a suitable wooden beam (120 x 120 x 1100 long) (1) to it.


### Securing the telescopic lift mast

#### **⚠ CAUTION**

In order to secure the telescopic lift mast, select a chain with sufficient load bearing capacity for the respective lift mast.

Note the maximum lift height.

- Extend the lift mast.
- Route the chain along the cross traverse of the outer mast (3) and connect under the cross traverse of the inside mast (4).
- Lower inside mast until the chain is impacted.




### Securing the triple lift mast

#### **⚠ CAUTION**

In order to secure the triple lift mast, select a chain with sufficient load bearing capacity for the respective lift mast.

Note the maximum lift height.


- Extend the lift mast.
- Route the chain along the cross traverse of the outer mast (7) and connect under the cross traverse of the central mast (8).
- Lower lift mast until the chain is impacted.
- Lower fork carriage down to the stop.



## Preparation for maintenance


**Preparation for maintenance****Installing and removing the floorplate** ▷

- Open the bonnet; see ⇒ Chapter "Open the motor hood.", P. 5-53.
- Lift floorplate by using (1) the handle.



- Separate connector on the accelerator (2) ▷
- Lift floorplate and place in a safe location.


Installation is carried out in reverse order.



## Removing and installing the rear cover

- Undo three screws (1).
- Lift up cover (2) and remove.

Installation is carried out in reverse order.



## Cleaning

## Cleaning

## Cleaning the truck

**⚠ CAUTION**

The engine must be switched off during washing.

- Switch off key switch and remove key.

**Instructions for washing**

- Always park vehicle according to regulations.
- Apply the parking brake (2).
- Switch off the key switch (1) and remove the key.

**Washing outside of truck****⚠ WARNING**

Risk of fire!

Do not clean with combustible liquids.

- Deposits/accumulations of combustible materials, especially on or in the vicinity of parts with high temperatures (e.g. exhaust pipes) must be removed regularly.


**⚠ WARNING**

If the forklift truck is to be cleaned with hot-water devices, all sensitive - particularly electric - components must be carefully covered.


Note the manufacturer's guidelines for working with cleaning agents.

- Clean the vehicle on the outside with water-soluble cleaning agents and water (water jet, sponge, cloth).
- Pay particular attention to all walk-in areas, the oil filling openings and their surroundings, as well as the lubricating nipples before lubricating.

Please note: The more often the truck is cleaned, the more frequently it must be lubricated.



7071\_003-021



7071\_003-022

**⚠ CAUTION**

Failure to follow these instructions could result in damaged components.

Steam jet cleaners may be used with max. 50 bar at 85°C at a distance of at least 20 cm.

Do not directly spray electric motors and other electrical components or their covers.

Do not aim the cleaning jet directly at stickers or notices.

Plastic parts, particularly on the console, may only be cleaned with plastics cleaners (display windows could become cloudy).

**Cleaning the electrical system****⚠ CAUTION**


Cleaning electrical system parts with water can damage the electrical system.

Cleaning electrical system parts with water is forbidden!

Only use a dry cleaning agent according to the manufacturer's specifications.

Do not remove covers etc.

- Clean and dry electrical system parts with weakly compressed air and a metal-free brush.


**Clean load chains****⚠ WARNING**

Risk of accident!

Load chains are safety elements.

The use of cold/chemical cleaners or fluids that are corrosive or contain acid or chlorine can damage the chains and is forbidden!

- Place a collection vessel under the lift mast.
- Use paraffin derivatives such as benzene for cleaning (take note of the manufacturer's safety information.)
- When cleaning with a steam jet, do not use additives.



## Cleaning

- After cleaning, immediately apply compressed air to chain to remove any water remaining in the chain joints. Move the chain several times during this process.
- Immediately spray the chain with chain spray according to the maintenance data table (see → Chapter "Maintenance data table", P. 6-165) while moving the chain.

## Cleaning the windscreens


On trucks with cabs (special equipment), the glass windscreens (1) must always be kept free of dirt and ice in order to ensure clear vision.

- Cleaning the windscreens.



### NOTE

*The windscreens can be cleaned using a conventional glass cleaner.*




## After washing

- Carefully dry truck (e.g. with compressed air).
- Sit on the driver's seat and start up the vehicle in line with the regulations.

### CAUTION

Risk of short circuit!

- If any moisture has penetrated into the motors despite the precautionary measures taken, first dry them using compressed air.
- The truck must then be started up to prevent possible corrosion damage.



## Maintenance after first 50 operating hours

### Maintenance during the breaking-in period

- Checking the ribbed V-belt condition and tension, see ⇒ Chapter "Checking the ribbed V-belt", P. 6-206.
- Checking the exhaust system, see ⇒ Chapter "Checking the exhaust gas system", P. 6-208.

## Maintenance as required

## Maintenance as required


## Cleaning the radiator, checking for leaks

- Only clean the radiator (1) with the engine switched off. ▷
- Clean radiator matrix with a suitable brush and blow out with compressed air (max. 2 bar).
- Check radiator and coolant hoses for leaks and retighten clamps, if necessary.

**▲ CAUTION**

Risk of engine damage!

Check whether the leakage has been stopped and contact your service centre, if necessary.



## Topping up coolant and checking coolant concentration

- Remove the rear cover, see ⇒ Chapter "Removing and installing the rear cover", P. 6-173. ▷

**▲ CAUTION**

Risk of engine damage!

If the coolant level is low, this indicates a leak in the cooling system.


- Check for leaks in the cooling system; see ⇒ Chapter "Cleaning the radiator, checking for leaks", P. 6-178.

**▲ WARNING**

Risk of scalding!

Only open the lid of the expansion tank when the engine has cooled down.

- Open the lid slowly (1) and allow the pressure to drop.
- Unscrew further and remove the lid.



**⚠ WARNING**

Coolant and coolant additives are hazardous to your health.

Please observe safety regulations when working with coolant, see ⇒ Chapter "Coolant", P. 3-33.

- Check the coolant concentration.

**Coolant concentration****⚠ CAUTION**

Risk of corrosion!

The percentage of coolant additive must always be at least 40%, even if the frost protection is not needed in warmer climates.

If greater frost protection is required for climatic reasons, the percentage of the coolant additive can be increased to up to 60%.

The percentage of the coolant additive must not exceed 60%, otherwise the frost protection is reduced. In addition, the cooling effect is also reduced.

Only use clean softened water in the coolant.

Frost protection up to °C	Water percentage %	Coolant additive percentage %
-25	60	40
-30	55	45
-35	50	50
-40	40	60

Fill quantity in the cooling system, see ⇒ Chapter "Maintenance data table", P. 6-165.

**⚠ CAUTION**


Coolant additive with a different specification must not be mixed in!

- For topping up, use coolant as per the maintenance data table; see ⇒ Chapter "Maintenance data table", P. 6-165.

Only use coolant according to the manufacturer's instructions.

### Maintenance as required

- Screw the lid back on again (1) tightly.
- Re-attach the rear cover.



### Drain the fuel filter of water




#### ⚠ WARNING

Consumables are toxic.

Note safety regulations for working with diesel fuel; see ⇒ Chapter "Diesel fuel", P. 3-30.

- Open the bonnet; see ⇒ Chapter "Open the motor hood.", P. 5-53.
- Hold suitable collection vessel underneath the drainage screw (1).
- Open the drainage screw (1) on the filter and drain off fuel (approx. 100 cm<sup>3</sup>) until cleaner fuel escapes.
- Manually retighten drainage screw (1).
- Close the bonnet.



#### **i** NOTE


*The draining of water is particularly important for operating in the tropics and depending on the quality of fuel used.*

## Replacing the air filter insert


### NOTE

*Exchanging the air filter insert is necessary only when the AIR FILTER message appears on the display and operating unit, or every two years.*

- Open the bonnet; see → Chapter "Open the motor hood.", P. 5-53.



- Release the three clips (4) on the air filter.
- Take off the air filter cover (5).



## Maintenance as required


- Remove (7) and replace the main cartridge. ▷

**⚠ CAUTION**


Risk of engine damage!

The safety cartridge must remain in the air filter housing until all residual dirt has been removed from the housing so that no dirt enters the induction system!


- Blow out the air filter housing with compressed air.



- Remove the (8) safety cartridge, check it for contamination, and replace it if necessary. ▷
- Insert the safety (8) cartridge.
- Insert a new main (7) cartridge.



- Insert the air filter (5) with the mark (6) facing upwards. ▶
- Secure the three clips (4) on the air filter.
- Close the motor hood.



## Checking parking brake setting

### **i** NOTE

*Only reset the brake cable if it has become elongated.*

- Open the bonnet; see ⇒ Chapter "Open the motor hood.", P. 5-53.
- Disassemble base plate; see ⇒ Chapter "Installing and removing the floor-plate", P. 6-172

### **i** NOTE

*The adjustment instructions were not yet available at the time of printing. Please contact your service centre.*

## Servicing battery

### **i** NOTE

*Battery servicing is carried out in accordance with the battery manufacturer's operating manual.*

## Maintenance as required




### ⚠ WARNING

There is a risk of damage, short circuit and explosion.

Do not place any metal objects or tools on the battery. Keep away open flames; no smoking.

## Checking the battery charge status

- Open the bonnet, see ⇒ Chapter "Open the motor hood.", P. 5-53.
- With maintenance-free batteries, check the charge state at the inspection window: ▷
- **Green:** The battery is optimally charged.
- **Black:** The charge state is no longer optimal. The battery should be recharged. After recharging, the indicator changes back to green.
- **Transparent-(light-coloured):** The charge state is no longer adequate for reliable starting. It is necessary to replace the battery.



## Charging the battery

- With batteries that are not maintenance-free, check the level of the battery acid.



### ⚠ WARNING

The electrolyte (dilute sulphuric acid) is poisonous and caustic.

Follow the safety regulations when handling battery acid ⇒ Chapter "Battery acid", P. 3-33.

The battery acid must be up to the lower edge of the insert in the battery housing or up to 5 mm above the upper edge of the plates. Observe the manufacturer's specifications!

### ⚠ CAUTION

The battery can be damaged!

Only fill up missing fluid with distilled water.

- Unscrew the battery cell covers and check the acid density with an acid siphon. ▷

The density of the acid must achieve the value in the table. The listed density of the acid refers to 27 °C acid temperature.

Density of acid	empty	full
normal	1.13	1.28
droplets	1.08	1.23




#### ⚠ WARNING

Risk of explosion! Charging releases gases that are explosive.

While charging, the surfaces of the battery cells must be exposed to ensure sufficient ventilation.

The charging area must be properly ventilated.

Keep the bonnet open during charging; avoid spark formation near the battery.



- Immediately charge empty batteries until they are full again.

The charging current shall not exceed 1/10 of capacity.

The cell lid of the battery must be kept dry and clean.

Any spillage of battery acid must be neutralised immediately.

Terminals and lugs must be clean, lightly coated with terminal grease and tightly screwed.

- After charging, screw the battery cell covers back on.
- Close the bonnet.

## Maintenance as required

## Maintaining hydraulic equipment


**▲ WARNING**

Hydraulic oils are hazardous to your health and are under pressure during operation.


Note safety regulations for working with hydraulic oils; see ⇒ Chapter "Hydraulic fluid", P. 3-32.

**Check hydraulic oil level**

- Position truck horizontally.
- Tilt lift mast forward.
- Lower forks; if there are attachments (special equipment), retract the working cylinder.
- Switch off the engine.
- Open the bonnet; see ⇒ Chapter "Open the motor hood.", P. 5-53.
- Disassemble base plate; see ⇒ Chapter "Installing and removing the floor-plate", P. 6-172.
- Unscrew (1) the dipstick and pull it out.
- Check oil level. The oil level must be at least up to the mark (2) on the dipstick.
- If the oil level is not up to the required level, the hydraulic oil must be topped up according to the maintenance data table (see ⇒ Chapter "Maintenance data table", P. 6-165) using the filler neck until the mark is reached.
- Reinsert (1) the dipstick and tighten it.



7071\_003-072



7094\_700-002

**Checking hydraulic equipment for leaks**

- Check pipe and hose screw connections for leaks (traces of oil).

Hose lines must be replaced if:

- the outer layer is damaged or embrittled with cracks
- they are leaking
- Unnatural deformations (e.g. bubble formation or buckling)
- fitting is detached from hose
- heavy damage to or corrosion of the fitting

Pipes must be replaced in case of:

- Abrasion with loss of material
- unnatural deformations and visible signs of bending stress
- they are leaking

## Servicing Eberspächer particle filters ▶

The particle filter system filters soot particles from the exhaust gases of the diesel engine.

The collected soot is burned in the filter.

The particle filter system consists of:

- Particle filter (2) with burner (3) and fuel supply (4, 5).
- Control unit (1)
- Operating device integrated in the display and operating unit (6)

The soot particulates are collected in the particle filter (2).

During engine operation, the glow plug is actuated for around one minute approx. every two hours.

After an engine operating time of approx. 7.5 hours, the message *Abgasreiniger* (EXH. GAS PURIFIER) appears in the display and operating unit. The particulate filter must be regenerated.



### NOTE

*If it is temporarily not possible to perform regeneration, you can continue to drive the vehicle for approx. another half hour.*

## Regenerating the particle filter



- Drive to a suitable parking space.



### ⚠ WARNING

Risk of fire!

The parking space may not be in a hazardous materials area, since hot combustion gases exit the exhaust pipe during regeneration.



## Maintenance as required

**i NOTE**

*Combustion may cause bad odours if fuel containing sulphur was used for operating the engine.*

**i NOTE**


*It is not possible to start the engine during regeneration.*

The regeneration must be started manually with the engine switched off and the ignition switched on.

A safety circuit prevents regeneration when the engine is running as the particle filter system might be destroyed.

- Switch off the engine and switch on the ignition again.
- Press the start button (7).


After pressing the start button, the regeneration process is completed automatically.




The message **BITTE WARTEN (PLEASE WAIT)** (8) appears in the display for the entire regeneration process.

After approx. 25 minutes, the regeneration is complete. The display **BITTE WARTEN (PLEASE WAIT)** (8) goes out. The filter is free of soot again.

If the burner flame goes out during the regeneration process, the control unit will automatically attempt to start up again.



Faults in the regeneration process are shown by the message **ABGASREINIGER (EXH. GAS PURIFIER)** (9). The faults must be corrected by the service centre.




## Maintenance as required

**Emergency stop during the regeneration process** ▷**⚠ WARNING**

Risk of fire!

If smoke starts to develop during the regeneration process, press the emergency stop switch immediately. By pressing the emergency stop switch, the diesel supply is cut off and regeneration is interrupted.



## Servicing wheels and tyres

### ⚠ WARNING

Risk of accident! With uneven wear or incorrect air pressure, the stability of the forklift truck decreases and the braking distance increases.

- Replace worn or damaged tyres on the right and left.

### Checking air pressure

- Check and correct the air pressure at all four wheels.

### i NOTE

*The correct air pressure for pneumatic tyres (special equipment) is based on the type of tyres used. Observe the information on the stickers (2) on your vehicle.*

### Checking condition and wear of the tyres

### ⚠ WARNING

Tyre quality affects the stability and handling of the forklift truck.



Changes can only be made in consultation with the manufacturer.

When changing wheels or tyres, always ensure that this does not cause the forklift truck to tilt to one side (e.g. always change right and left wheels at the same time).

### i NOTE

*The wear of the tyres on an axle must be approximately the same.*


- *The minimum tread depth (1) for pneumatic tyres must be **min. 1.6 mm** in every area of the tread.*
  - *Super-Elastic tyres (special equipment) can be worn down to the wear mark (4).*
- Measure the tread depth at all four wheels.
  - Remove any foreign matter that may have become lodged in the tyre tread.



## Maintenance as required

### Checking wheel fastenings

- Check the wheel fastening bolts (3) for tightness and re-tighten as necessary, for tightening torque values see ⇒ Chapter "Maintenance data table", P. 6-165. ▷



### Lubricating joints and controls


- Oil or grease other bearings and joints according to the maintenance data table. See ⇒ Chapter "Maintenance data table", P. 6-165.
- Driver's seat guide
- Cab door hinges (lubricate grease nipples with grease)
- Engine bonnet hinges (lubricate grease nipples with grease)
- Control linkage for valves

### Maintaining the steering axle

#### Checking the steering axle

- Check rubber elements of the axle tumbler bearing for condition and wear.


- Check the stub axle bearing (1) and tie rod joint (2) for play and wear. ▶



- Check the steering cylinder (4) for leaktightness (traces of oil). ▶

**NOTE**

*In the case of excessive play or of wear, have your service centre replace the appropriate parts.*



## Maintenance as required

**Lubricating the steering axle**

- Use grease to lubricate the lubricating nipples (5) at the stub axle bearing and steering lever bearings (see → Chapter "Maintenance data table", P. 6-165). Operate steering during the lubrication process.

**i NOTE**

*Please note: The more often the truck is cleaned, the more frequently it must be lubricated.*

**Checking the hoses for leaktightness**

- Retighten leaky connections.



**i NOTE**

*Have your service centre replace defective lines.*

- After repairs, force out trapped air by repeatedly turning the steering wheel from stop to stop.

**Checking the tightening torque of the stub axle nuts**

- Set steering to end stop.
- Use the torque wrench to check the tightening torque (see → Chapter "Maintenance data table", P. 6-165) of the stub axle nut (3).



## Servicing the mast bearing

### Mast bearing screws: Check the tightening torque


- Lift the fork carriage and secure against accidental lowering.

#### **⚠ WARNING**

Risk of injury!

Observe the safety regulations for working on lift masts, see ⇒ Chapter "Working at the front of the forklift truck", P. 6-170.

- Check tightening torque (see ⇒ Chapter "Maintenance data table", P. 6-165) of the mast bearing screws (1) with a wrench torque.



### Lubricating the mast bearing

- Lubricate the mast bearings with grease at the lubricating nipples (2) on the left and right (see ⇒ Chapter "Maintenance data table", P. 6-165).

## Load chain maintenance

### Testing the condition and wear of lift chains, lubricating

- Checking the condition of the load chains and checking for wear.

The load chains must be checked for the following external damage:

- broken fishplates
- broken bolts
- loose, twisted bolts
- surface rust
- stiff joints
- Wear and tear, damage to the clamping screw and end link.

## Maintenance as required

### WARNING

If the chain is damaged before reaching the permissible elongation, the load chain may break.

If any of the above-mentioned damage has occurred, the load chain must be replaced without delay.

- Spray the load chains with chain spray according to the maintenance data table, see ⇒ Chapter "Maintenance data table", P. 6-165.
- Checking the load chain tension.

### CAUTION

Never compensate tyre wear by adjusting lift chain tension!

Only retighten the load chains after elongation due to wear. The chains should be replaced once elongation reaches 3%.

### CAUTION

If the load chains can no longer be retightened, the chains must be replaced completely, along with all associated connecting parts.

Please contact your service centre.

### NOTE


*After adjusting the load chains, the clearance between the fork carriage stop and run-out stop must be checked, see ⇒ Chapter "Checking play between fork carriage stop and run-out stop", P. 6-211.*

### Setting the load chains Tele mast

- Unscrew the cap screw (1) and remove the safety (2) cap.
- With the lift cylinders fully extended, retighten the load chains at the tensioning nuts (3) until the centre of the middle fork carriage support roller is 15 mm below the upper edge of the inner mast.

Stop always between lift cylinder and piston.

- Replace the (2) safety cap.
- Apply Loctite to the cap screw (1) and tighten.



### Setting the load chains triplex mast

- Fully lower the fork carriage.

Mast uprights must be flush at the top. If not:


- Unscrew the cap screw (1) and remove the safety (2) cap.
- Retighten the load chains at the bail nuts (3) on the outer mast.
- Replace the (2) safety cap.
- Apply Loctite to the cap screw (1) and tighten.

- Unscrew the cap screw (4) and remove the safety (6) cap. ▷

- With the lift cylinders fully extended, retighten the middle load chains at the tensioning nuts (5) until the centre of the middle fork carriage support roller is 15 mm below the upper edge of the inner mast.

Stop always between lift cylinder and piston.

- Replace the (6) safety cap.
- Apply Loctite to the cap screw (4) and tighten.




## Maintenance as required

**Lubricating the lift mast and roller track**

- Remove dirt and lubricant residue from the roller track.
- Lubricate the roller tracks (1) of the outside, middle, and inside mast with a super-pressure adhesion lubricant to reduce wear. See → Chapter "Maintenance data table", P. 6-165.

**NOTE**

*Spray the roller track evenly from a distance of approx. 15-20 cm. Wait approx. 15 minutes until the equipment is ready to use again.*

**Servicing the restraining belt****⚠ DANGER****Malfunctions result in an increased risk.**

Do not use the forklift truck with a defective restraining belt. Have the belt replaced immediately.

Only have a defective belt replaced by your customer service office.

Only use genuine spare parts for repairs.


Do not make any changes to the belt.

**NOTE**


*Conduct the following checks regularly (monthly). In the case of significant strain, a daily check is necessary.*

### Checking the restraining belt

- Remove the belt (3) and check it for wear. The belt may not be frayed or cut. The stitching may not be loose.
- Check that the belt is not dirty.
- Check whether parts are worn or damaged, including the attachment points.



- Check the buckle (1) for proper locking. When the belt latch (2) is inserted, the belt must be held securely. The belt latch (2) must release when the red button (4) is pushed.
- The automatic blocking mechanism must be tested at least once a year:
  - Park the forklift truck on level ground.
  - Pull out the belt with a jerk. The automatic blocking mechanism must block extension of the belt.
  - Tilt the seat at least 30°, to do this tilt the bonnet.
  - Slowly extend the belt. The automatic blocking mechanism must block extension of the belt.



### Cleaning the belt

- Clean the belt as needed (brush is sufficient).

### Replacement after accident

As a rule, the restraining belt must be replaced after an accident.

## Maintenance as required

## Check driver's seat

**⚠ WARNING**

Risk of injury!

- After an accident have the driver's seat checked with attached restraining belt and fastening .
- Check controls for proper functioning.
- Check condition of seat (e.g. for wear to upholstery) and reliable fastening to hood.

**⚠ WARNING**

Risk of injury!

- Have the seat repaired by Technical Service if damage is observed during checking.



## Replacing fuses

**⚠ DANGER**

**Risk of fire! Using the wrong fuses can result in lack of protection against short circuits.**

Only use fuses with the prescribed nominal current.


## Main fuse carrier

- Open the motor hood, see ⇒ Chapter "Open the motor hood.", P. 5-53.

**NOTE**

*The main fuse carrier is positioned to the right of the valve block.*

- Open the cover fastenings (1) and remove the cover.
- Replace the defective fuse, fuse assignment see ⇒ Chapter "Fuse assignment in main fuse holder", P. 7-231.
- Push down the cover until the cover fastenings (1) snap back into place.
- Close the motor hood.




### Additional equipment for fuse carrier


- Undo the fixing screws (2) of the front cover and remove the cover (3).

#### NOTE

*The fuse carrier additional equipment is positioned on the right-hand side on the outside.*



- Open the cover fastenings (4) and remove the cover.
- Replace the defective fuse, fuse assignment see ⇒ Chapter "Fuse assignment special equipment", P. 7-232.
- Push down the cover until the cover fastenings (4) snap back into place.
- Refit the cover (3) and tighten the fixing screws (2).



## Maintenance as required


**Attachment maintenance**

- Lubricate the slide rails of attachments (special equipment), such as a sideshift or clamp according to the maintenance data table. See ⇒ Chapter "Maintenance data table", P. 6-165 appears on the display.

The diagram shows a clamp.

**NOTE**

*Observe the manufacturer's maintenance specifications.*



## 1000-hour maintenance/annual maintenance

### Other tasks

- Carry out the services of the maintenance as required, see ⇒ Chapter "Maintenance as required", P. 178.

### Maintenance of drive axle

#### Drive axle, checking oil level



#### ⚠ WARNING

Consumables are toxic!

Observe the safety regulations for handling brake fluid, see ⇒ Chapter "Oils", P. 3-29.


- Park the forklift on a level surface.
- Unscrew the checking (1) screw.

The oil level must reach the lower edge of the bore.

- Unscrew the filling plug, if necessary, (2) and fill with oil as per the maintenance data table; see ⇒ Chapter "Maintenance data table", P. 6-165 until it escapes from the hole for the checking screw (1).
- Renew the sealing ring on the oil drain plug (1).
- Tighten the oil checking screw (1) with a torque of 10 Nm.
- Renew the sealing ring on the oil drain plug (2).
- Tighten the oil drain plug (2) with a torque of 24 Nm.
- Check the oil level at both wheel drives.

#### Checking the drive axle for leaks

- Inspect the power unit for leaks (traces of oil).




7071\_003-076

## 1000-hour maintenance/annual maintenance

**Adjusting the parking brake**

- Open the bonnet; see ⇒ Chapter "Open the motor hood.", P. 5-53.
- Adjust the parking brake switch (2) so that traction drive is switched off (1) when the parking brake control cable is pulled.
- Close the motor hood.

**Lubricating the parking brake lever bearing and ratchet**

- Lightly lubricate the parking brake lever bearing and ratchet according to the maintenance data table. See ⇒ Chapter "Maintenance data table", P. 6-165 appears on the display.

**Checking the counterweight attachment**

- Check the mounting screws of the counterweight on the frame to make sure they are secure.

**Changing the engine oil and filter**

- Open the motor hood, see ⇒ Chapter "Open the motor hood.", P. 5-53.


**⚠ WARNING**

Consumables are toxic!  
Observe the safety regulations for handling engine oil, see ⇒ Chapter "Oils", P. 3-29.


**i** NOTE

*Change oil only when motor is at operating state temperature.*

- Open the floor opening in the chassis.
- Place a suitable collection vessel under the drain plug (1). ▷
- Unscrew the drain plug (1) and allow the oil to drain off completely.
- Replace the sealing ring (2).
- Tighten the drain plug to 30 Nm.




- Unscrew the oil filter lid (3).
- Replace the oil filter insert (5). ▷
- Replace the O-rings (4).
- Screw on the oil filter cover (3) and hand-tighten.



## 1000-hour maintenance/annual maintenance

- Unscrew the oil filter cover (6) and fill with new engine oil according to the maintenance table, see ⇒ Chapter "Maintenance data table", P. 6-165.
- Start the engine, allow to run for a short while and turn off again.
- Check the engine oil level, see ⇒ Chapter "Checking the engine oil level", P. 5-54.
- Close the motor hood.




## Checking the ribbed V-belt


 NOTE

*If damage is found, the ribbed V-belt has to be replaced to prevent failures or functional errors.*

- Manually turn the engine and check the ribbed V-belt (1) for:
  - Support tears (tear, core breaks, cross-sectional breaks)
  - Layer separation (cover layer, anchor bars)
  - Broken support
  - Frayed anchor bars
  - Flank wear (material wastage, frayed flanks, flank hardening, surface tears)



## Checking the toothed belt

### ⚠ CAUTION

The engine can be seriously damaged in the event of non-compliance!


If damage is detected, the toothed belt must be replaced.

- Remove the toothed belt cover.
- Manually crank the engine and check the toothed belt for damage.

### **i** NOTE

*A special tool is required for replacing the toothed belt. Contact STILL service personnel if necessary.*

- Reattach the tooth belt cover.



## Replacing the fuel filter



### ⚠ WARNING

Working materials are toxic.


Observe the safety regulations when handling Diesel fuel, see ⇒ Chapter "Diesel fuel", P. 3-30.

- Open the bonnet, see ⇒ Chapter "Open the motor hood.", P. 5-53.
- Hold a suitable collection vessel under the fuel filter (1).
- Unscrew the fuel filter (1).

### **i** NOTE

*A second fuel filter (special equipment) can be installed. The water must be drained from both filters.*

- Wet the sealing surface of the new fuel filter with Diesel fuel and tighten the filter by hand.
- Start the engine, see ⇒ Chapter "Start the engine", P. 5-62.
- Check the fuel filter for leaks.



## 1000-hour maintenance/annual maintenance

- Close the bonnet.

### Replacing the fuel filter for Eberspächer exhaust gas cleaners




#### ⚠ WARNING

Consumables are toxic!

Note safety regulations for working with diesel fuel; see → Chapter "Diesel fuel", P. 3-30.

- Remove and replace the fuel filter (2) for the exhaust gas cleaner by releasing the clips (1).



7071\_003-080

### Checking the exhaust gas system

- Inspect the exhaust gas system for external damage, secure fit, and leaks.

### Checking the heating system for leaks

- Use a testing device to check the cooling and heating system (special equipment) for leaks.



#### NOTE

*A special tool is necessary for the test. Contact STILL service personnel.*

### Check lift cylinders and connections for leaks. ▷


- Lift the fork carriage and secure against accidental lowering.

#### ⚠ WARNING

Risk of injury!

Observe the safety regulations for working on lift masts, see ⇒ Chapter "Working at the front of the forklift truck", P. 6-170.

- Check hydraulic connections and lift cylinders for leaks (visual inspection).
- Tighten leaking screw joints, repair leaking hydraulic cylinders.



### Maintain lifting system ▷

- Check bearings for wear and clearance.
- Check chain roller bearings, support roller bearings on lift mast and fork carriage for clearance, condition and secure positioning.
- Bearings are lubricated for life, and are maintenance-free. Replace in the event of damage, excessive clearance or stiffness.

#### ⚠ WARNING

Risk to stability!

No deliberate change in the tilt angle is permitted.

Readjustment after replacement or repair of tilt cylinders only permitted by your service centre!



## 1000-hour maintenance/annual maintenance

**Check lateral clearance (Y)**

- Cant fork carriage in mast guide.
- Measure clearance between mast cross-piece and support roller with feeler gauge.

Permissible lateral clearance (Y):

**min. 0.1 mm**

**max. 0.3 mm** (at narrowest point)



**max. 1.1 mm** (at any other point)

**Check bearing clearance (X)**** NOTE**

*Before this check, make sure that the lateral clearance (Y) complies with the specified tolerances.*

- Park vehicle on a flat surface and lift fork carriage.
- Position parallel base at tips of fork arms.
- Lower fork carriage onto this base.
- Measure clearance between support roller and lift mast bearing surface with feeler gauge.

**Bearing clearance (X): max. 0.6 mm**




### Checking play between fork carriage stop and run-out stop ▷

#### NOTE

Perform the check after adjustments to the load chains. See ⇒ Chapter "Load chain maintenance", P. 6-195.

- Extend the fork carriage completely to the stop in the lift cylinder.
- Use the feeler gauge to check the clearance between the fork carriage stop and roller of the run-out stop (3).

**Clearance: at least 2 mm**



6210\_800-019


### Checking the fork arms ▷

- Check the fork arms (1) for visible deformations. The wear may not exceed 10% of the original strength.

#### CAUTION

Worn fork arms must always be repaired as a pair.

- Check the fork latch (3) function.
- A locking screw (2) against falling out must be available.




7094\_842-001

## 1000-hour maintenance/annual maintenance

**Checking reversible fork arms**** NOTE**

*This check is only required for reversible fork arms (special equipment).*

- Check the outside of the fork bend (1) for cracks. Please contact the service centre.



## 3000-hour maintenance/two-year maintenance

### Work that must also be carried out

- Carry out maintenance work as necessary, see ⇒ Chapter "Maintenance as required", P. 178.
- Carry out 1000 hour maintenance, see ⇒ Chapter "1000-hour maintenance/annual maintenance", P. 203.

### Changing the gear lubricant oil



#### ⚠ WARNING

Consumables are toxic!  
Observe the safety regulations for handling gear lubricant oil, see ⇒ Chapter "Oils", P. 3-29.


- Park the forklift on a level surface.
- Raise the truck on blocks, see ⇒ Chapter "Raising and jacking up", P. 6-168.
- Remove the wheels from the drive axle.
- Place a suitable collection vessel under the oil drain plug (5).
- Unscrew the oil drain plug (5) and allow the oil to drain out completely.



#### ENVIRONMENT NOTE


*Dispose of used oil according to applicable regulations.*

- Replace the sealing ring on the oil drain plug (5).
- Tighten the oil drain plug (5) to a torque of 24 Nm.



## 3000-hour maintenance/two-year maintenance

- Unscrew the checking (1) screw.
- Unscrew the filling plug (2) and fill with oil as per the maintenance data table (see ⇒ Chapter "Maintenance data table", P. 6-165) until it escapes from the hole for the checking screw (1).
- Replace the sealing ring on the oil drain plug (1).
- Tighten the oil drain plug (1) to a torque of 10 Nm.
- Replace the sealing ring on the oil drain plug (2).
- Tighten the oil drain plug (2) to a torque of 24 Nm.
- Change the gear lubricant oil of both wheel drives.
- Re-fit the wheels to the drive axle; for tightening values see ⇒ Chapter "Maintenance data table", P. 6-165.




### Checking the wheel bearing

- Check the wheel bearing for excessive play, stiffness, damage, and wear.

Have STILL service personnel replace parts in the event of play or wear.

### Checking the engine mountings

- Check all engine mountings for security and wear, and replace them if necessary.




## Replacing the toothed belt

- Replace the toothed belt of the engine.

**i** NOTE

*This requires a special tool. Contact STILL service personnel.*





## 6000-hour maintenance

### Work that must also be carried out

- Carry out maintenance work as necessary, see ⇒ Chapter "Maintenance as required", P. 178.
- Carry out 1000 hour maintenance, see ⇒ Chapter "1000-hour maintenance/annual maintenance", P. 203.
- Carry out 3000 hour maintenance, see ⇒ Chapter "3000-hour maintenance/two-year maintenance", P. 213.

### Replacing the hydraulic oil and filter

#### **WARNING**

Hydraulic oils are hazardous to your health and are under pressure during operation.


Note safety regulations for working with hydraulic oils; see ⇒ Chapter "Hydraulic fluid", P. 3-32.

### Replacing the hydraulic oil and filter


- Position forklift truck on level ground.
- Tilt mast back.
- Lower forks; if there are attachments, run in working cylinder.
- Switch off the engine.
- Open the bonnet; see ⇒ Chapter "Open the motor hood.", P. 5-53.

## 6000-hour maintenance

- Unscrew the (1) hydraulic oil filter cover.



- Unscrew the hydraulic oil drain plug (2) under the hydraulic oil tank; direct the hydraulic oil into a collection vessel.


**ENVIRONMENT NOTE**

*Dispose of used oil according to applicable regulations.*

- Screw in drain plug (2) with a new seal and tighten.
- Remove the old filter insert from the filter cover and (1) dispose of it.
- Install a new filter insert.
- Fasten (1) the filter cover.

**Tightening torque: 30 Nm**

- Unscrew (1) the dipstick 1 and remove it.
- Pour new hydraulic oil according to the maintenance data table into the dipstick opening, see → Chapter "Maintenance data table", P. 6-165.
- Reinsert (1) the dipstick and tighten it.



## 6000-hour maintenance

**Bleeding lift cylinders**

Tele-Mast design:

- Loosen the hexagonal head screw (4) in the lift cylinder head a half to one turn

Hi-Lo mast and triple mast:

- Loosen the hexagonal (5) head screw on the cylinder head of the middle cylinder and the hexagonal head screws (4) on the lift cylinder heads of the outer cylinder by half to one full rotation.

**NOTE**

*Do not unscrew too far!*

- Load the fork arms and actuate the "lift-lower" operating lever carefully until oil escapes from the bleeder screws without bubbles.
- Retighten bleeder screws.

**Venting the tilt cylinder**



- Tilt the mast forwards and backwards several times until it is up against the stop.

The tilt cylinders bleed themselves automatically.

**Bleeding the steering system**

- Turn the steering wheel several times from stop to stop.

The steering system bleeds itself automatically.



## 9000-hour maintenance/five-year maintenance

### Work that must also be carried out

- Carry out maintenance work as necessary, see ⇒ Chapter "Maintenance as required", P. 178.
- Carry out 1000 hour maintenance, see ⇒ Chapter "1000-hour maintenance/annual maintenance", P. 203.
- Carry out 3000 hour maintenance, see ⇒ Chapter "3000-hour maintenance/two-year maintenance", P. 213.

### Changing the coolant

#### **WARNING**

Coolant and coolant additive are hazardous to your health.

Please observe safety regulations when working with coolant, see ⇒ Chapter "Coolant", P. 3-33.

### Draining the coolant

- Remove covering from the back, see ⇒ Chapter "Removing and installing the rear cover", P. 6-173.


#### **WARNING**

Risk of scalding!

Only open the lid of the expansion tank when the engine has cooled down.

## 9000-hour maintenance/five-year maintenance


- Open the lid slowly (1) and allow the pressure to drop. ▷
- Open the bonnet; see ⇒ Chapter "Open the motor hood.", P. 5-53.
- Place a sufficiently large collection vessel under the engine.




- Open the clip (3) and remove the hose. ▷
- In addition to draining the coolant from the engine, remove the connection spigot together with the coolant regulator (arrowed).

**ENVIRONMENT NOTE**

*Dispose of the coolant properly.*

**Topping up the coolant**

- Rotate the coolant regulator (7) 90° anti-clockwise and remove it from the (5) connection spigot. ▷
- Replace the sealing ring (6) and wet it with coolant.
- Insert the coolant regulator (7) into the connection spigot (5) and rotate it 90° clockwise.
- Re-fit the connection spigot (5) with the coolant regulator (7) into the engine block.
- Tighten the securing bolts (4) with a torque of 15 Nm.



- Re-attach the coolant hose to the connection spigot (5). Check that the clip is properly seated.

**i NOTE**

*Only use coolant additive according to the manufacturer's guidelines.*


- Refill with coolant; for mixture ratio see ⇒ Chapter "Topping up coolant and checking coolant concentration", P. 6-178.

**⚠ CAUTION**

Coolant additive with a different specification must not be mixed in!

- Use coolant additive and anti-corrosion agent as shown in the maintenance data table, see ⇒ Chapter "Maintenance data table", P. 6-165.

- Screw the lid back on again (1) tightly.
- Start the engine; see ⇒ Chapter "Start the engine", P. 5-62.
- Run the engine at approx. 1500 rpm for a maximum of two minutes.
- Check the coolant level again.
- Close the engine hood.
- Re-attach the rear cover.



7071\_003-045




7

---

## Technical data

## Dimensions

## Dimensions



7071\_003-024

The customer-specific dimensions for dimensions h1, h3, h4, h6 and b1 can be found in your order acknowledgement.

**Centre of gravity S (distance from front axle)**

R70-40	1123 mm
R70-45	1139 mm
R70-50	1159 mm

## VDI datasheet

### NOTE

Provisional values valid for the standard device. Variants may deviate from them.

### Characteristics

		R70-40	R70-45	R70-50
Manufacturer		STILL	STILL	STILL
Drive: electric, diesel, petrol, LPG, mains electric		Diesel	Diesel	Diesel
Operation: manual, accompanied, stand, seated, order picking		Seat	Seat	Seat
Capacity/load	Q (kg)	4000	4500	4999
Load centre of gravity	c (mm)	500	500	500
Load distance	x (mm)	540	540	540
Wheelbase	y (mm)	2005	2005	2005

### Weight

		R70-40	R70-45	R70-50
Tare weight	kg	5800	6086	6395
Axle weight with front/rear load	kg	8627/1173	9462/1124	10290/1105
Axle weight without front/rear load	kg	2552/3248	2628/3458	2697/3698

### Wheels, frame

		R70-40	R70-45	R70-50
Tyres: superelastic (SE), solid rubber (V), pneumatic (L)		SE	SE	SE
Front wheel size		250-15	28x12.5-15	28x12.5-15
Rear wheel size		250-15	250-15	250-15
Wheels, number front/rear (x = driven)		2x/2	2x/2	2x/2
Track width: front	b 10 (mm)	1136	1210	1210
Track width: rear	b 11 (mm)	1120	1120	1120

## VDI datasheet

## Basic dimensions

		R70-40	R70-45	R70-50
Tilt lift mast/fork carriage forwards/backwards	Degree	6/8	6/8	6/8
Height with lift mast retracted	h1(mm)	2400	2400	2400
Free lift	h2 (mm)	160	160	160
Lift height	h3(mm)	3180	3180	3180
Height with lift mast extended	h4(mm)	4187	4187	4187
Height to top of overhead guard	h6 (mm)	2300	2300	2300
Sitting height	h7(mm)	1176	1176	1176
Coupling height	h10 (mm)	493	493	493
Total length	l1 (mm)	4027	4085	4130
Length including fork back	l2 (mm)	3027	3085	3130
Maximum length	b1	1380	1506	1506
Fork arm dimensions	s/e/l (mm)	50/120/1000	50/120/1000	50/150/1000
Fork carriage according to ISO 2328 Class/Form A, B		Category III/Form A	Category III/Form A	Category III/Form A
Fork carriage width	b3 (mm)	1310	1310	1410
Floor clearing with load under lift mast	m1 (mm)	140	140	140
Ground clearance centre of wheelbase	m2 (mm)	165	165	165
Working width for pallet 1000 x 1200 transverse	Ast (mm)	4418	4470	4510
Working width for pallet 800 x 1200 longitudinal	Ast (mm)	4618	4670	4710
Turning radius	Wa (mm)	2678	2730	2770
Smallest pivot point distance	b13 (mm)	680	680	680

## Performance data

		R70-40	R70-45	R70-50
Truck speed with/without load	km/h	21/21	21/21	21/21
Lifting speed with/without load min. fan speed	m/s	0.56/0.60	0.54/0.58	0.47/0.51

		R70-40	R70-45	R70-50
Lowering speed with/without load	m/s	0.56/0.55	0.54/0.51	0.54/0.51
Pulling force with/without load	N	22150/19000	22000/19550	21870/20040
Climbing capability with/without load	%	22/34	20/33	18/32
Acceleration time with/without load	S.	5.3/4.9	5.3/4.9	5.3/4.9
Service brake	S.	Mechanical	Mechanical	Mechanical

### Switching off

		R70-40	R70-45	R70-50
Engine manufacturer/model		VW/CBJ	VW/CBJ	VW/CBJ
Engine output as per ISO 1585	kW	55	55	55
Rated rpm	1/min	2400	2400	2400
Maximum torque	Nm	247	247	247
Number of cylinders/cubic capacity	cm <sup>3</sup>	4/2000	4/2000	4/2000
Fuel consumption according to VDI cycle	l/h	-	-	-

### Miscellaneous

		R70-40	R70-45	R70-50
Type of traction control		Stilltronic	Stilltronic	Stilltronic
Working pressure for equipment	bar	250	230	250
Oil volume for attachments	l/min	-	-	-
Noise level in driver's ear	dB (A)	78	78	78
Tow coupling, type/model		Bolt	Bolt	Bolt

## Wheels and tyres

## Wheels and tyres

## Permissible types of tyres

Only the tyre types listed can be used. We recommend consulting our customer service office before refitting.

## Tyres for R70-40

Comment	Tyre pressure (bar)	Tyres		Track (mm)		Mast type (height in mm)	
		front/rear	front	rear	front	rear	Tele
<b>Superelastic SIT tyres</b>							
Standard	-	250-15	250-15	1136	1120	up to 3250	up to 3200
Twin	-	7.00-15	250-15	1364	1120	up to 3250	up to 3200
Continental	-	250-15	250-15	1136	1120	up to 3250	up to 3200
<b>Pneumatic tyres</b>							
		250-15	250-15	1136	1120	up to 3250	up to 3200
Twin XZM	10/10	7.00-15	250-15	1364	1120	up to 3250	up to 3200
Michelin XZM	10/10	250-15	250-15	1136	1120	up to 3000	up to 2300

## Tyres for R70-45, R70-50

Comment	Tyre pressure (bar)	Tyres		Track (mm)		Mast type (height in mm)	
		front/rear	front	rear	front	rear	Tele
<b>Superelastic SIT tyres</b>							
Standard	-	28x12.5-15	250-15	1210	1120	up to 3250	up to 3200
Twin	-	7.00-15	250-15	1364	1120	up to 3250	up to 3200



## Fuse assignment


**i** NOTE

Depending on equipment, not all fuses will be present in your truck.

## Fuse assignment special equipment ▷

**i** NOTE

Depending on equipment, not all fuses will be present in your truck.




- F1 Fuse 5 A
- F2 Fuse 10 A
- F3 Fuse 10 A

## Circuit diagrams

## Hydraulics

## Hydraulics

## Hydraulic circuit diagram



7071\_003-063

1	Steering cylinder	10	4-way directional control valve block
2	Steering unit	11	Burst pipe protection
3	Priority valve	12	Lift cylinders
4	Variable pump	13	Tilt cylinder
5	Hydraulic oil tank	14	Lowering brake
6	Breather plug	15	Accumulator tank
7	Return line filter	16	Pressure reducing valve with housing
8	Suction screen	17	Fan motor
9	3-way directional control valve block		

## Electrical equipment

## Electrical equipment

## Legend for circuit diagrams

**NOTE**

*This legend applies to all possible equipment variants. Not all components/assemblies listed here have to be installed in your industrial truck.*

**General operating materials**

A1	Load balancing printed circuit board	F10	Fuse (control fuse)
A2	Charge controller	F11	Fuse for A2
A3	Throttle valve controller printed circuit board	G1	Battery
A4	Traction control unit	G2	Battery
A5	Contacteur stand	G3	Battery
A6	Fan motor printed circuit board	H1	Indicator light for S1
A7	Control fuse printed circuit board	H2	Engine/generator temperature light
A8	Special function printed circuit board	H3	Neutral position indicator light
A9	Digital truck central control unit	H4	General temperature indicator light
A10	Steering column printed circuit board	K1	Relay
A11	Field regulator	K2	Relay
A12	Protective circuit printed circuit board	R1	Resistor for A1
A13	Fuses/protective circuits printed circuit board	R2	Resistor
F1	Fuse (main fuse)	R3	Temperature sensor
F2	Fuse (control fuse)	S1	Key switch
F3	Fuse (control fuse)	S2	Battery - main switch
F4	Fuse (control fuse)	U1	Voltage transformer
F5	Fuse (control fuse)	U2	Voltage transformer
F6	Fuse (control fuse)	U3	Filter part
F7	Fuse (control fuse)	U4	Impedance converter
F8	Fuse (control fuse)	U5	not used
F9	Fuse (control fuse)	U6	AC-AC voltage transformer
		U7	Overcurrent protector

X1	Battery plug female half	1A6	Current sensor printed circuit board
X2	Battery plug male half	1A7	Start V-engine printed circuit board
X3	Connector plug for 1A1	1A10	Impulse control system
X4	Connector plug for 2A1		
X5	Connector plug for 1A2	1B1	Accelerator
X6	Connector plug for 1A4	1B2	Brake transmitter
X7	Connector plug for 6A1	1B3	2-pedal potentiometer
X8	Terminal rail for G1	1B4	2-pedal potentiometer
X9	Connector plug for 6A3 - standard discharge indicator	1C1	Quenching capacitor
X10	Connector plug for 6A3 - discharge indicator with switch-off		
X11	Connector plug for A9	1F1	Fuse for 1M1
X12	4-way traction motor connector plug	1F2	Fuse for 1M2
X13	6-way traction motor connector plug	1F3	Fuse
X14	4-way pump motor connector plug	1F11	Fuse
X15	6-way pump motor connector plug	1F12	Fuse
X16	Accelerator connector plug	1F13	Fuse
X17	Field connections for A9		
X18	CAN bus plug for A9	1G1	Generator
X19	CAN bus plug for A9		
		1K1	Main contactor
		1K2	Braking contactor
X99	not used	1K3	not used
		1K4	Auxiliary contactor
Z1	Protective circuit	1K5	Safety relay for 1K1
		1K6	Relay for S1
		1K7	Relay for ignition
		1K8	Safety relay monitoring
		1K9	Bridge contactor
		1K10	not used
		1K11	Forwards motion contactor
		1K12	Reverse motion contactor

### Traction drives

1A1	Traction control printed circuit board
1A2	Output stage
1A3	Biasing current excitation printed circuit board
1A4	Field control printed circuit board
1A5	Retardation printed circuit board

## Electrical equipment

1K21	Forwards motion contactor	1S3	Parking brake switch
1K22	Reverse motion contactor	1S4	Parking brake switch
1K23	Relay for forwards motion switch-off	1S5	Cornering switch
		1S6	Cornering switch
1L1	Charge reversal throttle	1S7	Cornering switch
1L2	Throttle	1S8	Cornering switch
1L3	Throttle	1S9	Traction safety switch
		1S10	Reversing button
1M1	Right traction motor	1S11	Safety switch for 1S10
1M2	Left traction motor (or 1 motor drive)	1S12	Brake switch
		1S13	Switch for 2nd braking stage
1R1	Series resistor for 1A1	1S14	Step switch
1R2	Rotational angle detector (accelerator)	1S15	Travel direction zero position switch
1R3	Resistor for monitoring	1S16	Accelerator switch
1R4	Resistor for monitoring		
1R5	Resistor	1T1	Charging current switch
1R6	Potentiometer for speed restriction		
1R7	not used	1U1	Traction current actual-value sensor
1R8	not used		
1R9	not used	1V1	Main thyristor traction control
1R10	Excitation resistor for electric braking	1V2	Gate turn-off thyristor traction control
1R11	Resistor for 2nd braking stage	1V3	Charge reversal thyristor traction control
1R12	Brake resistor	1V4	Free-wheeling diode traction control
1R13	Brake resistor	1V5	Brake diode
1R14	Stabilising resistor	1V6	Brake diode
1R15	not used	1V7	Brake diode
1R16	Resistor	1V8	Charge reversal diode
1R17	Temperature sensor	1V9	Charging diode
1R18	Excitation resistor for electric braking	1V10	Diode
		1V11	Diode
1S1	Forwards travel direction switch	1V12	Diode
1S2	Backwards travel direction switch	1V13	Diode

1V14 Diode	2B1 Lift sensor
1Z1 Protective circuit for 1V1	2B2 Tilt sensor
1Z2 Protective circuit for 1V2	2B3 Auxiliary hydraulic sensor 1
1Z3 Protective circuit for 1V3	2B4 Auxiliary hydraulic sensor 2
1Z4 Protective circuit for 1V4	2B5 Auxiliary hydraulic sensor 3
1Z5 Protective circuit for 1V5	2B6 Retarder
1Z6 Protective circuit for 1V6	2C1 Quenching capacitor
1Z7 Protective circuit for 1V7	2F1 Fuse for 2M1
1Z8 Protective circuit for 1V8	2F2 Fuse for 2M2
1Z9 Protective circuit for 1V9	2F11 Fuse
1Z11 Protective circuit for 1K11	2F12 Fuse control circuit
1Z12 Protective circuit for 1K12	2K1 Pump contactor
1Z13 Protective circuit for 1K1	2L1 Charge reversal throttle
1Z14 Protective circuit for 1K2	2L2 Throttle
1Z20 Protective circuit printed circuit board	2L3 Throttle
1Z21 Protective circuit for 1K21	2M1 Pump motor
1Z22 Protective circuit for 1K22	2M2 Pump motor
1Z23 Protective circuit	2R1 Series resistor for 2A1
1Z24 Protective circuit	2R2 Lift rotational angle detector
1Z25 Protective circuit	2R17 Temperature sensor
1Z26 Protective circuit	
1Z27 Protective circuit	
1Z28 Protective circuit	
1Z29 Protective circuit	
1Z30 Protective circuit	

### Hydraulic drives for moving load

2A1 Pump control printed circuit board	2S1 Lift switch
2A6 Current sensor printed circuit board	2S2 Tilt switch
2A7 Proportional technology control unit	2S3 Auxiliary hydraulic switch 1
	2S4 Auxiliary hydraulic switch 2
	2S5 Lift end limit switch

**Electrical equipment**

2S6 Lift end limit switch  
 2S7 Lift end limit switch  
 2S8 Lift end limit switch

2T1 Charging current transformer

2U1 Pump current actual-value sensor

2V1 Main thyristor pump control  
 2V2 Gate turn-off thyristor pump control  
 2V3 Charge reversal thyristor pump control  
 2V4 Free-wheeling diode pump control

2X1 42-way SAAB connector plug  
 2X2 Hydraulic control unit CAN bus plug  
 2X3 Hydraulic control unit CAN bus plug

2Y1 Directional control solenoid valve (lift)  
 2Y2 Directional control solenoid valve (lower)  
 2Y3 Directional control solenoid valve (tilt)  
 2Y4 Directional control solenoid valve (tilt)

2Y5 Auxiliary hydr. directional control solenoid valve 1

2Y6 Auxiliary hydr. directional control solenoid valve 1

2Y7 Auxiliary hydr. directional control solenoid valve 2

2Y8 Auxiliary hydr. directional control solenoid valve 2

2Y9 Release valve

2Y10 Valve on fork carriage

2Z1 Protective circuit for 2V1

2Z2 Protective circuit for 2V2  
 2Z3 Protective circuit for 2V3  
 2Z4 Protective circuit for 2V4

**Auxiliary drives**

3A1 Power-assisted steering control unit  
 3A2 Control motor injection pump printed circuit board

3B1 Steering transmitter

3C1 Quenching capacitor

3F1 Fuse for 3M1

3F2 Fuse for 3M2

3K1 Steering motor contactor

3K2 Compressor contactor

3M1 Power-assisted steering motor

3M2 Compressor motor

3M3 Control motor injection pump

3S1 Air supply switch

**Signal devices**

4A1 not used

4F1 Fuse

4F2 Fuse

4H1 Alarm horn

4H2 Buzzer

4K1	Horn relay	5E20	Left rotating signal beacon
4S1	Horn button	5E21	Right rotating signal beacon
4V1	Diode for 9H2	5E22	Middle rotating signal beacon
4Z1	Protective circuit for 4H1 (capacitor)	5E23	Rotating signal beacon
4Z2	Protective circuit for 4H1 (diode)	5E24	Left reverse light
		5E25	Right reverse light
		5E26	Left corner marker light
		5E27	Right corner marker light
		5E28	Rear searchlight
		5E29	Rear searchlight
		5E30	Middle front searchlight

### Lighting

5C1	Capacitor	5F1	Fuse for right headlight
5E1	Right headlight	5F2	Fuse for left headlight
5E2	Left headlight	5F3	Fuse for right parking light
5E3	Right rear light	5F4	Fuse for left parking light
5E4	Left rear light	5F5	Fuse for searchlight
5E5	Right side light	5F6	Fuse for brake light/wiper/rotating signal beacon
5E6	Left side light		
5E7	Right stop light	5F11	Fuse
5E8	Left stop light	5F12	Fuse
5E9	not used	5F13	Fuse
5E10	Front left direction indicator	5F14	Fuse
5E11	Front right direction indicator	5F15	Fuse
5E12	Rear left direction indicator	5F16	Fuse
5E13	Rear right direction indicator		
5E14	Left licence plate light	5H1	Direction indicator light
5E15	Right licence plate light	5H2	Vehicle direction indicator light
5E16	Reverse light	5H3	Trailer direction indicator light
5E17	Right searchlight	5H4	Trailer direction indicator light
5E18	Left searchlight	5H5	Right corner marker light
5E19	Interior lighting	5H6	Left corner marker light

## Electrical equipment

5H7	Lighting indicator light
5H8	Lighting indicator light
5K1	Direction hazard warning light sensor
5K2	Relay for reverse light
5K3	Relay for trailer socket
5K4	Relay for trailer socket
5K5	Relay for trailer socket
5K6	Pulse generator for reverse light
5K7	Relay for reverse light
5K8	Relay for stop light
5K9	Relay for front searchlight
5L1	Throttle
5R1	Series resistor for 5K2
5S1	Light switch
5S2	Warning light switch
5S3	Direction indicator switch
5S4	Left searchlight switch
5S5	Right searchlight switch
5S6	Rotating signal beacon switch
5S7	Brake light switch
5S8	Reversing light switch
5S9	Rear searchlight switch
5S10	Brake light switch
5V1	Diode
5V2	Diode
5V3	Diode

## Measurement and display devices

6A1	Carbon brush monitor printed circuit board
6A2	Carbon brush monitor printed circuit board
6A3	Discharge indicator printed circuit board
6A4	Impulse transmitter printed circuit board
6A5	Start delay printed circuit board
6A6	Carbon brush monitor printed circuit board
6B1	Oil temperature sensor
6B2	Coolant temperature sensor
6B3	Fuel level sensor
6B4	Glow plug indicator sensor
6B5	Jetronik sensor
6B6	Jetronik air-flow sensor
6B7	Tachometer generator
6B8	Lambda sensor
6B9	Speed sensor
6B10	Tachometer generator
6B11	Coolant temperature sensor
6B12	Coolant level sensor
6B13	Lambda sensor
6B14	Coolant temperature sensor (rev. air duct)
6B15	Impulse transmitter for 6P4
6B16	Start volume transmitter
6B17	Speed sensor for 1M1
6B18	Carbon brush monitor for M2
6B19	Carbon brush monitor for G1
6F1	Fuse for indicator lights

6H1	Coolant temperature light	6P6	Oil temperature indicator
6H2	Oil pressure warning light	6P7	Oil pressure indicator
6H3	Fuel level lamp	6P8	Fuel level indicator
6H4	Glow filter indicator light	6P9	Wheel base indicator
6H5	Air filter indicator light	6P10	Speed indicator
6H6	Carbon brush indicator light for 1M1	6P11	Ammeter indicator
6H7	Carbon brush indicator light for 1M2	6P12	Discharge indicator/hour meter
6H8	Carbon brush indicator light for 2M1	6P13	Carbon brush wear indicator
6H9	Carbon brush indicator light for 3M1	6S1	Oil pressure warning switch
6H10	General carbon brush indicator light	6S2	Air filter indicator switch
6H11	Brake fluid indicator light	6S3	Oil pressure switch
6H12	Start indicator light	6S4	Brake fluid switch
6H13	Catalytic converter indicator light	6S5	Motor blower monitoring switch
6H14	Motor blower indicator light	6S6	Engine temperature switch
6H15	Engine temperature indicator light	6S7	Soot filter indicator switch
6H16	Soot filter indicator light (gn)	6S8	Reset switch for carbon brush wear indicator
6H17	Soot filter indicator light (rd)	6S9	Oil filter switch
6H18	Indicator light at 6 km/h		
6H19	Mast vertical position indicator		
<b>Special functions</b>			
6K1	Relay for oil pressure	7A1	Printed circuit board for parking brake signal transmitter
6K2	Relay for oil pressure		
6K3	Relay for coolant light	7B1	Lift mast sensor
6K4	Relay for coolant light		
6K5	Relay for hour meter	7F1	Fuse
		7F2	Fuse
6P1	Operating hour meter		
6P2	Operating hour meter	7H1	Indicator light for 1S3
6P3	Discharge indicator	7H2	Warning signal transmitter
6P4	Milometer		
6P5	Coolant temperature indicator	7K1	Relay for warning signal

**Electrical equipment**

7K2	Emergency cut-off contactor
7K5	Dead man relay (lift)
7K6	Dead man relay (traction)
7K7	Relay for seat contact
7S1	Seat contact switch
7S2	Emergency switch
7S3	Battery locking switch
7S4	Temperature switch
7S5	Temperature switch
7S6	Temperature switch
7S7	Temperature switch
7S8	Temperature switch
7S9	Temperature switch
7S10	Temperature time switch
7S11	External start switch
7S12	Warning signal switch
7S13	Dead-man switch
7S14	Emergency start switch
7S15	Switch for solenoid valve
7V8	Diode for solenoid valve
7X1	Pilot contact
7X11	Connector for external start
7Y8	Left solenoid valve (fork carriage)
7Y9	Right solenoid valve (fork carriage)

**Automated functions**

not assigned

**Miscellaneous**

9A1	Control unit for ignition
9A2	Shut-down solenoid printed circuit board
9A3	Jetronik control unit
9A4	Generator start/carbon brush monitor printed circuit board
9A5	Lambda control system control unit
9A6	Protective circuit printed circuit board
9A7	2-pedal printed circuit board with shut-down device
9A8	2-pedal printed circuit board with fuse
9A9	Soot burner control
9A10	Control unit heater
9B1	Thermocouple for soot burner
9B2	Temperature switch for heater
9C1	Capacitor
9E1	Spark plug
9E2	Spark plug
9E3	Spark plug
9E4	Spark plug
9E5	Spark plug
9E6	Spark plug
9E7	Spark plug
9E8	Spark plug
9E9	Ignition distributor
9E10	Heater blower
9E11	Defroster blower
9E12	Seat heater
9E13	Sheathed-element heater plug
9E14	Sheathed-element heater plug

9E15	Sheathed-element heater plug	9H4	Indicator light for 9S4
9E16	Sheathed-element heater plug	9H5	GREEN soot burner indicator
9E17	Sheathed-element heater plug	9H6	RED soot burner alarm
9E18	Auxiliary heater	9H7	Soot burner diagnostic LED
9E19	Passenger seat heater	9H8	Soot burner signal transmitter
9E20	Defroster blower		
9E21	Cigar lighter	9K1	External start contactor
9E22	Sheathed-element heater plug for soot burner	9K2	Relay for 9M1
		9K3	Glow plug relay
9F1	Fuse for lambda control system	9K4	Relay for ignition
9F2	Fuse for ignition	9K5	Starter lockout relay
9F3	Fuse for charge controller	9K6	Starter lockout relay
9F4	Fuse for starter	9K7	Relay for 9E11
9F5	Fuse for 9E10	9K8	Auxiliary relay for diesel mode
9F6	Fuse for sheathed-element heater plugs	9K9	Auxiliary relay for diesel mode
9F7	Fuse for seat heater	9K10	Charging contactor
9F8	Fuse for radio	9K11	Auxiliary relay for diesel mode
9F9	not used	9K12	Auxiliary relay for diesel mode
9F10	not used	9K13	Auxiliary relay for 1A2
9F11	not used	9K14	Auxiliary relay for 1S9
9F12	Fuse for 12-volt starter	9K15	Relay for 9E20
9F13	Fuse for soot burner	9K16	Relay for 9Y5
9F14	Fuse for soot burner	9K17	Relay for 9M5/9M6
9F15	Fuse for soot burner	9K18	Relay for S1
9F16	Fuse for 9K26	9K19	Relay for 9Y4
9F17	Fuse for defroster	9K20	Relay for 9Y4
		9K21	Relay for soot burner operating indicator
9G2	Generator	9K22	Relay for soot burner operating indicator
		9K23	Relay for soot burner lock
9H1	Indicator light for 9S3	9K24	Relay for soot burner starter lockout
9H2	Generator indicator light	9K25	Current regulator for sheathed-element heater plug

## Electrical equipment

9K26	Relay for 9H8	9R9	Series resistor for sheathed-element heater plug
9K27	Relay for 9Y8	9R10	Series resistor for sheathed-element heater plug
9L1	Throttle for charge controller	9R11	Series resistor
9M1	Starter	9R12	Series resistor
9M2	Wiper motor	9R13	Resistor
9M3	Rear windscreen wiper motor	9R15	Series resistor for sheathed-element heater plug/soot burner
9M4	Defroster blower motor	9S1	Wiper switch
9M5	Fan motor	9S2	Rear windscreen wiper switch
9M6	Fan motor	9S3	Switch for 9E10
9M7	Injection pump motor	9S4	Switch for seat heater
9M8	Fuel pump	9S5	Switch for automatic charging
9M9	Control motor for lambda sensor	9S6	Temperature switch
9M10	Windscreen washer motor	9S7	Switch for 9E11
9M11	Rear window washer motor	9S8	Left door contact switch
9M12	Roof wiper motor	9S9	Right door contact switch
9M13	Blower for soot burner	9S10	Switch for 9E20
9M14	not used	9S11	Switch for soot filter
9M15	not used	9S12	Bonnet switch
9M16	Secondary fan elec. machine	9S13	Switch for 9M12
9M17	ASM circulating pump	9S14	Soot burner starting switch
9R1	Rotational angle detector for control motor	9S15	Soot burner emergency cut-off
9R2	Series resistor for external start system	9T1	Ignition coil
9R3	Heater resistor	9V1	Diode
9R4	Heater resistor	9V2	Diode
9R5	Series resistor	9V3	Diode
9R6	Varistor	9W1	Steering column slip ring
9R7	Series resistor		
9R8	Series resistor for sheathed-element heater plug		

9Y1	Cold-start valve	9Y7	Start valve for catalytic converter
9Y2	Idle stop valve	9Y8	Soot burner fuel injector
9Y3	Throttle valve solenoid		
9Y4	Solenoid valve for gas tank	9Z1	Protective circuit for thermostatic switch
9Y5	Shut-down solenoid	9Z2	Protective circuit for fan 9M5/9M6
9Y6	Actuator solenoid for automatic battery charging unit		



**A**

ABGASREINIGER (EXH. GAS PURIFIER) message	142
ACCELERATOR message	137
Accessories	
Overview	49
Accident recorder	124
Adjusting the steering column	59
After washing	176
AIR FILTER message	135
Assembling attachments	103
Attachment	
maintenance	202
Attachments	103–104
Control in general	105
Controlling using multi-lever controls	106
Fastening	103
Overview	49
Special risks	14
Taking up a load	107

**B**

Battery	
charging	184
Checking the charge state	184
Disposal	7
Maintenance	183
Battery acid	33
BRAKE SENSOR message	138

**C**

C. U. R. data	47
Cab	112
Cab doors	112
Carrying loading units	91
Carrying out work on the hydraulic equipment	167
Change direction of travel	
Single-pedal operation with multiple lever version	76
Changes to the forklift truck	23

Check coolant concentration	178
Check driver's seat	200
Check lift cylinders and connections for leaks	209
Checking	
the toothed belt	207
Checking play between fork carriage stop and run-out stop	211
Checking the counterweight attachment	204
Checking the engine mountings	214
Checking the engine oil level	54
Checking the exhaust gas system	208
Checking the fork arms	211
Checking the heating system for leaks	208
Checking the wheel bearing	214
Checking wheel fastenings	192
Cleaning the electrical system	175
Cleaning the truck	174
Condition of the driveways	73
Connections for attachments	
Depressurising	104
Consumables	29
Battery acid safety instructions	33
Coolant safety instructions	33
Disposal	34
Safety precautions for diesel fuel	30
Coolant	33, 178
changing	221
topping up	178
COOLANT LEVEL message	140
COOLANT TEMP message	141
Copyright and proprietary rights	4
Coupling	
the trailer	117
Crane lifting	
Attaching lifting slings	145
Determining loading weight	145
Loading truck	147
Crane loading	145
Cross-references	5
Cruise control	113

Currentness of manual	4	Driver's seat MSG 65/MSG 75	
<b>D</b>		Adjust lumbar support	58
Damage	24	Adjusting	56
Dangerous locations	73	Adjusting backrest extension	58
Defects	24	Adjusting the backrest	57
Definition of directions	6	Adjusting the seat suspension to your weight	57
Depositing and retrieving loading units	100	Moving	56
Depressurising		Switching seat heater on and off	59
Multi-lever operation	105	Drivers	20
Diagram of functional sequences	6	Driveways	72–73
Diesel engine emissions		Driving	
checking	26	on ascending and descending slopes	101
Diesel fuel	30, 163	Single-pedal operation with multiple lever version	74
filling up	149	Driving on lifts	101
Winter operation	163	Driving on loading bridges	102
Dimension of driveways	72	Driving on slopes	72
Dimensions	226	Driving with cruise control	113
Direction indicators	111	<b>E</b>	
Direction of travel/flasher/fault multi- function display	45	Eberspächer exhaust gas cleaners	
Display and operating unit	44	Replacing the fuel filter	208
Additional displays	120	Eberspächer particle filters	
Additional settings	124	servicing	187
Display settings and changes	120	EC declaration of conformity	2
Displays	120	EC mark of conformity	2
Fleet Manager functions	123	Emergencies	71
Normal displays	120	Emergency lowering	87
Resetting the daily number of kilometres and daily driving time	122	Emissions	35
Setting the language	122	Battery	37
Disposal		Diesel engine emissions (DME)	36
Battery	7	Exhaust gases	36
Units	7	Heat	36
Documentation scope	3	Noise emissions	35
Drive axle		Vibrations	35
check for leaks	203	Engine oil	
Check oil level	203	changing	204
Maintenance	203	Engine oil filter	
Driver's compartment		changing	204
Single pedal version	42	Error code table	126

Error messages		Indicator and operating unit	
Diagram	125	Setting the date or time	121
<b>F</b>		Information regarding performing	
Filling the washer system	55	maintenance	156 – 157
Flashing light	109	Instructions for washing	174
Fleet Manager functions	123	Insulation test	27
Floorplate	172	Insurance coverage on company	
Fork extension	86	premises	23
Forwards motion		Intervals for maintenance and inspection	159
Single-pedal operation with multiple		Issue date of manual	4
lever version	75		
Fuel filter		<b>J</b>	
Drain water	180	Jump starting	147
Functional sequences	6		
Fuse assignment		<b>L</b>	
Additional equipment	232	Label locations	
Main fuse holder	231	Overview	46
<b>G</b>		Lift mast	
Gear lubricant oil		Lubricating the roller track	198
changing	213	Lift mast versions	81
General	2	Lifting system	
<b>H</b>		Controls	84
Hazard area	91	Maintenance	209
Hazard warning system	110	Multi-lever operation	85
Hazards and countermeasures	16	Lifting system variants	81
Heater	113	Lighting	108
Hydraulic circuit diagram	234	Load	
Hydraulic fluid	32	taking up	94
Hydraulic system		Load chains	
Bleeding lift cylinders	220	checking	195
Changing the hydraulic oil filter	217	Cleaning	175
Check oil level	186	Lubrication	195
Checking for leaks	186	Maintenance	195
Maintenance	186	Loads	
Replace hydraulic oil	217	transport	97
Venting the tilt cylinder	220	Lubricating joints and controls	192
		Lubricating the parking brake lever	
<b>I</b>		bearing and ratchet	204
Impermissible use	10	<b>M</b>	
		Maintenance and lubrication	157
		Maintenance data table	165

Maintenance during the breaking-in period	177	OVERHEATING message	141
Maintenance plan	159	<b>P</b>	
Maintenance points overview	158	Packaging	7
Maintenance work for which no special qualifications are necessary	156	Park truck secured	150
Malfunction during a lifting operation	82	Parking brake	
Mast bearings		Adjusting the switch	204
Checking tightening torque	195	Check adjustment	183
Lubrication	195	Particle filter	
Maintenance	195	Operational requirements	27
Measures for prolonged shutdown, storage of truck	151	Place of use	11
Medical equipment	25	Prior to taking up a load	90
Message		Prohibition on use by unauthorised persons	21
BREMSE ANZIEHEN (APPLY HANDBRAKE!)	135	Proper use	10
LOWER FORKS	136	<b>Q</b>	
REFERENCE LIFT	137	Qualifications of personnel	156
SAFETY BELT	130	<b>R</b>	
SITZSCHALTER (SEAT SWITCH)	132	Radiator	
Mini-console	45	Checking for leaks	178
Misuse of safety devices	24	cleaning	178
MOT/GEN-TEMP message	139	Raising and jacking up	168
Multi-lever operation		Re placing the air filter insert	181
Lift, lower fork carriage	85	Rear cover	173
Tilt mast	85	Removing the lift mast	170
<b>N</b>		Replacing	
Nameplate	46	the fuel filter	207
Neutral position		the toothed belt	215
Single-pedal operation with multiple lever version	77	Replacing fuses	200
<b>O</b>		Resetting the daily number of kilometres and daily driving time	122
OIL PRESSURE message	140	Residual hazards, residual risks	13
Oils	29	Restraining belt	64
Open the motor hood	53	Fastening	65
Operating company	20	Fastening on a steep slope	65
Operating materials	165	Malfunctions due to cold	66
Quality and quantity	162	releasing	66
Operating the service brake	77	Retrofitting	23
Operating the signal horn	64	Returning to service after storage	152

Reverse motion	
Single-pedal operation with multiple lever version	76
Reversible fork arms	
checking	212
Reversible forks	86
Ribbed V-belt	
Checking condition and tension	206
Rights, duties and rules of behaviour for the driver,	21
Risk for employees	18
Rules for driveways and the working area,	73
<b>S</b>	
Safety check	26
Safety devices	167
Safety instructions for maintenance	
Raising and jacking up	168
Working at the front of the forklift truck	170
Safety instructions for working on the lift mast	
Removing the lift mast	170
Securing lift mast against tilting back	170
Securing the telescopic lift mast	170
Securing the triple lift mast	171
Safety regulations for maintenance	
Carrying out work on the hydraulic equipment	167
General information	167
Safety devices	167
Working on electrical equipment	167
Safety regulations for servicing	
Set values	168
Safety regulations when driving	69
Safety regulations when handling loads	89
Sample graphics	6
Securing	144
Securing lift mast against tilting back	170
Securing the telescopic lift mast	170
Securing the triple lift mast	171
Service intervals	159
Service restraining belt	
Replacement after accident	199
Service the restraining belt	198
Checking the restraining belt	199
Cleaning the belt	199
Set values	168
Setting forks	91
Setting the date	121
Setting the language	122
Setting the load chains	
Tele mast	197
Triplex mast	197
Setting the time	121
Setting the traction programs	68
Shutdown	151
Side windows	112
Signal terms	5
Spare Parts	162
Special equipment	48
Special risks	14
Specialist	20
Start the engine	62
Steering	80
Steering axle	
Checking	192
Checking the hoses for leaktightness	194
Lubrication	194
Maintenance	192
STEERING message	139
Steering system	
Checking function	68
Storage	152
Stub axle nuts	
Checking tightening torque	194
SURVEILLANCE message	138
<b>T</b>	
Technical data	
Dimensions	226
Time of maintenance	157

Tow coupling	
manual	117
Towed load	116
Towing	144
Proper usage	10
Trailer	
Towing	119
Transport	143
Transport of swinging loads	93
Transporting pallets	92
Travel direction switch	
Single-pedal operation with multiple lever version	75
Turning on the key switch	60
Tyres	
Safety principles	25
<b>U</b>	
Use of working platforms	12
Use wheel chocks	151
<b>V</b>	
Variants	48

VDI datasheet	227
Vehicle identification number	47
Visual inspections	52

**W**

Warning regarding non-original parts	24
Washing outside of truck	174
Wearing parts	162
Wedging	143
Wheels and tyres	
Checking air pressure	191
Checking condition and wear of the tyres	191
Checking wheel fastenings	192
Maintenance	191
Technical data	230
Testing the condition	55
Windscreen wiper/-washer	111
Working at the front of the forklift truck	170
Working materials	
Safety information Oils	29
Safety precautions for hydraulic fluid	32
Working on electrical equipment	167



Still GmbH  
Berzeliusstrasse 10  
D-22113 Hamburg

Ident no. 171650 - V2 EN